


Motor Controller SFC-LACI

FESTO

Manual

Motor Controller

Type
SFC-LACI-...-DN
(DeviceNet)



Manual

567 387
en 0812NH
[742 429]

Contents and general instructions

Original de

Edition en 0812NH

Designation GDGP-SFC-LACI-DN-EN

Order no. 567 387

© (Festo AG & Co. KG, D-73726 Esslingen, Germany, 2009)

Internet: <http://www.festo.com>

E-Mail: service_international@festo.com

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility module or design.

Adobe® and Reader® are either a registered trademark or a trademark of Adobe Systems Incorporated in the United States and/or other countries.

DeviceNet® is a registered trademark of Open DeviceNet Vendor Association, Inc. (ODVA)

Contents

Intended use	IX
Safety instructions	X
Target group	XI
Service	XI
Scope of delivery	XI
Important user instructions	XII
SFC-LACI motor controller manual	XIV
Information on the version	XV
Product-specific terms and abbreviations	XVI
Field bus specific terms and abbreviations	XIX
 1. System summary	 1-1
1.1 Overview	1-3
1.1.1 Components	1-3
1.1.2 Operating principle	1-5
1.1.3 Operational reliability	1-7
1.1.4 Operating modes of the SFC-LACI-DN	1-10
1.1.5 Measuring reference system	1-11
1.1.6 Homing methods to switch with index search	1-14
1.1.7 Homing methods to the stop	1-17
1.2 Communication	1-18
1.2.1 Data exchange via DeviceNet	1-18
1.2.2 Festo handling and positioning profile (FHPP)	1-23
1.3 Commissioning options	1-26
 2. Fitting	 2-1
2.1 General Information	2-3
2.2 Dimensions of the controller	2-4
2.3 Mounting the controller	2-5
2.3.1 Wall mounting	2-5
2.3.2 H-rail mounting	2-6

3.	Installation	3-1
3.1	Installation overview	3-3
3.2	Power supply	3-6
3.2.1	Function of the hardware enable	3-9
3.3	Earthing	3-10
3.4	Motor connection	3-11
3.5	Parameterising interface	3-14
3.6	Controller interface	3-16
3.7	Connecting the field bus	3-18
3.7.1	Field bus cable	3-18
3.7.2	Field bus baud rate and field bus length	3-19
3.7.3	Bus power supply	3-20
3.7.4	Connection with field bus plugs / adapters from Festo	3-21
3.7.5	Connection with other Sub-D plugs (IP20)	3-25
3.8	Bus termination with terminating resistors	3-26
3.9	Local digital inputs and outputs	3-27
3.9.1	Specifications of the outputs	3-28
3.9.2	Specifications of the inputs	3-29
4.	Control panel (only type SFC-LACI-...-H2)	4-1
4.1	Design and function of the control panel	4-4
4.2	The menu system	4-6
4.3	[Diagnostic] menu	4-8
4.4	[Positioning] menu	4-11
4.5	[Settings] menu	4-13
4.5.1	[Settings] [Axis type]	4-14
4.5.2	[Settings] [Axis parameter]	4-14
4.5.3	[Settings] [Homing paramet.]	4-15
4.5.4	[Settings] [Position set]	4-16
4.5.5	[Settings] [Jog mode]	4-17
4.5.6	[Settings] [BUS parameter]	4-17
4.5.7	[Settings] [Password edit]	4-18
4.6	Menu command "HMI control"	4-20

5.	Commissioning	5-1
5.1	Preparations for commissioning	5-4
5.1.1	Checking the drive	5-5
5.1.2	Checking the power supply	5-5
5.1.3	Before switching on	5-6
5.1.4	Simultaneous attempts to access the controller	5-7
5.2	Commissioning with the control panel (only SFC-LACI-...-H2)	5-8
5.2.1	Set the field bus parameter	5-9
5.2.2	Setting the homing run parameters	5-11
5.2.3	Activate device control	5-13
5.2.4	Carrying out homing	5-14
5.2.5	Teach the axis zero point	5-16
5.2.6	Teach software end positions	5-18
5.2.7	Setting the tool mass	5-19
5.2.8	Teaching positioning records	5-20
5.2.9	Test run	5-22
5.3	Commissioning with FCT	5-23
5.3.1	Installing the FCT	5-24
5.3.2	Procedure	5-25
5.4	Commissioning on a DeviceNet master	5-27
5.4.1	Overview of commissioning on the field bus	5-27
5.4.2	Configuration of the DeviceNet master ("I/O configuration")	5-28
5.5	Festo Handling and Positioning Profile (FHPP)	5-30
5.5.1	FHPP operating modes	5-30
5.5.2	Structure of the cyclic I/O data (FHPP standard)	5-32
5.5.3	Description of the I/O data (Record select)	5-34
5.5.4	Description of the I/O data (Direct mode)	5-35
5.5.5	Description of the control bytes CCON, CPOS, CDIR	5-36
5.5.6	Description of the status bytes SCON, SPOS, SDIR (RSB)	5-39
5.5.7	Examples of control and status bytes (FHPP standard)	5-42

5.6	Drive functions	5-56
5.6.1	Homing	5-56
5.6.2	Jog mode	5-58
5.6.3	Teaching via field bus	5-60
5.6.4	Record selection: Carrying out a record	5-62
5.6.5	Record selection: Switching to next record	5-67
5.6.6	Direct mode: Specification of a position or force	5-68
5.6.7	Direct mode: Continuous setpoint specification (Continuous Mode)	5-72
5.6.8	Standstill monitoring	5-74
5.6.9	Using hardware enable	5-76
5.6.10	Using the local digital outputs	5-77
5.6.11	Using a brake/clamping unit	5-84
5.6.12	Position sampling (on-the-fly measurement)	5-87
5.7	Notes on operation	5-89
6.	Diagnosis and fault display	6-1
6.1	Diagnostics options	6-3
6.2	LED status displays	6-5
6.3	Error messages	6-7
6.4	Diagnostics via field bus	6-14
6.4.1	Overview	6-14
6.4.2	Diagnostic memory	6-15
6.5	Diagnosis via parameter channel (FPC)	6-17
6.6	Warning “Index pulse warning”	6-18

A.	Technical appendix	A-1
A.1	Technical data	A-3
A.2	Accessories	A-5
A.3	Converting the units of measurement	A-6
B.	Parametrizing via field bus	B-1
B.1	Parameterising via Explicit Messaging	B-3
	B.1.1 DeviceNet Classes	B-3
	B.1.2 Parameter overview (class, attribute, instance)	B-4
B.2	Parameterisation via FPC	B-15
	B.2.1 Structure of the Festo Parameter Channel (FPC)	B-15
	B.2.2 Task identifiers, response identifiers and error numbers	B-17
	B.2.3 Rules for job reply processing	B-20
	B.2.4 Example of parameterising via FPC	B-22
B.3	FHPP finite state machine	B-24
	B.3.1 Create readiness to operate	B-26
	B.3.2 Positioning	B-27
B.4	Reference FHPP Parameters	B-30
	B.4.1 FHPP parameter groups	B-30
	B.4.2 Overview of parameter numbers (PNU)	B-31
	B.4.3 Representation of the parameter entries	B-40
	B.4.4 Device data	B-41
	B.4.5 Diagnosis	B-48
	B.4.6 Process Data	B-55
	B.4.7 Positioning record table (Record list)	B-65
	B.4.8 Project data	B-79
	B.4.9 Axis parameters for electric drives 1	B-88
	B.4.10 Supplementary objects	B-101

C.	CI interface	C-1
C.1	The CI interface	C-3
C.1.1	Using the parameterising interface	C-3
C.1.2	Accessing the CI objects	C-4
C.1.3	Access via a terminal program	C-5
C.1.4	Composition of the CI commands	C-6
C.1.5	Checking the data	C-9
C.2	Reference CI	C-11
C.2.1	Object overview (Index, Subindex)	C-11
C.3	Description of additional CI objects	C-21
C.3.1	Communication Profile Area	C-22
C.3.2	Manufacturer Specific Profile Area	C-23
C.3.3	Standardised Device Profile Area	C-29
D.	Index	D-1

Intended use

The single-axis field controller (Single Field Controller) type SFC-LACI-... is used as a position controller and position servo for the electric drives, types DNCE-...-LAS and DFME-...-LAS.

This manual deals with the basic functions of the SFC-LACI and the DeviceNet interface of the SFC-LACI-...-DN. The drives DNCE-...-LAS and DFME-...-LAS and additional components are documented in separate operating instructions.

The SFC-LACI and the connectable modules and cables may only be used as follows:

- as designated
 - only in industrial applications
 - in faultless technical condition
 - in original condition without modification (only the conversions or modifications described in the documentation supplied with the product are permitted).
-
- Follow the safety instructions and use all the components and modules as described in the documentation.
 - Observe also the standards specified in the relevant chapters, as well as national and local laws and technical regulations.
 - Observe the maximum values of all additional components (e.g. sensors, actuators).

Safety instructions

When commissioning and programming positioning systems, the safety regulations in this manual as well as those in the operating instructions for the other components used should be observed unconditionally.

The user must make sure that nobody is within the sphere of influence of the connected actuators or axis system. Access to the possible danger area must be prevented by suitable measures such as protective screens and warning signs.



Warning

Electric axes move with high force and at high speed. Collisions can lead to serious injury to human beings and damage to components.

- Make sure that nobody can reach into the sphere of influence of the axes or other connected actuators and that no items are within the positioning range while the system is connected to energy sources.



Warning

Errors in parameterizing can cause injury to human beings and damage to property.

- Enable the controller only if the axis system has been correctly installed and parameterized.

Target group

This manual is intended exclusively for technicians trained in control and automation technology, who have experience in installing, commissioning, programming and diagnosing positioning systems.

Service

Please consult your local Festo Service or write to the following e-mail address if you have any technical problems:

service_international@festo.com

Scope of delivery

Included in the scope of delivery for motor controller type SFC-LACI are:

- Single field controller, optionally with control panel
- Configuration package FCT (Festo configuration tool)
- User documentation on CD ROM

The following are available as accessories (see appendix A.2):

- Connecting cables
- Mounting attachments

Important user instructions

Danger categories

This manual contains instructions on the possible dangers which may occur if the product is not used correctly. These instructions are marked (Warning, Caution, etc.), printed on a shaded background and marked additionally with a pictogram. A distinction is made between the following danger warnings:



Warning

This means that failure to observe this instruction may result in serious personal injury or damage to property.



Caution

This means that failure to observe this instruction may result in personal injury or damage to property.



Note

This means that failure to observe this instruction may result in damage to property.

The following pictogram marks passages in the text which describe activities with electrostatically sensitive components.



Electrostatically sensitive components may be damaged if they are not handled correctly.

Marking special information

The following pictograms mark passages in the text containing special information.

Pictograms



Information:
Recommendations, tips and references to other sources of information.



Accessories:
Information on necessary or sensible accessories for the Festo product.



Environment:
Information on environment-friendly use of Festo products.

Text markings

- The bullet indicates activities which may be carried out in any order.
- 1. Figures denote activities which must be carried out in the numerical order specified.
- Hyphens indicate general activities.

SFC-LACI motor controller manual

This manual contains basic general information on operating, mounting, installing and commissioning the positioning systems with the motor controller SFC-LACI-...-DN. It also contains information on the functions of the DeviceNet interface as well as information on commissioning with the Festo Configuration Tool (FCT) software package.



Information on additional components can be found in the operating instructions supplied with the product.

Type	Designation	Contents
Brief overview + descriptions on CD ROM	–	Brief overview: Important initial information and documentation overview CD: Includes descriptions as listed below
Description	Motor controller SFC-LACI GDCP-SFC-LACI-DN-...	Installation, commissioning and diagnosis of positioning systems with the SFC-LACI with communication via DeviceNet
Help system for software	Festo Configuration Tool help (contained in FCT software)	Functional descriptions for the Festo Configuration Tool configuration software
Further descriptions as per control interface	Variants GDCP-SFC-LACI-IO-... GDCP-SFC-LACI-PB-... GDCP-SFC-LACI-CO-...	Installation, commissioning and diagnosis of electric drives with the SFC-LACI with communication via a different control interface
Operating instructions	Drives DFME-...-LAS DNCE-...-LAS	Installing and commissioning the drive

Information on the version

The hardware version specifies the version status of the mechanical and electronic components of the SFC-LACI. The firmware version specifies the version status of the operating system of the SFC-LACI.

You can find the specifications on the version status as follows:

- Hardware version and firmware version under “Device data” in the Festo Configuration Tool, when there is active linkage to the SFC-LACI.
- Firmware version on the control panel under [Diagnostic] [SW information].


Firmware version from	What is new?	Which FCT Plugin?
V 01.00	Motor controller mit DeviceNet interface Type SFC-LACI-...-DN supports the following drives: <ul style="list-style-type: none">– DNCE-...-LAS– DFME-...-LAS	SFC-LAC V 03.00

Product-specific terms and abbreviations

Term / abbreviation	Meaning
0-Signal	There is a 0 V signal present at the input or output (positive logic, corresponds to LOW)
1-Signal	There is a 24 V signal present at the input or output (positive logic, corresponds to HIGH)
Acknowledge	Confirm, reply message, e.g. “Acknowledge START.” “Acknowledge an error.” The user confirms that he has noted the error. The device then leaves the error status (if the error still exists, it will be displayed again).
Applied load (Additional load)	The mass of a workpiece. Applies only to a single positioning record, see Fig. 0/1
AZ (= axis zero point),	Axis zero point, see section 1.1.5
EMC	Electromagnetic compatibility
FCT (= Festo Configuration Tool)	Software with uniform project and data management for all supported device types. The special requirements of a device type are supported with the necessary descriptions and dialogues by means of plug-ins.
FHPP	“Festo Handling and Positioning Profile”: Uniform field bus data profile for positioning controllers from Festo. See 1.2.2
FHPP standard	FHPP sequence control. See 1.2.2
FPC	“Festo Parameter Channel” for parameter access. See section 1.2.2
HALT	With a HALT signal, a running positioning movement is interrupted and the drive stops. The positioning record remains active, i.e. with a new START signal the record will be continued. Compare STOP.
HMI	“Human Machine Interface” refers to the control panel on the variant SFC-LACI-...-H2. [HMI = on] means that parameterisation and operation can begin using the control panel or FCT. The control interface is then deactivated.
Homing run	See overview of measuring reference system in section 1.1.5
I/O	Input and/or output
Jog mode	Manual positioning in positive or negative direction

Term / abbreviation	Meaning
Load voltage, logic voltage	The load voltage supplies the power electronics of the motor controller and thereby the motor. The logic voltage supplies the evaluation and control logic of the motor controller as well as the local digital I/Os (see section 3.2).
MMI	“Man Machine Interface”, corresponds to HMI
PLC/IPC	Programmable logic controller/industrial PC
Positioning mode (Profile position mode)	See overview of operating modes in section 1.1.4
Position record	Positioning command defined in the position set table, consisting of target position, speed, acceleration and other values
PZ (= project zero point)	Project zero point, see section 1.1.5
REF (= REFerence point)	Reference point, see section 1.1.5
Reference switch	Proximity sensor used for defining the reference point. The integrated homing switch must not be moved in DNCE-...-LAS and DFME-...-LAS (exception: minimum offset as described in section 6.6).
Software limit	See overview of measuring reference system in section 1.1.5
STOP	With a STOP signal a running positioning movement is interrupted: The drive stops, the positioning record counts as concluded. Compare HALT.
Teaching	Accept an actual position in the position set table, or as axis zero point, project zero point, or software end point. The desired position can be approached in Jog mode.
Tool load	For example: the mass of a gripper attached to the piston rod (or the front plate) of the drive (including mounting elements). The tool load applies to all positioning records, see Fig. 0/1

Tab. 0/1: Index of terms and abbreviations



- 1 Tool load
- 2 Additional load
- 3 The total of 1 and 2: see under “Effective load” in the operating instructions for the drive

Fig. 0/1: Tool load and additional load

Field bus specific terms and abbreviations

Term / abbreviation	Meaning
0x1234 or 1234h	Hexadecimal numbers are marked by a prefixed “0x” or by a suffixed “h”
ATTR	ATTRibute number
BCD	Binary coded decimal
Bit strobe	All slaves are scanned by the master with a command. Serves for transmitting small amounts of data between a master and one or several slaves, e.g. for synchronizing input or output data (is not supported by the SFC-LACI-DN).
CI	Command Interface
CLS	CLaS, object classification
COS/Cyclic	The messages are sent either by the master or by the slave cyclically (at a fixed time interval), or when there is a change of state. In COS messaging, a message is generated “cyclically” if no status change occurs within a certain time; for this reason COS and Cyclic are often treated as a single message type.
EDS	Electronic Data Sheet; contains the specific properties of the slave (e.g. number of I/Os, parameters, etc.).
Explicit Messaging	Direct connection. Explicit Messaging constitutes an (acyclic) point-to-point communications connection with low priority between two devices, and is typically used for configuration and diagnostic purposes. Explicit messages contain the address and value of an attribute and a Service Code that describes how these data are to be treated.
I/O messaging (implicit messaging)	I/O data transfer “I/O Messaging” is used for the exchange of time-critical data (e.g. process data). An I/O message contains exclusively data. All information about how the data are to be treated are stored in the “Connection” object that is assigned to this message.
I/O polling	The slaves are interrogated by the master. The master sends a polling command to a slave; data for the slave are transmitted together with this. If the slave has on its part any data for the master, then it sends them to the master. If a slave does not answer a polling request from a master, then this results in a timeout.
INST	INSTance number

Term / abbreviation	Meaning
LSB	Least significant byte (lower-value byte)
MAC ID	Media AccessControl Identifier, see “Slave address”
MSB	Most significant byte (higher-value byte)
Object	Data (attributes) are summarised in an object. These attributes describe various properties of a DeviceNet device, and can be read and written via the bus. Access see: “Object Directory”
Object Directory	The Object Directory contains all device parameters and current processing data which are directly accessible via FHPP, field bus or CI. The Object Directory is divided into a range which contains general specifications on the device (device identification, manufacturer name etc.) and communication parameters, as well as a range which describes the specific device functions. The identification of an entry (object) of the object directory takes place depending on access via: FHPP-FPC: Parameter number PNU CI: Index and Subindex DeviceNet: Class, Instance, Attribute
PNU	Parameter number as per FHPP-FPC
Slave address (node address)	Each of the up to 64 stations in a DeviceNet network has its own MAC ID (Media Access Control Identifier); component of the CAN identifier.
Terminating resistor	Resistor for minimising signal reflections. Terminating resistors must be installed or switched in at the end of bus segment cables.

Tab. 0/2: Index of terms and abbreviations for the field bus

System summary

Chapter 1

Contents

1.1 Overview 1-3

1.1.1 Components 1-3

1.1.2 Operating principle 1-5

1.1.3 Operational reliability 1-7

1.1.4 Operating modes of the SFC-LACI-DN 1-10

1.1.5 Measuring reference system 1-11

1.1.6 Homing methods to switch with index search 1-14

1.1.7 Homing methods to the stop 1-17

1.2 Communication 1-18

1.2.1 Data exchange via DeviceNet 1-18

1.2.2 Festo handling and positioning profile (FHPP) 1-23

1.3 Commissioning options 1-26

1. System summary

1.1 Overview

1.1.1 Components

- 1 Higher-order control
- 2 Software level:
Festo Configuration Tool (FCT)
- 3 Controller level:
SFC-LACI
- 4 Drive level:
DFME-...-LAS or
DNCE-...-LAS




Fig. 1/1: Principle of a positioning system with the SFC-LACI

1. System summary

To construct a positioning system with the SFC-LACI, you need the following components:

SFC-LACI	Motor controller, optionally with control panel
Drive	Electric drive DNCE-...-LAS or DFME-...-LAS, with accessories and mounting attachments
Power supply unit 24 V	for logic voltage supply
Power supply unit 48 V	for load voltage supply
Power supply cable	for supplying the SFC-LACI with logic and load voltage → section 3.2
Motor cable / Encoder cable	for connecting the drive to the SFC-LACI → section 3.4
Programming cable	for information transfer between the PC and the SFC-LACI → section 3.5
Field bus cable	for information transfer between the higher-level controller and the SFC-LACI → section 3.6

1. System summary

1.1.2 Operating principle




Fig. 1/2: Simplified diagram of control structure

No.	Block	Task
1	Setpoint generator	Generates executable position and velocity curves
2	Reference variable input	Uses desired position, velocity and acceleration curves to calculate a force curve and from that a current curve, which is then directly input as the current setpoint value. Permits drive with minimum contouring error.
3	State vector feedback	Controls position and speed
4	PI current regulator	Makes sure that all three strings have the correct current values
5	Output stage	The three strings are supplied with current via pulse width modulation
6	Current Control	Phase current regulation and electrical commutation
7	Observer	Determines speed and external forces of interference (e.g. friction, gravity)

1. System summary

The SFC-LACI has three types of memory:

FLASH

The FLASH memory stores the default settings and the firmware. The data from the FLASH memory are loaded when the device is switched on the first time or when the EEPROM has been deleted.

RAM

The volatile RAM memory stores the parameters that are currently being used and which can be modified using the control panel or FCT. When the modifications have been saved, they are transferred to the EEPROM.

EEPROM

The non-volatile EEPROM stores the parameters that are loaded when the device is switched on. The parameters in the EEPROM are retained even after the power supply has been switched off.



In order to restore the default settings, you can delete the EEPROM with the CI command 20F1h / PNU 127 (see section B.4.4). User-specific settings will then be lost.

1. System summary

1.1.3 Operational reliability

A complex system of sensors and monitoring functions ensures operational reliability:

- Temperature monitoring: Final output stage in the SFC-LACI and linear motor
- Voltage monitoring: detection of faults in the logic power supply and detection of undervoltage in the load voltage supply
- I^2t monitoring / overload protection
- Contouring error monitoring (e.g. in the event of sluggishness or overloading of the drive)
- Software end position detection
- Limit switch detection



Note

Check within the framework of your EMERGENCY STOP procedures to ascertain the measures that are necessary for switching your machine/system into a safe state in the event of an EMERGENCY STOP.

- If an EMERGENCY STOP circuit is necessary for your application, use additional, separate safety limit switches (e.g. as normally closed limit switches wired in series).
- Use hardware limit switches or, if required, mechanical safety limit switches and fixed stops or shock absorbers as appropriate in order to make sure that the axis always lies within the permitted positioning range.

1. System summary

- Note also the following points:

Remedy	Reaction
Cancelling the ENABLE signal at the controller interface	<ul style="list-style-type: none">– Without brake/clamping unit: The controller end stage is switched off. The effective load on the drive will continue to move due to inertia, or it will fall if mounted in a vertical or sloping position.– When using a brake/clamping unit: If the drive moves when ENABLE is cancelled, then it will initially be brought to a standstill (using quick stop deceleration). As soon as the drive is standing still, the configured brake output (Out1 or Out2) is reset: The brake/clamping unit closes. Simultaneously, the switch-off delay time begins to run. The SFC-LACI still controls the position. The controller end stage is switched off after the switch-off delay.
Switching off the load voltage or cancelling the hardware enable	The load voltage is switched off The effective load on the drive will continue to move due to inertia, or it will fall if mounted in a vertical or sloping position. The controller may report the drop out of the load voltage after a few seconds have initially passed. Accordingly, a brake is only closed after a delay. Refer also to the information on using the hardware enable in section 5.6.9.
Cancelling the STOP signal at the controller interface.	By default, the drive brakes with the “Quick stop deceleration” (can be set via FCT or CI object 6085h). As an alternative, the braking ramp in the respective positioning record can be used, see CI object 605Eh.
Triggering a limit switch	The drive brakes with the limit switch deceleration (can be set via FCT or CI object 6510/15h). The error message “Limit switch actuated” is issued. The drive held stationary in a controlled position, The brake is opened (if present), Err = 0, MC = 0, Ready = 0 (if no automatic brake is parameterised).



Note

Remaining path check for the STOP signal

If the parameterised stop ramp is not sufficient to stop the drive before reaching the software end point, the deceleration (braking) is raised to the maximum value, as far as possible.

1. System summary



Warning

There is no plausibility check to see whether the deceleration (braking) that is set is actually achievable. The deceleration that can be achieved depends on your application (e.g. power and switching speed of your power supply unit, effective load, mounting position).

If the deceleration cannot be achieved, an error will occur and the controller may be turned off (depending on the error). The effective load on the drive will continue to move due to inertia, or it will fall if mounted in a vertical or sloping position.

- Perform a test run to see whether the quick stop deceleration that is set is actually achievable.
- When doing this, pay attention to the FCT diagram (“Measured data” page).

If the desired deceleration cannot be achieved:

- Use stronger power units or reduce the dynamics.

1. System summary

1.1.4 Operating modes of the SFC-LACI-DN

Profile position mode	<p>Positioning mode. Standard operating mode when the SFC-LACI is switched on. The specification of the positioning tasks occurs:</p> <ul style="list-style-type: none">– via Record selection: Selection of one, from a maximum of 31 positioning records stored in the SFC-LACI. Automatic record switching is also possible.– via Direct mode: The positioning task is directly transferred with the appropriate setpoint values over the field bus.
Profile Torque Mode	<p>Force control. The drive exerts a certain force.</p>
FHPP Continuous Mode	<p>A changeable target position (continuous nominal specification) is specified at millisecond intervals (typical 4 ... 10 ms).</p>
Homing mode	<p>Performing a homing run</p>
Demo mode	<p>The positioning records stored in the SFC-LACI are executed in sequence.</p>




The FHPP operation modes are described starting from section 5.5.

1. System summary

1.1.5 Measuring reference system

Homing	Homing determines the position of the homing reference point REF. When homing is concluded, the axis stands at the axis zero point AZ.
The homing method	The homing method defines how the homing point REF is determined.
Reference point REF	binds the measuring reference system to a proximity sensor or a fixed stop, depending on the homing method.
Axis zero point AZ	is shifted by a defined distance to the reference point REF (offset of the axis zero point). The software end positions and the project zero point are defined in relation to the axis zero point.
Project zero point PZ	is a point within the effective stroke which the user can freely select and to which both the actual position and the target positions in the position record table refer. The project zero point is shifted by a defined distance to the axis zero point AZ (offset of the project zero point). The offset of the project zero point cannot be adjusted via the control panel.
Software end positions	limit the permitted positioning range (effective stroke). If the target position of a positioning command lies outside the software end positions, the positioning command will not be processed and an error will be registered.
Effective stroke	The distance between the two software end positions. The maximum stroke which the axis can perform with the parameters currently set.
Offset reference point	The distance of the reference point REF from the retracted end position (tolerance +/- 1 mm). For reasons of technical control, this has to be measured and parameterised. See figures in Tab. 1/2 and Tab. 1/3.

1. System summary



Tab. 1/1: Measuring reference system

1. System summary

Calculation rules

Point		Calculation rule	
Axis zero point	AZ	= REF + a	
Project zero point	PZ	= AZ + d	= REF + a + d
Lower software end position	LSE	= AZ + b	= REF + a + b
Upper software end position	USE	= AZ + c	= REF + a + c
Target/actual position	TP, AP	= PZ + g	= AZ + d + g = REF + a + d + g

Prefixed

All points and offsets have a sign prefix:

Value	Direction
+	Positive values face from the basis point in the direction of the extended end position.
—	Negative values face from the basis point in the direction of the retracted end position.

Units of measurement

Different units of measurement can be set in the FCT, e. g. metric (mm, mm/s, mm/s²) or imperial (inch, inch/s, inch/s²).
The CI interface, on the other hand, works with increments.
For converting increments: see section A.3.

1. System summary

1.1.6 Homing methods to switch with index search

The following can be used for homing to a proximity sensor:

1. The integrated reference switch of the drive (recommended). It is located on the retracted (negative) end position and must not be moved (exception: minimum offset with an “Index pulse warning”, see section 6.6).
2. A proximity sensor to be externally attached by the user.




The proximity sensors can be configured as reference switches or as limit switches. This means homing either runs to the reference switch or to the limit switch.

If a proximity switch is configured both as a reference switch and as a limit switch, then its signal during homing is interpreted as a reference signal, and afterwards as a limit switch signal in the referenced state of the drive.


1. System summary

Homing methods to switch with index search

– Switch negative (at the retracted end position)



– Switch positive (at the extended end position)



- 1 The drive (here: DFME-...-LAS) moves at search speed v_{rp} to the switch and reverses. After leaving the switching range, the drive moves to the next index signal of the displacement encoder. The reference point REF is there.
- 2 Then the drive moves at speed v_{zp} from the reference point REF to the axis zero point AZ.

Tab. 1/2: Homing to switch with index search

1. System summary

Special features of homing

To reference switch

If a reference signal is not found when homing to the reference switch before the drive reaches a fixed stop or a limit switch, then the drive will reverse and search for the switch in the opposite direction. If a reference signal is found there, the drive runs through the switching range of the reference switch. The reference point is subsequently the following index pulse at the end of the switching range.

To limit switch

If a reference signal is not found when homing to the limit switch before the drive reaches a fixed stop, then homing is interrupted and a homing error is registered.



Note



Homing error due to incorrect positioning of the limit switches

- Position the limit switches such that the switching range extends over the nearest fixed stop (or end position). There must be no range between the limit switch and fixed stop (or end position) in which the limit switch is not actuated (undefined range).
- Note that ferritic elements (e.g. mounting attachments) in the vicinity of magnetic switches can move the switching range.

1. System summary

1.1.7 Homing methods to the stop

Exact homing by reference to a fixed stop can only be carried out against externally fitted stops (without rubber buffer or similar). Therefore you should preferably use the homing methods to switch.

Homing methods to the stop	
– Negative fixed stop (retracted end position, near to motor)	
 <p>The diagram illustrates the homing process for a negative fixed stop. In step 1, the drive moves to the left until it reaches a fixed stop, which is marked as the reference point (REF). The distance from the motor to this stop is labeled as $Offset_{Ref}$. In step 2, the drive moves to the right from the REF position to the axis zero point (AZ). The distance between REF and AZ is marked with a '+' sign.</p>	
– Positive fixed stop (extended end position, remote from motor)	
 <p>The diagram illustrates the homing process for a positive fixed stop. In step 1, the drive moves to the right until it reaches a fixed stop, which is marked as the reference point (REF). The distance from the motor to this stop is labeled as $Offset_{Ref}$. In step 2, the drive moves to the left from the REF position to the axis zero point (AZ). The distance between REF and AZ is marked with a '-' sign. In step 3, an externally fitted fixed stop is shown at the end of the travel.</p>	
<p>1 The drive (here: DFME...-LAS) moves at search speed v_{rp} to the fixed stop (= reference point).</p> <p>2 The drive moves at speed v_{zp} from the reference point to the axis zero point AZ. The offset must be $\neq 0$!</p> <p>3 Externally fitted fixed stop</p>	

Tab. 1/3: Homing to the stop

1.2 Communication

1.2.1 Data exchange via DeviceNet

DeviceNet was developed by Rockwell Automation and the ODVA (Open DeviceNet Vendor Association) as an open field bus standard based on the CAN protocol. DeviceNet belongs to the CIP-based networks. CIP (Common Industrial Protocol) forms the user interface of DeviceNet and defines the exchange of:

- I/O messages, e.g. time-critical processing data and
- explicit messages with low priority, e.g. for configuration or diagnosis.



The Open DeviceNet Vendor Association (ODVA) is the user organisation for DeviceNet. Publications on the DeviceNet/ CIP specification can be found under:

- ODVA (Open DeviceNet Vendor Association)
<http://www.odva.org>
- CI (ControlNet International)
<http://www.controlnet.org>.

Explicit Messages (Explicit Messaging)

Explicit messages consist of a request and an answer. This way services can be directly requested from or executed by a station.

Explicit messages contain (target address, class, instance, attribute and value of the attribute as well as a service identifier (service code) for data use.

1. System summary

I/O Messages (I/O Messaging)

I/O messages are sent by a station, and can be received and processed by one or more stations. For I/O messages, the following dialogues are possible between the stations:

- the slaves are interrogated cyclically by the master (Polled I/O), or
- the messages are sent either by the master or by the slave cyclically, or when there is a change of state (COS/Cyclic), or
- all slaves are scanned by the master with a command (“Bit Strobe” is not supported by the SFC-LACI).

The data field contains exclusively user data; no protocol data are specified. All information on using the data are saved in the assigned “Connection Object”.

Up to 64 field bus nodes can be operated via the serial CAN bus in a DeviceNet network. The extent of the network depends on the baud rate selected (125 kBaud, 250 kBaud or 500 kBaud).

DeviceNet telegrams contain up to 8 bytes of user data. If it is necessary to exchange larger amounts of data, then the data are broken down by means of fragmentation before being sent, transmitted sequentially and then put together again in the recipient. This normally occurs automatically.

The configuration data contain the source and the destination address of the data for the sender and recipient of the messages.

1. System summary

Object model	<p>In DeviceNet, data are accessed via objects. Each DeviceNet station has one or more objects of various classes. An object is an instance of a class:</p> <ul style="list-style-type: none">– Standard classes describe e.g. basic features, the communication behaviour or parameters of individual channels of a slave.– Manufacturer-specific classes describe device-specific properties or parameters.
Device profile	<p>Device profiles define the minimum available objects and communication functions for the specific device types. The SFC-LACI corresponds to the DeviceNet specification of the device profile “Communication Adapter” (device type number 000Ch).</p>
Predefined connection	<p>For simple slave devices, predefined master/slave connections (“Predefined Master/Slave Connection Sets”) can be used; these simplify the transmission of I/O data between the higher-order controller (master) and the decentralised peripheral devices (slaves). The SFC-LACI-DN works according to the specification “Predefined connection set, Group 2 slave only”.</p>

1. System summary

As “Group 2 slave” the SFC-LACI-DN supports the following dialogue types, services and object classes:

CAN ID	Dialogues (Message Type)
10xxxxxx010	Master’s Change of State or Cyclic Acknowledge
10yyyyyy011	Slave’s Explicit/ Unconnected Response
10xxxxxx100	Master’s Explicit Request
10xxxxxx101	Master’s I/O Poll Command/Change of State/Cyclic
10xxxxxx110	Unconnected Explicit Request Messages
10xxxxxx111	Duplicate MAC ID Check Messages
CAN ID = Connection ID (DeviceNet) xxxxxx = MAC ID (Destination) yyyyyy = MAC ID (Source)	

Service Code	Service Name
14 (0x0E)	Get Attribute Single
16 (0x10)	Set Attribute Single
75 (0x4B)	Allocate Group 2 Identifier Set
76 (0x4C)	Release Group 2 Identifier Set

1. System summary

DeviceNet Standard Classes	Class
Identity Objects e.g. manufacturer identifier, device type, etc.	001
Message Router for forwarding of “Explicit Messages” to other objects	002
DeviceNet Objects – e.g. MAC ID, baud rate, etc.	003
Assembly Objects Summary of the attributes of a number of objects, so that the data to or from all the objects can be sent or received over a single connection.	004
Connection Objects Management of resources for “Explicit Messaging” and “I/O Messaging”	005
Acknowledge Handler Management and reply messages for receipt acknowledgements, timeouts for acknowledgements and limit values for repeat attempts, etc.	043

Festo-specific classes	Class
Diagnostic memory	101
Diagnostic memory (administration)	102
Process data	103
Record list	104
Project data	105
Factor group	106
Axis data electric drives 1	107
System errors	108
Field bus diagnosis	109
Hybrid parameter (only for Festo Service)	110
Test commands (only for Festo Service)	111
Data Trace Administration (only for Festo Service)	112

1. System summary

1.2.2 Festo handling and positioning profile (FHPP)

Customised for handling and positioning tasks, Festo developed an optimised data profile, the “Festo Handling and Positioning Profile (FHPP)”.

FHPP enables uniform sequence control and programming for the various field bus systems and controllers from Festo.

Communication via the field bus can take place cyclically (I/O Messaging) or acyclically (Explicit Messaging). Mixed operation is typical:

- Commissioning and application parameters are transmitted via “Explicit Messaging”.
- Time-critical sequence control is performed according to **FHPP Standard** (“I/O Messaging”, 8 bytes I/O).
- Parameterisation in operation is done according to **FHPP-FPC** (“I/O Messaging”, 8 bytes I/O) or via “Explicit Messaging”.

FHPP standard

FHPP standard is used for time-critical sequence control. Here there are two FHPP operation modes:

- **Record selection:**
The higher-level control (PLC) selects positioning records (positioning tasks) stored in the SFC-LACI.
- **Direct mode:**
The tasks are formulated directly in the master’s cyclical output data. Possible are positioning mode, continuous setpoint specification and gasoline operation.

Detailed information on the FHPP standard can be found starting at section 5.5.



FHPP-FPC (Festo Parameter Channel)

Optionally, an additional 8 I/O bytes can be used for parameterisation via FPC. The additional bytes can be configured via the I/O data length (HMI, FCT software).

	Assembly Object		Data ¹⁾ Byte	Tele-grams
	Input	Output		
FHPP standard	128	130	8	1
FHPP standard + FPC	129	131	16	3
¹⁾ Setting the data length, see CI object 2FF5				

Tab. 1/4: Data length

If the FPC is not needed in normal operation, the data length can be reduced to 8 bytes (= FHPP standard) in order to optimise the PLC access in cyclic data transfers. Instead of 3 telegrams, only one more telegram is then transmitted. Parameter modifications can still be carried out with “Explicit Messaging”.



Detailed information on the FHPP-FPC can be found starting in the section B.2.

1. System summary




Fig. 1/3: Festo Handling and Positioning Profile (FHPP)

1.3 Commissioning options

You can parameterise and commission the SFC-LACI as follows:

- with the Festo Configuration Tool (FCT)
→ section 5.3
- at the control panel (HMI, nur Typ SFC-LACI-...-H2)
→ chapters 4 and 5
- via DeviceNet (DN) → section 5.4.1

Functions		HMI	FCT	DN
Parameterisation	- Choice: Drive and associated parameters	x	x	x
	- Uploading/downloading of configuration data	-	x	x
	- Saving different configurations in projects	-	x	x
	- Creating a position set table	x	x	x
	- Configuration of a chained record	-	x	x
	- Parameterising force mode	-	x	x
	- Parameterising jog mode	-	x	x
Commissioning	- Homing run (limited selection with HMI)	(x)	x	x
	- Teaching of positions	x	x	x
	- Testing position sets	x	x	x
	- Testing set chaining	x	x	x
	- Testing force mode	-	x	x
	- Testing jog mode	-	x	x
	- Testing continuous setpoint specification	-	-	x
Diagnostics / Service	- Reading and displaying diagnostic data	x	x	x
	- Oscilloscope function (trace): Graphic presentation of positioning procedures	-	x	-



Parameterisation can also be done via the parameterisation interface with CI commands (→ section B.2). Only experienced users may operate the module by means of CI commands.

Fitting

Chapter 2

Contents

2.1 General Information 2-3

2.2 Dimensions of the controller 2-4

2.3 Mounting the controller 2-5

2.3.1 Wall mounting 2-5

2.3.2 H-rail mounting 2-6

2. Fitting

2.1 General Information



Caution

Uncontrolled drive motion may cause personal injury and material damage.

- Before carrying out fitting, installation and/or maintenance work, always switch off the power supply.



Caution

If a drive is mounted in a sloping or vertical position, loads may fall down and cause injury to persons.

- Check whether additional external safety measures are necessary (e.g. toothed latches or moveable bolts).

This prevents the work load sliding down suddenly if there is a power failure.



Also note the following documentation:

- The operating instructions for the drive, (e.g. DNCE-...-LAS)
- The instructions for the additional components (e.g. the fitting instructions for the cables).

2. Fitting

2.2 Dimensions of the controller




Fig. 2/1: Dimensions of the controller

2.3 Mounting the controller

You can mount the SFC-LACI in one of two ways:

1. Wall mounting on a flat surface
2. H-rail mounting



Note

Mount the SFC-LACI or hat rail so that there is sufficient space for heat dissipation (above and below at least 40 mm).

2.3.1 Wall mounting

You will need:

- A mounting surface of approximately 250 x 320 mm
- 2 sets of central supports type MUP-8/12 (accessory items)
(The four brackets are clipped into the edge of the housing, see Fig. 2/2.)
- 4 tapped holes for screw size M3 with matching screws.




Fig. 2/2: Wall mounting

2. Fitting

2.3.2 H-rail mounting

Procedure:

1. Make sure that the mounting surface can support the weight (approx. 1500 g) of the SFC-LACI.
2. Install an H-rail (mounting rail EN 50022 – 35x7.5 or better still 35x15).
3. For rail 35x7.5: the max. distance is 3.3 mm between the housing web and the H-rail.
 - If possible, use a part of the H-rail where there are no mounting screws.
 - If screws are necessary below the SFC-LACI: use e.g. an M6 screw as per ISO-7380ULF.
4. Hang the SFC-LACI on the H-rail as follows:
 - first from below, pressing against the tension springs, then
 - press up against the H-rail so that the SFC-LACI clicks into place.

- 1** H-rail
- 2** Tension springs
- 3** Distance between housing web and H-rail: 3.3 mm (rail 35x7.5)




Fig. 2/3: H-rail mounting

Installation

Chapter 3

Contents

3.1 Installation overview 3-3

3.2 Power supply 3-6

3.2.1 Function of the hardware enable 3-9

3.3 Earthing 3-10

3.4 Motor connection 3-11

3.5 Parameterising interface 3-14

3.6 Controller interface 3-16

3.7 Connecting the field bus 3-18

3.7.1 Field bus cable 3-18

3.7.2 Field bus baud rate and field bus length 3-19

3.7.3 Bus power supply 3-20

3.7.4 Connection with field bus plugs / adapters from Festo 3-21

3.7.5 Connection with other Sub-D plugs (IP20) 3-25

3.8 Bus termination with terminating resistors 3-26

3.9 Local digital inputs and outputs 3-27

3.9.1 Specifications of the outputs 3-28

3.9.2 Specifications of the inputs 3-29

3.1 Installation overview



Warning

Before carrying out fitting, installation and/or maintenance work, always switch off the power supply.

In this way, you can avoid:

- uncontrolled movements of the connected actuators
- undefined switching states of the electronic components
- damage to the electronic components.



Caution

Faulty pre-assembled lines may destroy the electronics and trigger unexpected movements of the motor.

- For connecting the electric components of the system, use only the cables listed as accessories (see Tab. 3/2).
- Lay all flexible lines so that they are free of kinks and free of mechanical stress; if necessary use chain link trunking.

3. Installation




Fig. 3/1: Connections to the SFC-LACI

Connection to the SFC-LACI-DN			Description
1	Parameterising interface	M8 socket, 4-pin	RS232 interface for parameterising, commissioning and diagnosis via FCT → section 3.5
2	Controller interface	Sub-D, 9-pin, plug	Interface for connecting to a PLC controller → section 3.6
3	Voltage supply	Sub-D-7WT, plug	Voltage connection with 2 high-current contacts and 5 low-current contacts (separate load and logic voltage supply) → section 3.2
4	Earth terminal	Stud bolt, M4	Connection for functional earth → section 3.3
5	Local digital I/Os	M8 socket, 3-pin	Local digital inputs and outputs → section 3.9
6	Motor connection	Plug connector, type ITT Cm3	Power supply for linear motor and sensor signals → section 3.4

Tab. 3/1: Overview of connections

3. Installation



If unused plug connectors are touched, there is a danger that damage may occur to the SFC-LACI or to other parts of the system as a result of ESD (electrostatic discharge). Place protective caps on unused terminal connections in order to prevent such discharges.

Overview of cables and plugs

Connection		Cable/plug	Type
1	Parameterising interface	Programming cable	KDI-MC-M8-SUB-9-2,5
2	Controller interface	Field bus plug	FBS-SUB-9-BU-2x5POL-B
		Field bus adapter	FBA-2-M12-5POL
3	Voltage supply	Power supply cable	KPWR-MC-1-SUB-15HC-...
5	Local digital I/Os	Connecting cable	KM8-M8-... or NEBU-M8-...
6	Motor connection	Motor cable	NEBM-T1G6-T1G6-...
		Encoder cable	NEBM-T1G12-T1G12-...

Tab. 3/2: Overview of cables and plugs (accessories)

For complying with the IP protection class: Tighten the union nuts/locking screws on the plugs by hand; seal unused M8 connections with type ISK-M8 protective caps (accessories).



Observe the tightening torques specified in the documentation for the cables and plugs used.



Festo plugs which comply with protection class IP20:
– screw terminal adapter type FBA-1-SL-5POL
– field bus plug FBS-SUB-9-WS-CO-K.

3.2 Power supply



Warning

- Use only **PELV circuits** as per IEC/DIN EN 60204-1 for the electric power supply (protective extra-low voltage, PELV).
Take into account also the general requirements for PELV circuits as per IEC/DIN EN 60204-1.
- Use only **power supply units** that guarantee reliable electrical isolation of the operating voltage as per IEC/DIN EN 60204-1.

Protection against electric shock (protection against direct and indirect contact) is guaranteed in accordance with IEC/DIN EN 60204-1 by using PELV circuits (electrical equipment of machines, general requirements).



Note



Note that the tolerances of the voltage supply must also be observed directly at the voltage supply connection of the SFC-LACI.

- For the power supply, use only the cables specified in Tab. 3/2.
- Use closed-loop regulated power supply units that comply with the requirements described in Tab. 3/4.




Load voltage supply: The use of power supply units with lower output levels is possible with restricted motion dynamics and loads. To do this, you need to enter the power output of your power supply unit into the FCT (or via the CI object 6510/50h).

3. Installation

Connection	Pin	Designation	Function	Cable colour ¹⁾
<div><div>Power</div></div>	A1	Load voltage	+48 VDC load	Black, 1
	A2	Load voltage	GND load	Black, 2
	1	Logic voltage	+24 VDC logic	White
	2	Logic voltage	GND logic	Brown
	3	Hardware enable	+24 VDC hardware enable	Green
	4	FE	FE ³⁾	– ²⁾
	5	Hardware enable	GND hardware enable	Yellow
	–	Plug housing	FE ³⁾	Earthing strap with cable lug M4
		Earth terminal (housing)	FE ³⁾	–
<div><div>¹⁾ Cable colours with supply cable type KPWR-MC-1-SUB-15HC-...</div><div>²⁾ With cable type KPWR-MC-1-SUB-15HC-... not connected.</div><div>³⁾ Use only one connection; see section 3.3</div></div>				

Tab. 3/3: “Power” connection (voltage supply) on the SFC-LACI



Caution

Damage to the device

The power supply inputs on the SFC-LACI have no special protection against overvoltage.

- Make sure the permissible voltage tolerance is never exceeded; see Tab. 3/4.

3. Installation

Requirements to be met by the power supply

Voltage	Application	Currents
48 VDC +5/-10 %	Load supply (pins A1, A2)	Nominal current (peak current): 10 A (20 A) Internal fuse: 16 A slow-blow (external as an option)
24 VDC ±10 %	Logic supply (pins 1, 2)	Nominal current: 0.4 A Peak current: 0.8 A (without local outputs) Internal fuse: 4 A slow-blow (external as an option)
	Local outputs OUT1/2	Supply via logic supply (pins 1, 2) Max. 1 A permissible per output
	Hardware enable (pins 3, 5)	Minimum switching current
	Total current consumption 24 V	Dependent on the system architecture, up to 3.8 A

Tab. 3/4: Requirements to be met by the power supply

Example of a power supply connection

- 1
- Connect the earth terminals of the two power supply units
- 2
- External fuses (as an option)
- 3
- Switch for hardware enable
- 4
- Earth terminals (only use one, see section 3.3)




Fig. 3/2: Power supply connection example

3. Installation

3.2.1 Function of the hardware enable

Application of 24 VDC to pin 3 (relative to pin 5) of the power supply connection is essential for operation of the SFC-LACI.

In a similar fashion to the relay, “Hardware Enable” switches the load voltage on and off, whereby the voltage of the hardware enable represents the control voltage:

- Hardware enable applied: the load voltage is switched through.
- Hardware enable missing: the load voltage is blocked.

Switching the voltage on or off of the “Hardware Enable” is thus equivalent to switching the load voltage on or off.



The Hardware Enable is electrically isolated.



Use of the Hardware enable is described in section 5.6.9.

3.3 Earthing



Note

- Connect **one** of the earth terminals of the SFC-LACI at low impedance (short cable with large cross-section) to the earth potential.

You can thereby avoid interference from electromagnetic sources and ensure electromagnetic compatibility in accordance with EMC directives.

To earth the SFC-LACI, use **one** of the following terminals (see Tab. 3/3):

- Earth terminal on the housing of the SFC-LACI, **or**
- Earthing strip with cable lug on the plug housing.



Note

Note that **only one** of the three earth terminals may be used (to avoid earth loops).





When using the earth terminal on the housing of the SFC-LACI:

- Use a suitable earthing cable with an M4 cable lug together with the accompanying nut and toothed washer.
- Tighten the nut with max. 1.7 Nm.

3. Installation

3.4 Motor connection

The linear motor is controlled via the motor connection and the signals from the displacement encoder are transmitted via the motor connection.

Pin	Colour	Function	Plug on the SFC-LACI
1	White	Motor: String U	 Black plug, A
2	Brown	Motor: String V	
3	Green	Motor: String W	
4	–	–	
1	Yellow	Motor: String U/	 Black plug, B
2	Grey	Motor: String V/	
3	Pink	Motor: String W/	
4	–	–	
1	Blue	VCC +5 V DC	 Yellow plug (sensors)
2	Red	GND	
3	White	Temperature sensor	
4	Brown	Temperature sensor GND	
5	orange	Reference switch +24 V DC	
6	Grey	Reference switch input	
1	Green	Data serial +	 Red plug (BiSS position measuring system)
2	Yellow	Data serial –	
3	Black	GND	
4	Brown	VCC +5V DC	
5	Red	Pulse –	
6	orange	Pulse +	

Tab. 3/5: Motor connection to the SFC-LACI

Displacement encoder for BiSS interface

The BiSS interface is a 2-wire interface for interference-immune sensor connection. In contrast to the SSI interface, the data transmission is bi-directional, which means, for example, that data can also be written into the sensor for parametrisation.

Data is transmitted via a pulse cable controlled by the master and a data cable controlled by the sensor as serial transmission. Data is written to the slave via the cycle's pulse width modulation in accordance with the "BiSS B mode" protocol specification http://www.biss-ic.de/files/BiSS_b3ds.pdf; the direction of the data cable is not switched. Pulse and data are transmitted using RS485 technology, which means a signal is sent not-inverted as well as inverted and issued at the receiver as differential input. This suppresses common-mode interference. The data are also secured by a CRC code.

The BiSS interface supports 2 read-out modes:

- The sensor data channel for fast pulse out (pulse up to 10 MHz) of the sensor information
- The parameter channel for reading and writing sensor parameters as well as for depositing user-specific data protected against zero voltage in the sensor's EEPROM

The distinction is made on the basis of the start bit, details can be referred to in the specifications given.

3. Installation




Fig. 3/3: Sensor data communication

Bits	Type	Label
[19:30]	DATA	Cycle counter 12 bit (multiturn position)
[8:18]	DATA	Angle data 11 bit (singleturn position)
[7]	Error	Error bit E1 (amplitude error)
[6]	Error	Error bit E0 (frequency error)
[0:5]	CRC	Polynomial 0x43; $x^6+x^1+x^0$ (inverted bit output)

Tab. 3/6: BiSS Interface


3.5 Parameterising interface

Serial interface for parameterising, commissioning and diagnosing.



Note
For connecting a PC to the SFC-LACI, use only the cable specified in Tab. 3/2.

- If necessary, remove the protective cap from the parameterising interface.
- Connect the following terminals with the programming cable:
 - the socket on the SFC-LACI
 - a serial interface COMx of the PC.

M8 socket		Description	
	1	GND	Ground
	2	RXD	RS232 ¹⁾ : Receiving cable of PC, transmitting cable of SFC-LACI
	3	TXD	RS232 ¹⁾ : Transmitting cable of PC, receiving cable of SFC-LACI
	4	–	(reserved, do not use)
¹⁾ The levels correspond to the RS232 standard.			

Tab. 3/7: Parameterising interface (RS232) of the SFC-LACI

3. Installation



Information on commissioning and parameterising the SFC-LACI via the parameterising interface can be found in section 5.3.2 and in the help system for the Festo Configuration Tool software package.
Information on transmitting CI commands via the parameterising interface can be found in appendix B.



Note

The parameterising interface (RS232) is not electrically isolated and is not real-time capable. It is not suitable for permanent connection to PC systems, or as a control interface.

- Use this terminal only for commissioning.
- Remove the programming cable in continuous operation.
- Seal the terminal with the protective cap supplied (type ISK-M8).


3.6 Controller interface

Communication with the higher-order controller (PLC/IPC) occurs via the controller interface.

There is a 9-pin Sub-D plug on the SFC-LACI for connecting the field bus. This connection is used for the incoming and continuing field bus cables.



Note
Only field bus plugs of type FBS-SUB-9-BU-2x5-POL-B and FBA-2-M12-5-POL from Festo ensure conformance to IP54.
Note the instructions in section 3.7.5 if other Sub-D plugs are used.

Connection	Pin	Designation	Function	Field bus plug ¹⁾
 I/F	1	n.c.	Not connected	–
	2	CAN_L	CAN Bus Low	A/L
	3 ²⁾	CAN_GND	CAN bus reference potential	GND
	4	n.c.	Not connected	–
	5	CAN_SHLD	Capacitive connection to housing	Clamping strap
	6 ²⁾	CAN_V–	Bus interface voltage supply reference potential	–
	7	CAN_H	CAN Bus High	B/H
	8	n.c.	Not connected	–
	9	CAN_V+	Power supply to the bus interface	V+
	–	Screening/ housing	Connection to functional earth	Clamping strap
¹⁾ Pin assignment in the field bus plug type FBS-SUB-9-BU-2x5POL-B ²⁾ Pin 3 and pin 6 are connected internally with each other in the SFC-LACI-DN.				

Tab. 3/8: “I/F” connection (control terminal) on the SFC-LACI-...-DN

3. Installation



Note

The screen connection at pin 5 of the field bus interface is capacitively connected internally to the housing. This prevents equalising currents from flowing via the screening of the field bus cable (see Fig. 3/4).

1 Capacitive connection

2 Housing




Fig. 3/4: Screen connection inside the SFC-LACI

3.7 Connecting the field bus

3.7.1 Field bus cable



Note

Faulty installations or high transmission rates may cause data transmission errors as a result of signal reflections and attenuations.

Transmission errors can be caused by:

- missing or incorrect terminating resistor
- incorrect screened connection
- branches
- transmission over long distances
- inappropriate cables.

Observe the cable specifications. For information on the cable type refer to the manual for your controller or to the DeviceNet specification.



Note

If the SFC-LACI is installed in a machine on a movable mounting, the field bus cable must be provided with strain relief on the moving part of the machine. Also observe the relevant regulations in EN 60204 part 1.



Use a twisted-pair screened 4-wire cable as the field bus cable.

If the field bus plug FBS-SUB-9-BU-2x5POL-B is used, a cable diameter of 5 ... 10 mm is permitted.

3. Installation

3.7.2 Field bus baud rate and field bus length

The maximum permissible fieldbus length and length of the branch lines depends on the baud rate used. You will find detailed information in the manuals for your control system or bus interface or DeviceNet specification.

**Note**

- Refer to the manuals for your control system or bus interface in order to ascertain which T-adapter and maximum branch line length are permitted for your controller.
- Also take into account the sum of the branch line lengths when calculating the maximum permitted length of the field bus cable.

3. Installation

3.7.3 Bus power supply

Bus supply

Avoid excessively long distances between the bus interface/logic supply and the SFC-LACI.



Caution

- When connecting the field bus interface and the power supply for the bus interface pay attention to the polarity.
- Connect the screen.
- Protect the power supply for the bus interface with an external fuse, in accordance with the number of bus slaves.



Note

Bus slaves have different tolerances in respect of the interface supply, depending on the manufacturer. Observe this when planning the bus length and placing the power supply unit.

For the SFC-LACI the following tolerance applies to the bus interface supply (pin 9 on the Sub-D plug):

$$V_{\max} = 30.0 \text{ V}$$

$$V_{\min} = 11.0 \text{ V}$$



Recommendation:

Place the power supply unit approximately at the centre of the bus.

3.7.4 Connection with field bus plugs / adapters from Festo



With Festo field bus plugs type FBS-SUB-9-BU-2x5POL-B or the field bus adapter FBA-2-M12-5POL you can connect the SFC-LACI to the field bus in a user-friendly manner. You can disconnect the plug from the SFC-LACI without breaking the bus connection (T-Tap function).




Fig. 3/5: Layout of the bus interface and example of connection

3. Installation

Field bus plug FBS-SUB-9-BU-2x5POL-B (IP54)

- Observe the fitting instructions for the field bus plug. Tighten the two fastening screws at first by hand and then with max. 0.4 Nm.



Note

The clamp strap in the field bus plug from Festo is connected internally capacitively with the metallic housing of the Sub-D plug. This is to prevent equalising currents flowing through the screening of the field bus cable.

- Clamp the screening of the field bus cable under the clamp strap in the field bus plug. The “SLD” terminal in the field bus plug is optional.

- 1 Folding cover with inspection window
- 2 Clamp strap for screen connection
- 3 Blanking plug if connection unused
- 4 Field bus continuing (OUT)
- 5 Field bus incoming (IN)
- 6 Capacitively connected




Fig. 3/6: Field bus plug type FBS-SUB-9-BU-2x5POL-B

3. Installation

M12 adapter FBA-2-M12-5POL (IP54)





The bus is connected via a 5-pin M12 socket with PG9 screw connector. Use the second connection socket for the continuation of the field bus.



Note

- Use protective caps or blanking plugs to seal unused connections.

M12 adapter	Pin no.
	<ul style="list-style-type: none">1. Screening2. 24 VDC bus3. 0 V DC bus4. CAN_H5. CAN_L
 <p>Protective cap or plug with bus termination resistor if connection is not used</p>	

Tab. 3/9: Pin assignment of field bus interface (adapter for 5-pin M12 connection)






With the two M12 connections you can implement a T-adaptor.



Screw terminal adapter (IP20)

With the adapter type FBA-1-SL-5POL the bus can be connected to a 2x5-pin terminal strip. Use the second row of connections for the continuing field bus.
The maximum permitted current at the terminals is 4 A.
Use cables with a cross sectional area of min. 0.34 mm².

Order this adapter together with the terminal strip type FBSD-KL-2x5POL. In this way you can implement a T-adapter function.

Screw terminal adapter	Pin no.
	1. 0 V DC bus 2. CAN_L 3. Screening 4. CAN_H 5. 24 VDC bus
 	2x5-pin terminal strip

Tab. 3/10: Pin assignment of field bus interface (5-pin screw terminal adapter)

3. Installation

3.7.5 Connection with other Sub-D plugs (IP20)

If you are using the Festo plug type FBS-SUB-9-WS-CO-K or Sub-D plugs from other manufacturers, you must replace the two flat screws by which the field bus plug is fitted in the SFC-LACI by bolts of type UNC 4-40/M3x5 (supplied).

**Note**

Note that when using Sub-D plugs from other manufacturers only IP20 protection is attained.

**Note**

If both screws or stud bolts are removed simultaneously, there is a risk that the plug may be pressed into the SFC-LACI housing with the internal circuit board.

- Always leave one of the screws or stud bolts fitted while changing over.

1. First slacken just one of the mounting screws and remove it.
2. Screw one of the mounting bolts into the vacant tapped hole and tighten it.
Maximum tightening torque: 0.48 Nm
3. Repeat steps 1 and 2 for the other screw.

3.8 Bus termination with terminating resistors



Note

If the SFC-LACI is at the start or end of the field bus segment, a bus terminator is required.

- **Always** use a bus termination at both ends of the field bus.

If you are using T-adapters, install the terminating resistor at the unused output of the T-adapter.

Recommendation: Fit a terminating resistor in the Festo field bus plug for the bus termination.



- 1 Protective cover
- 2 Resistor for bus termination (120 Ω , 0.25 W)




Fig. 3/7: Bus termination with resistor in field bus plug FBS-SUB-9-BU-2x5POL-B



Field bus plug FBS-SUB-9-WS-CO-K (IP20) has an integrated switchable terminating resistor.


Install a terminating resistor using the adapters

If the SFC-LACI you are connecting is at the end of the field bus, you must install a terminating resistor (120 Ω , 0.25 W) in the field bus socket:

- Connect the terminating resistor between the cores for CAN_H and CAN_L.

3. Installation

3.9 Local digital inputs and outputs



Connection	Pin	Function
Output 1 (Out1)	3	Ground (GND)
	4	Signal
	1	+24 VDC logic voltage output
Output 2 (Out2)	3	Ground (GND)
	4	Signal A
	1	Signal /A
Input 1 (In1)	3	Ground (GND)
	4	Proximity sensor contact
	1	+24 VDC voltage output for proximity sensor
Input 2 (In2)	3	Ground (GND)
	4	Proximity sensor contact
	1	+24 VDC voltage output for proximity sensor

3. Installation

3.9.1 Specifications of the outputs

The local digital outputs are supplied by the 24-V logic voltage (no electrical isolation). They are ESD-protected and short circuit proof, but do not have reverse polarity protection against infeed.



Caution

If 24 V DC voltage is applied and the output pins are used incorrectly, the device may be seriously damaged.

Therefore:

- Do not apply voltage to the outputs.
- Note the current limitation for the outputs (max. 1 A permissible per output).

Special features of output 1 (Out1)

- Standard PLC output (active high-side switching)

Special features of output 2 (Out2)

- Differential output (can be pulse-width modulated)
- High- und low-side switching (active full bridge)
- It is not used for controlling a PLC, but rather for controlling a load, e.g. to control a pulsed motor brake, a valve or a fan.



The possible uses dependent on the selected pins are described in section 5.6.10.

3. Installation

3.9.2 Specifications of the inputs

- based on DIN/EN 61131, Part 2 (IEC 1131-2), Type 1
- are supplied by the 24-V logic voltage (no electrical isolation).



Note

Damage to the device

The 24 V DC voltage at pin 1 does not have any special protection against overload.

- Use this connection only for proximity sensors (sensor supply).

Use of this connection as a power supply for other devices is not permitted.

- For connecting the proximity sensor, use a cable with rotating thread sleeve (union nut) on the end of the cable, e.g. an extension cable type KM8-M8-... or NEBU-M8-...
- When selecting the proximity sensor, note that the accuracy of the proximity sensor switching point may affect the accuracy of the reference point.
- During installation, note the position of the reference switch relative to the index pulse. If necessary, move the reference switch (see “INDEX PULSE WARNING”, section 6.3).

3. Installation

Control panel (only type SFC-LACI-...-H2)

Chapter 4

4. Control panel (only type SFC-LACI-...-H2)

Contents

4.1 Design and function of the control panel 4-4

4.2 The menu system 4-6

4.3 [Diagnostic] menu 4-8

4.4 [Positioning] menu 4-11

4.5 [Settings] menu 4-13

 4.5.1 [Settings][Axis type] 4-14

 4.5.2 [Settings][Axis parameter] 4-14

 4.5.3 [Settings][Homing parameter.] 4-15

 4.5.4 [Settings][Position set] 4-16

 4.5.5 [Settings][Jog mode] 4-17

 4.5.6 [Settings][BUS parameter] 4-17

 4.5.7 [Settings][Password edit] 4-18

4.6 Menu command “HMI control” 4-20

4. Control panel (only type SFC-LACI-...-H2)

The control panel of the SFC-LACI-...-H2 provides many functions for commissioning, parameterisation and diagnostics. An overview of the key and menu functions can be found in this chapter.



Commissioning with the control panel is described starting from section 5.2.



With the SFC-LACI-...-H0 (without control panel), you can commission the device via the parameterising interface using the Festo Configuration Tool (FCT). Instructions on this can be found in section 5.3.2.



Caution

Simultaneous or alternating attempts to access the SFC-LACI via FCT, control panel and controller interface can cause unpredictable errors.

- Make sure that the FCT, the control panel and the controller interface of the SFC-LACI are not used at the same time.
- If necessary, use the possibility of blocking parameterising and positioning functions via the control panel (HMI access, see section 5.5.2)

4. Control panel (only type SFC-LACI-...-H2)

4.1 Design and function of the control panel

The control panel allows:

- Parameterising and referencing the drive
(Homing run methods: to the stop and to the integrated reference switch of the drive)
- Teaching and editing the positioning records
- Execution/testing of positioning records.

- 1 LC display
- 2 Operating buttons
- 3 LEDs
 - Power (green)
 - I/F (green/red)
 - Error (red)




Fig. 4/1: Control panel of the SFC-LACI-...-H2

LC display

The graphic LCD shows all text in English. The display can be rotated 180°; see [LCD adjustment] menu command.

LEDs





Display of operating states (see section 6.2):

- Power: Power supply
- I/F: Communication via the controller interface
- Error: Error message or warning

4. Control panel (only type SFC-LACI-...-H2)

Operator keys

Basic functions of the operator keys:

Key	Function	
	MENU	Activates the main menu from the status display
	ESC	Discards the current entry and switches back in stages to the higher-order menu level or status display
	EMERG.STOP	If [HMI = on]: interrupts the current positioning procedure (-----> Error mode; confirm with <Enter>, then automatic return to the status display)
	OK	Confirms the current selection or entry
	SAVE	Saves parameter settings permanently in the EEPROM
	START/STOP	Starts or stops a positioning procedure (only in Demo mode). After stop: Display of current position; use <Menu> to return to the higher-order menu level.
	← →	Scrolls within a menu level in order to select a menu command
	EDIT	Sets parameters

Tab. 4/1: Key functions (overview)

4. Control panel (only type SFC-LACI-...-H2)

4.2 The menu system

Status display and main menu

When the logic voltage is switched on, the SFC-LACI carries out an internal check.

```
DeviceNet INIT
PARAMETER ERROR

Diagnostic <menu>
Config <Enter>
```

During the first commissioning or when the EEPROM is deleted, the error message “DeviceNet INIT PARAMETER ERROR” will appear, as the field bus parameters are not parameterised (see section 5.2.1).

When the device is switched on again (i.e. when the field bus parameters have already been completely parameterised once), the display will show briefly the Festo logo then change to the status display.

```
SFC-LACI...
D...
Xa = 0.00 mm

HMI:off
<Menu>
```

The **status display** shows the following information:

- The type designation of the SFC-LACI
- The type of connected drive
- The position of the drive $x_a = \dots$
(still without significance when unit is switched on)
- The current setting of the device control
(HMI = Human Machine Interface)

```
→ Diagnostic
   Positioning
   Settings
   ↓
←→ ESC <Menu>
   OK <Enter>

→ HMI control
   LCD adjustment
   ↑
←→ ESC <Menu>
   OK <Enter>
```

The **main menu** is accessed from the status display using the <Menu> key. The currently active key function is displayed in the lower lines of the LCD display.

4. Control panel (only type SFC-LACI-...-H2)


Menu command		Description
→ Diagnostic	Displays the system data and the settings currently in effect (→ section 4.3)	
→ Pos. set table	Displays the position set table	
→ Axis parameter	Displays axis parameters and data	
→ System paramet.	Displays system parameters and data	
→ DeviceNet Diag	Displays field bus parameters of the SFC-LACI	
→ SW information	Displays the operating system version (firmware)	
→ Positioning	Homing and positioning runs (→ section 4.4)	
→ Homing	Start the homing run	
→ Move posit. set	Start an individual positioning record	
→ Demo posit. tab	Starts the "Demo mode"	
→ Settings	Parameterisation (→ section 4.5)	
→ Axis type	→ Not adjustable	The type of the drive is automatically detected
→ Axis parameter	→ Zero point	Offset of the axis zero point relative to the reference point
	→ SW-limit-neg	Software end position, negative; offset relative to the axis zero point
	→ SW-limit-pos	Software end position, positive; offset relative to the axis zero point
	→ Tool load	Tool load mass (e.g. gripper on front plate/piston rod)
	→ SAVE...	Saves parameters to the EEPROM
→ Homing paramet.	→ Homing method	Homing method
	→ Velocity v _{rp}	Speed when searching for the reference point
	→ Velocity v _{zp}	Speed when moving to the axis zero point
	→ SAVE...	Saves parameters to the EEPROM
→ Position set	→ Position nr	Number of positioning set (1 ... 31)
	→ Pos. set mode	Absolute or relative positioning; if necessary, energy optimised
	→ Position	Target position
	→ Velocity	Velocity
	→ Acceleration	Acceleration
	→ Deceleration	Deceleration (Braking)
	→ Jerk Acc.	Acceleration jerk
	→ Jerk Dec.	Deceleration jerk
	→ Work load	Applied load (= workpiece mass)
	→ Time MC	Damping time
	→ SAVE...	Saves parameters to the EEPROM
→ Jog mode	Move the drive using the arrow buttons	
→ BUS parameter	Setting field bus parameters of the SFC-LACI	
→ Password edit	Set up a local password for the control panel (→ section 4.5)	
→ HMI control	Preset the device control via the control panel (→ section 4.6)	
→ LCD adjustment	Rotate the display 180°	

Tab. 4/2: Menu commands (overview)

4. Control panel (only type SFC-LACI-...-H2)

4.3 [Diagnostic] menu

In order to display the system data and the currently effective settings:



- 1. Select the [Diagnostic] menu in the main menu <Enter>.
- 2. Select a menu command <Enter>.

← → You can scroll through the data with the arrow keys.

ESC You can use the <Menu> key to return to the higher-order menu.

[Diagnostic] [...]	Description	
[Pos. set table]	Nr	Number of the positioning record
	a/r (e)	Absolute (a) or relative (r) positioning, (e) = energy optimised
	Pos	Target position
	Vel	Velocity
	acc *)	Acceleration
	dec *)	Deceleration (Braking)
	Work load *)	Applied load (= workpiece mass)
	ja *)	Acceleration jerk
	jd *)	Deceleration jerk
	t_MC *)	Damping time
	*) After 5 s, the lower part of the display changes.	

4. Control panel (only type SFC-LACI-...-H2)

[Diagnostic] [...]	Description	
[Axis parameter]	v max	Maximum speed
	x neg	Stroke limitation: Software end position, negative
	x pos	Stroke limitation: Software end position, positive
	x zp	Offset axis zero point
	Tool load	Tool mass (e.g.a gripper on the front plate/piston rod)
[System paramet.]	Load Power	Load voltage ok?
	VDig	Digital voltage (= Logic voltage) [V]
	I max	Max. phase current [A]
	P_Pos	Average power during last positioning procedure [W]
	t_Pos	Time taken for the last positioning procedure [s]
	Cycle	Number of positioning movements
	Mode	Unit of measurement [mm]
	Hom.meth.	The parameterised homing method: – RefS.n: Reference switch in negative direction – RefS.p: Reference switch in positive direction – Bl.pos: Fixed stop in positive direction – Bl.neg: Fixed stop in negative direction – LimS.p: Limit switch in positive direction – LimS.n: Limit switch in negative direction
	Ref. switch	Activated (switching) position of the parameterised reference switch
	Neg. Lim-Sw	Activated (switching) position of the negative limit switch
	Pos. Lim-Sw	Activated (switching) position of the positive limit switch
	T_Motor	Temperature of the linear motor [°C]
	T_LACI	Temperature of the SFC-LACI [°C]

4. Control panel (only type SFC-LACI-...-H2)

[Diagnostic][...]	Description	
[DeviceNet Diag]	Bus diagnosis	
	– No Power / BUS Off	No bus supply connected or the field bus was not correctly parameterised. No connection to the master is possible.
	– Device Operational	DeviceNet in the status “Data exchange” and connected to a master
	– Device in Standby	No connection with the DeviceNet master, device is ready for operation
	– Minor Fault	Recoverable fault has occurred (e.g. timeout)
	– Unrecoverable Fault	Serious fault detected (e.g. duplicated MAC ID); a reset is needed to make the device ready for operation again.
	Baudrate	Preset baud rate of the SFC-LACI
[SW information]	MAC ID	Address of the SFC-LACI
	I/O Datalength	Set I/O data length. – 8 bytes: only FHPP standard (the SFC-LACI is controlled as per the Festo Handling and Positioning Profile). – 16 bytes: FHPP standard and FPC (additional use of the FPC for parameterising the SFC-LACI)

Tab. 4/3: [Diagnostic] menu

4.4 [Positioning] menu

Starting a homing run or a positioning run



Warning

Electric axes move with high force and at high speed. Collisions may cause injury.

- Make sure that nobody can place his/her hand in the positioning range of the moveable mass and that there are no objects in its path.



Note


- Before starting the reference run, make sure that:
 - The positioning system is set up and wired completely, and is supplied with power.
 - The parameterising is completed.
- Only start a positioning run after:
 - The reference system has been defined by a reference run.
 - You have checked that the software end positions are far enough away from the mechanical end positions / fixed stops (at least 1 mm).



Note

Note that positioning records with speed $v = 0$ or invalid target positions (-> error "TARGET POSITION OUT OF LIMIT") cannot be executed.

4. Control panel (only type SFC-LACI-...-H2)



The “Positioning” menu includes entries for starting a homing run or a positioning run.





Note
Carry out the homing run and the positioning runs as described in the following sections:

- Homing: sections 5.2.2 to 5.2.4
- Positioning runs / test runs: section 5.2.9

[Positioning]	Description	Note
[Homing]	Starting a homing run with the set homing method	Setting the parameters: see [Settings] [Homing paramet.]
[Move posit. set]	Starting a defined positioning record from the position set table – or – for parameterised record chaining: start of a record chain	Parameterising and referencing must have been completed
[Demo posit. tab]	Test of all positioning records in the position set table (operating mode “Demo mode”)	Parameterising and referencing must have been completed. There must be at least two positioning records in the memory.

Tab. 4/4: [Positioning] menu


Cancelling a positioning movement

EMERG. STOP	You use «Menu» to interrupt a positioning task (→ Error mode EMERG.STOP)	
DEMO STOP	With «Enter», you can interrupt the “Demo mode” [Demo posit. tab]. The current positioning record will be executed before the axis stops. If you restart, the run will begin with positioning record 1.	

4. Control panel (only type SFC-LACI-...-H2)

4.5 [Settings] menu

For parameterising the axis system and the positioning records:



- 1. Select the entry [Settings] in the main menu <Enter>.
- 2. Select a menu command <Enter>.

[Settings]	Description	Section
[Axis type]	The axis controlled by the SFC-LACI	4.5.1
[Axis parameter]	Teach mode for setting the axis parameters	4.5.2
[Homing paramet.]	Setting the homing travel method and the speed during homing travel	4.5.3
[Position set]	Teach mode for programming the position record table	4.5.4
[Jog mode]	Jog mode: Continuous manual travel	4.5.5
[BUS parameter]	Setting the field bus parameters	4.5.6
[Password edit]	Setting up a password for the control panel	4.5.7

Tab. 4/5: [Settings] menu



Note
The set parameters take effect immediately after confirmation with OK <Enter>.

- Use **[SAVE...]** to permanently save the settings in EEPROM. Only then will the settings be retained even after switching off the power supply or in the event of a power failure.

4. Control panel (only type SFC-LACI-...-H2)

4.5.1 [Settings][Axis type]

The connected drive is automatically detected.

4.5.2 [Settings][Axis parameter]

Teach mode for setting the axis parameters

- Observe the instructions in sections 5.2.5 and 5.2.6.

[Axis parameter]	Description
[Zero point] *)	Offset axis zero point
[SW-limit-neg] *)	Software end position, negative
[SW-limit-pos] *)	Software end position, positive
[Tool load]	Tool mass, e.g. a gripper on the front plate/ piston rod
[SAVE...]	Save parameters in EEPROM
*) Teaching is only possible after a successful homing run.	



Note
A new homing run must always be carried out after modifying the axis zero point.



The project zero point PZ can only be set via FCT or PNU 500/CI 21F4h.

4. Control panel (only type SFC-LACI-...-H2)

4.5.3 [Settings] [Homing paramet.]

Setting the homing method and the speed during reference travel.

- Observe the instructions in section 5.2.2.

[Homing paramet.]	Parameter	Description
[Homing method]	switch negative	Homing to the integrated reference switch at the retracted end position with index search
	block negative	Homing to a negative fixed stop
	block positive	Homing to positive fixed stop
	Note: Further homing run methods can only be configured via FCT.	
[Velocity v_rp]	v_rp	Speed for searching for the reference point
[Velocity v_zp]	v_zp	Speed for moving to the axis zero point
[SAVE...]	Save parameters in EEPROM	



Note
A new homing run must always be carried out after modifying the homing run method.



The maximum speed for homing is subject to built-in limits.

4. Control panel (only type SFC-LACI-...-H2)

4.5.4 [Settings][Position set]

Parameterising the position set table

- Observe the instructions in section 5.2.8.
- Select first the number of the desired positioning record. The following settings refer to the currently selected positioning record.

[Position set]	Param.	Description
[Position nr]	Nr	Number of the position record [1 ... 31]
[Pos set mode]	[absolute/ relative]	Positioning mode absolute = position specification refers to the project zero point relative = position specification refers to the current position e = energy-optimized path generator
[Position] *)	xt	Target position in [mm]
[Velocity]	v	Positioning speed in [mm/s]
[Acceleration]	a	Acceleration in [mm/s ²]
[Deceleration]	d	Deceleration in [mm/s ²]
[Jerk Acc]	ja	Acceleration jerk in [m/s ³]
[Jerk Dec]	jd	Deceleration jerk in [m/s ³]
[Work load]	m	Applied load (= workpiece mass) in [g]
Time MC	t_MC	Damping time (time between reaching the target window and setting “Motion Complete”)
[SAVE...]	Saves parameters to the EEPROM	
*) Teaching is only possible after a successful homing run.		

4. Control panel (only type SFC-LACI-...-H2)

4.5.5 [Settings] [Jog mode]

You can use the arrow keys to move the drive continuously (also possible without previous reference run). The software end positions have no effect here.

4.5.6 [Settings] [BUS parameter]

Setting the field bus parameters

[BUS parameter]	Param.	Description
[MAC ID]	0 ... 63 (0 ... 3Fh)	Field bus address of the SFC-LACI Representation: "00 dec, 00 hex"... "63 dec, 3F hex"
[Baudrate]	125 kBd 250 kBd 500 kBd	Field bus baud rate as per settings on master
[I/O Datalength]	8 / 16 bytes	Set I/O data length – 8 bytes: only FHPP standard (the SFC-LACI is controlled as per the Festo Handling and Positioning Profile) – 16 bytes: FHPP standard and FPC (additional use of the FPC for parameterising the SFC-LACI)

Tab. 4/6: Menu [Settings] [BUS parameter]

The settings in this menu will be saved directly in EEPROM where they are safe from power failures after confirmation with OK <Enter>.



Note

The set field bus parameters first become effective after "Power off/on" or after a software reset (object 20F1/03h).

4. Control panel (only type SFC-LACI-...-H2)

4.5.7 [Settings][Password edit]

Access via the control panel can be protected by a (local) password in order to prevent unauthorized or unintentional overwriting or modification of parameters in the device. No password has been preset at the factory (presetting = 000).

- Keep the password for the SFC-LACI in a suitable place, e.g. in the internal documentation for your system.



If the active password in the SFC-LACI is lost:
The password can be deleted by entering a master password.
To do this, contact your Festo service partner.

Setting up a password

Select [Password edit] in the menu [Settings]:

```
New Password:
[ ? x x ] = 0
EDIT <—>      ESC <Menu>
                SAVE <Enter>
```

Enter a password with 3 digits. The current input position is marked with a question mark.

1. Use the arrow keys to select a digit 0 ... 9.
2. Confirm your input with <Enter>. The next entry position will be displayed.
3. After entering the third digit, save your setting with SAVE <Enter>.

4. Control panel (only type SFC-LACI-...-H2)

Enter password

```
Enter Password:
[ ? x x ] = 0

EDIT <—>      ESC <Menu>
                OK <Enter>
```

As soon as a password is active, it will be scanned automatically when the menu commands [Positioning], [Settings] or [HMI control] are accessed.

1. Use the arrow keys to select a digit 0 ... 9.
2. Confirm your entry with OK <Enter>. The next entry position will be displayed.
3. Repeat the entry for the remaining entry positions.

When the correct password is entered, all parameterising and control functions of the control panel are enabled until the power supply is switched off.

Changing/deactivating the password

If the password has not yet been entered since the unit was switched on:

```
Enter Password:
[ ? x x ] = 0

EDIT <—>      ESC <Menu>
                OK <Enter>
```

- Select the menu item [Settings][Password edit] and enter the existing 3 digit password:

1. Use the arrow keys to select a digit 0 ... 9.
2. Confirm your entry with OK <Enter>. The next entry position will be displayed.
3. Repeat the entry for the remaining entry positions.

If the password has already been entered since the unit was switched on:

```
New Password:
[ ? x x ] = 0

EDIT <—>      ESC <Menu>
                SAVE <Enter>
```

4. Enter the new password with 3 digits. If you wish to deactivate the password, enter "000".
5. After entering the last digit, save your setting with **SAVE** <Enter>.

4.6 Menu command “HMI control”

To select the menu commands [Positioning] and [Settings], the “HMI: on” setting is required. Only then is the SFC-LACI ready to process user entries on the control panel.



Caution
When control via the control panel or FCT is activated (HMI: on), the drive **cannot** be stopped with the STOP bit of the control interface.

When selecting the menu commands, you will be prompted to modify the HMI setting as necessary. You can also modify the setting directly with the menu command [HMI control].

HMI ¹⁾	Device control
on	<ul style="list-style-type: none">– The parameterising interface is activated. Operation and parameterisation can be performed manually via the control panel or via FCT.– The control interface is deactivated. The actual status of all the inputs then has no effect. The state of the outputs is unimportant.
off	Device control is done via the control interface.
¹⁾ Human Machine Interface	



Access to the SFC-LACI via the control panel and FCT can be locked out via the field bus (“HMIAccess locked”), see section 5.5.5 (CCON.B5 LOCK).

Commissioning

Chapter 5

Contents

5.1	Preparations for commissioning	5-4
5.1.1	Checking the drive	5-5
5.1.2	Checking the power supply	5-5
5.1.3	Before switching on	5-6
5.1.4	Simultaneous attempts to access the controller	5-7
5.2	Commissioning with the control panel (only SFC-LACI-...-H2)	5-8
5.2.1	Set the field bus parameter	5-9
5.2.2	Setting the homing run parameters	5-11
5.2.3	Activate device control	5-13
5.2.4	Carrying out homing	5-14
5.2.5	Teach the axis zero point	5-16
5.2.6	Teach software end positions	5-18
5.2.7	Setting the tool mass	5-19
5.2.8	Teaching positioning records	5-20
5.2.9	Test run	5-22
5.3	Commissioning with FCT	5-23
5.3.1	Installing the FCT	5-24
5.3.2	Procedure	5-25
5.4	Commissioning on a DeviceNet master	5-27
5.4.1	Overview of commissioning on the field bus	5-27
5.4.2	Configuration of the DeviceNet master ("I/O configuration")	5-28
5.5	Festo Handling and Positioning Profile (FHPP)	5-30
5.5.1	FHPP operating modes	5-30
5.5.2	Structure of the cyclic I/O data (FHPP standard)	5-32
5.5.3	Description of the I/O data (Record select)	5-34
5.5.4	Description of the I/O data (Direct mode)	5-35
5.5.5	Description of the control bytes CCON, CPOS, CDIR	5-36
5.5.6	Description of the status bytes SCON, SPOS, SDIR (RSB)	5-39
5.5.7	Examples of control and status bytes (FHPP standard)	5-42

5. Commissioning

5.6	Drive functions	5-56
5.6.1	Homing	5-56
5.6.2	Jog mode	5-58
5.6.3	Teaching via field bus	5-60
5.6.4	Record selection: Carrying out a record	5-62
5.6.5	Record selection: Switching to next record	5-67
5.6.6	Direct mode: Specification of a position or force	5-68
5.6.7	Direct mode: Continuous setpoint specification (Continuous Mode)	5-72
5.6.8	Standstill monitoring	5-74
5.6.9	Using hardware enable	5-76
5.6.10	Using the local digital outputs	5-77
5.6.11	Using a brake/clamping unit	5-84
5.6.12	Position sampling (on-the-fly measurement)	5-87
5.7	Notes on operation	5-89

5.1 Preparations for commissioning



Warning

Danger of injury

Electric axes can move suddenly with high force and at high speed. Collisions can lead to serious injury to human beings and damage to components.

- Make sure that nobody can reach into the operating range of the axes or other connected actuators (e.g. with a protective grille) and that no objects lie in the positioning range while the system is still connected to a power supply.

For commissioning, the mechanical system must be configured and a measuring reference system must be defined (see Tab. 1/1). By means of the measuring reference system, all positions are defined and movement can be made to them, e.g. with a positioning record from the position set table.

- Carry out parameterising and commissioning by means of the control panel or FCT, as described in the following chapters and in the FCT/PlugIn help.
- Check the default settings in the [Diagnostic] menu.
- Upon completion of commissioning, note the instructions for operation in the FCT/PlugIn help and in section 5.7.

5. Commissioning

5.1.1 Checking the drive



Note

During operation, the drive must not strike a stop without shock absorption.

- Use shock absorbers or buffers on all stops (exception: homing to a fixed stop).
- Before commissioning, make sure that drive and controller are completely set up and wired and that the working space is adequate for operation with an effective load.
- Observe the notes in the operating instructions for the axis used.

5.1.2 Checking the power supply



Caution

Interruption of running tasks due to inadequate load voltage supply ("LOAD POWER DOWN")

- Make sure that the load voltage supply tolerance can be maintained at full load directly on the voltage terminal of the SFC-LACI (see section 3.2).



Caution

Loss of reference position due to inadequate logic supply voltage

- Always carry out a homing run every time the logic voltage supply is switched on, in order to anchor the measuring reference system to the reference point (REF).

The SFC-LACI does not carry out any positioning tasks if it is not referenced.

5. Commissioning

5.1.3 Before switching on

When the SFC-LACI is switched on, the controller interface is activated as standard [HMI = off].



Caution

Unexpected movements of the drive due to incorrect parameterising

- Make sure that there is no active ENABLE signal when switching on the SFC-LACI on the controller interface.
- Parameterise the entire system completely before activating the controller with ENABLE or [HMI = on].

5.1.4 Simultaneous attempts to access the controller



Caution

Simultaneous or alternating attempts to access the SFC-LACI via FCT, control panel and controller interface can cause unpredictable errors.

- Make sure that the FCT, the control panel and the controller interface of the SFC-LACI are not used at the same time.



Note

In the following cases, it is **not** permitted to use the **FCT** to access the SFC-LACI for purposes of writing data (e.g. downloading parameters) or for control (e.g. “Move manually” or starting a homing run):

- While the SFC-LACI is executing a positioning motion or when a motion is started during access (e.g. via the control interface or via the control panel).
- If parameterisation or operation is carried out on the SFC-LACI with the control panel.

Note:

- Control by the FCT must not be activated while the drive is in motion or when control is being carried out via the field bus.

5.2 Commissioning with the control panel (only SFC-LACI-...-H2)



Information on the button functions and the menu structure of the control panel can be found in chapter 4.

Overview of initial commissioning

Commissioning steps	Section
1. Before switching on: make sure that there is no active ENABLE signal on the controller interface	5.1.3
2. Switch on the SFC-LACI, configure the field bus interface, then Reset	5.2.1
3. Set the parameters for the homing run: <ul style="list-style-type: none">– Homing method– Search speed to reference point– Positioning speed to axis zero point	5.2.2
4. Activate control panel device control [HMI = on]	5.2.3
5. Carry out homing run	5.2.4
6. Teach the axis zero point	5.2.5
7. Teach software end positions	5.2.6
8. Set the tool mass	5.2.7
9. Enter positioning records	5.2.8
10. Carry out a test run. Check motion behaviour, reference points and working range. Optimise as required.	5.2.9
11. Check the function of the controller interface and note the instructions on operation	5.4 ... 5.7

Tab. 5/1: Commissioning steps

5. Commissioning

5.2.1 Set the field bus parameter

```
DeviceNet INIT
PARAMETER ERROR

Diagnostic <menu>
Config <Enter>
```

- Switch the SFC-LACI on. During first commissioning or when the EEPROM has been deleted, the error message “DeviceNet INIT PARAMETER ERROR” will appear.

In order to set the field bus parameters during first commissioning or after deletion of the EEPROM:

- Select Config <Enter>.

```
SFC-LACI...
D...
Xa = 0.00 mm

HMI:off
<Menu>
```

For modifying the field bus parameters when re-commissioning (i.e. when these parameters have already been completely parameterised once):

- Select [Settings][BUS parameter][...] (see also section 4.5).

```
DeviceNet
MAC ID
Baudrate
I/O Datalength
ESC <Menu>
<-> OK <Enter>
```

1. Select the desired field bus parameter with the arrow keys (details see next page).
2. Press <Enter> to display the current setting.
3. If necessary, modify the setting with the arrow keys.
4. Accept the setting with OK <Enter>. The setting is saved against network failure.



Note

The set field bus parameters first become effective after “Power off/on” or after a software reset (object 20F1/03h / PNU 127).

5. Commissioning

```
→ Settings
  BUS parameter
    └─ MAC ID
```

Station number (MAC ID)

- Permitted station numbers: 0 ... 63
- An invalid station number is preset (shown on control panel as “???”). This is to make sure that a correct address is set during commissioning or exchange.

```
DeviceNet MAC ID

06 dec, 06 hex
          ESC <Menu>
<—>      OK <Enter>
```

```
→ Settings
  BUS parameter
    └─ Baudrate
```

Baudrate (baud rate)

- Possible baud rates: 125, 250, 500 kBd
- An invalid baud rate is preset (shown on control panel as “???”). This is to make sure that a correct baud is set during commissioning or exchange.

```
BUS Baudrate

125 kBd
          ESC <Menu>
<—>      OK <Enter>
```

```
→ Settings
  BUS parameter
    └─ I/O Datalength
```

I/O Datalength (data length)

- The following settings are possible:
 - 8 bytes:
FHPP standard (control of the SFC-LACI takes place according to Festo Handling and Positioning Profile)
 - 16 bytes:
FHPP standard and FHPP-FPC (additional use of the FPC for parameterising the SFC-LACI). It is transmitted in 3 telegrams.
- An invalid data length is preset (displayed as “???” on the control panel). This is to make sure that the correct data length is set during commissioning or exchange.

```
I/O Datalength

08 byte
          ESC <Menu>
<—>      OK <Enter>
```

5.2.2 Setting the homing run parameters

The reference point is determined as follows, depending on the homing method:

- by means of the drive's integrated reference switch with a subsequent index search (recommended) or
- by means of a fixed stop (to be fitted externally by the customer).



For homing to the switch, only the drive's integrated reference switch can be selected on the control panel. Use the FCT for parameterising if you require further options.



The homing run process is described in section 1.1.6.

You can set two different speeds for searching for the reference point and for the subsequent run to the axis zero point. The maximum speed is subject to built-in limits.

When homing to a fixed stop

1. Measure the distance between your reference point and the retracted end position ($\text{Offset}_{\text{Ref}} \rightarrow \text{Tab. 1/3}$).
2. Enter the value ($\pm 1 \text{ mm}$) in FCT or via the object 6410/16h / PNU 1055.



Note

Controller inaccuracies

If you do not enter the offset of the reference point, control inaccuracies (e.g. overshooting) can occur with small (100 mm) and large nominal strokes (400 mm).

When homing to the drive's integrated reference switch, the reference point position is known (6 mm) and must not be entered. This reference switch must not be moved.



Caution

Damage to components when the permissible impact pulse is exceeded.

- Operate the drive only with the permitted load (see operating instructions for the drive).
- If necessary, limit the maximum current (motor force) during the homing run using:
 - FCT – or
 - object 6073h / PNU 1034 “Max. Current”.

5. Commissioning

Setting parameters

```
→ Settings
  Homing paramet.
  └─ Homing method
  └─ Velocity v_rp
  └─ Velocity v_zp
    SAVE...
```

1. Set the following:
 - [Homing method]
 - Search speed for ascertaining the reference point [Velocity v_rp]
 - Speed of travel to axis zero point [Velocity v_zp].
2. Accept each setting with OK <Enter>. The setting will then take effect in the drive.
3. Save the parameter settings in EEPROM with the **[SAVE]** menu command. Only then will the settings be retained if the power supply is switched off or if there is a power failure.

5.2.3 Activate device control

```
Diagnostic
Positioning
Settings
→ HMI control
LCD adjustment
```



- Enable the control panel so that it can control the SFC-LACI [HMI = on]. This deactivates at the same time the controller interface of the SFC-LACI.

Caution

When control via the control panel or FCT is activated (HMI:on), the drive **cannot** be stopped with the STOP bit of the control interface.

```
PLEASE WAIT!
COMMUT.-POINT
EVALUATION IS
ACTIVE
```

Commutation point search:

When the controller is enabled for the first time with the ENABLE signal or [HMI = on], the drive will spend a few seconds determining its commutation point (vibrations).

5.2.4 Carrying out homing

Overview



Warning

Danger of injury!

Electric axes move with high force and at high speed. Collisions can lead to serious injury to human beings and damage to components.

- Make sure that nobody can reach into the sphere of influence of the axes or other connected actuators and that no items are within the positioning range while the system is connected to energy sources.



Caution

When the homing method is changed, the axis zero point offset is reset to the factory settings (see section 5.2.5). Existing parameterised software end positions and target positions already set in the position set table are shifted together with the axis zero point.

- Always carry out a homing run after changing the referencing method.
- Teach the offset of the axis zero point again if needed.

If the axis zero point is modified:

- Teach the software end positions and the target positions again if needed.



The homing run process is described in section 1.1.6.

5. Commissioning

```
→ Positioning
   └─ Homing
   └─ Move posit. set
   └─ Demo posit. tab
```



Start homing

1. Select [Positioning][Homing].
2. Start the homing run with START <Enter>.

If necessary, the homing run can be interrupted with the **<Menu> button (STOP)**.

If a reference signal is not found when homing to the drive's integrated reference switch before the drive has reached a fixed stop or a limit switch, then the drive will reverse and searches for the switch in the opposite direction (see section 1.1.6). If a reference signal is still not found, the SFC-LACI stops and reports an error (HOMING ERROR). The homing run must be repeated after the error message has been acknowledged:

1. Acknowledge the error message with <Enter>.
2. If necessary, check the functioning of the reference switch.
3. Check the settings of the parameters.
4. If required, use the arrow keys to move the drive into a different position (Menu [Settings][Jog mode]).
5. Repeat the homing run.

5. Commissioning

5.2.5 Teach the axis zero point

Factory setting

Axis zero point with:

- Homing to reference switch: 0 mm
- Homing to negative fixed stop: +1 mm
- Homing to a positive fixed stop: –1 mm



Note

Risk of overloading when homing to stop:
The drive must not press continuously against a mechanical stop (excessive warming).

- Make sure that the axis zero point is at least 1 mm away from the mechanical stop.

This causes the drive to leave the mechanical stop after recognising the reference point.



If necessary, teach the **axis zero point**:

Warning

The drive will move during teaching.

- Make sure that nobody can reach into the positioning range of the moveable load and that there are no objects in its path.

```
→ Settings
  Axis parameter
    — Zero point
    — SW-limit-neg
    — SW-limit-pos
    — SAVE
```

1. Select [Settings][Axis parameter][Zero point].
2. Move the drive manually to the desired axis zero point using the arrow keys.
3. Accept the position reached with OK <Enter>.
4. Save the parameter settings in EEPROM with the **[SAVE]** menu command.
5. Perform another homing run (see section 5.2.4).
When homing is concluded, the drive stands at the new axis zero point.

5. Commissioning



Note

If the axis zero point is modified:

Existing software end positions and the target positions in the position set table will be shifted together with the axis zero point.

- Teach the software end positions and the target positions again if needed.



The project zero point PZ can only be set via FCT or PNU 500 / Objekt 21F4h.

5.2.6 Teach software end positions

Factory settings

by homing method:

Homing method	Factory settings [mm]
Reference switch (AZ: 0 mm)	SW-limit-neg = 0 SW-limit-pos = (nominal stroke - 10)
Negative stop (AZ: +1 mm)	SW-limit-neg = 0 SW-limit-pos = nominal stroke
Positive stop (AZ: -1 mm)	SW-limit-neg = - (negative) nominal stroke SW-limit-pos = 0

If necessary, teach the **software end positions**:

1. Select [Settings][Axis parameter][SW-limit-neg] or [SW-limit-pos].
2. Move the drive with the arrow keys.



Note

During operation, the drive must not strike a stop without shock absorption.

- Parameterise the software end positions at least 1 mm from the nearest end stop.

3. Accept the position reached with OK <Enter>. The setting will then take effect.
4. Save the parameter settings in EEPROM with **[SAVE]**. Only then will the settings be retained even after switching off the power supply or in the event of a power failure.

5.2.7 Setting the tool mass

The weight of tools (e.g. grippers) on the front plate (or piston rod) of the drive has to be entered here.

1. Select [Settings][Axis parameter][Tool load].
2. Set the tool mass with the arrow keys.
3. Accept the setting with OK <Enter>. The setting will then take effect in the drive.
4. Save the parameter settings in EEPROM with the **[SAVE]** menu command.



The applied load (= mass of the individual workpieces), on the other hand, is entered in the positioning records ([Settings][Position set][Work load]).

5. Commissioning

5.2.8 Teaching positioning records

Requirements:

- The drive must be set up completely, wired and supplied with power.
- The SFC-LACI has been correctly parameterised.
- The homing run has been carried out successfully.
- The axis zero point and the software end positions have been set correctly.

Enter the positioning records as follows:

```
→ Settings
  Position set
    — Position nr
    — Pos set mode
    — Position
    — Velocity
    — Acceleration
    — Deceleration
    — Jerk Acc.
    — Jerk Dec.
    — Work load
    — Time MC
    — SAVE
```

1. Activate the desired positioning record (1 ... 31) with [Settings][Position set][Position nr].
2. Add or correct the positioning mode of the positioning record:
 - Select [Pos set mode] and use the arrow buttons to select the positioning mode:
 - absolute (a) = absolute position specification;
at the project zero point;
 - relative (r) = relative position specification;
at the current position;
 - energy optimised (...e) =
higher dynamic with less heating, but
the parameterised positioning profile
(trapezoid) is not exactly maintained.
 - Accept the value with OK <Enter>.



Note

If the positioning mode is modified:


- In the next step, check an already existing target position for plausibility.

5. Commissioning

3. Teach the target position of the position record:
 - Select [Position].
 - Move the drive manually to the desired target position with the arrow keys.
 - Accept the position reached with OK <Enter>. The setting of the target position and the positioning mode will then take effect in the drive.
4. Set the speed:
 - Select [Velocity].
 - Set the nominal speed with the arrow keys.
 - Accept the setting with OK <Enter>. The setting will then take effect in the drive.
5. Set the remaining parameters of this positioning record to appropriate values. Note:
 - “Jerk”:
The jerk in $[m/s^3]$ is the first derivative of the acceleration. Lower values result in gentler movement.
“Jerk Acc”: Jerk acceleration
“Jerk Dec”: Jerk when braking
 - “Work load”:
Mass of the individual workpieces; see section 5.2.7.
 - “Time MC” (damping time):
The time between reaching the target position window and setting MC “Motion Complete”), see Fig. 5/8.
6. Save this position record in EEPROM with **[SAVE]**.
7. Enter the next positioning record.

5. Commissioning

5.2.9 Test run



```
→ Positioning
   └─ Homing
      └─ Move posit. set
         └─ Demo posit. tab
```

1. Enter several positioning records (→ section 5.2.8).
 - You may wish to set target positions at the limits of the positioning range in order to check the software end positions.
 - You may wish to set various speeds, for example.
2. Select [Positioning][Move posit. set] in order to process a certain positioning record — or —
3. Select [Positioning][Demo posit. tab] in order to execute all position records. At least two positioning records must be entered in the position set table in order that this function can be used.



In the “Demo mode” [Demo posit. tab], all positioning records in the position set table are executed one after the other. If the position set table contains a positioning record with speed $v = 0$, this positioning record and all following records will not be executed; the positioning cycle will be continued with positioning record 1.

4. Start the test run.

With the **EMERG.STOP <Menu>** you can interrupt the current positioning task immediately.

With DEMO STOP <Enter> you can end the positioning cycle [Demo posit. tab]. However, the set currently being executed is completed first.

- Check the positioning behaviour.
 - Check the displayed positions of the axis.
5. If necessary, optimise the previous settings.

5.3 Commissioning with FCT

The Festo Configuration Tool (FCT) is the software platform for configuring and commissioning different components and devices from Festo.

The FCT consists of the following components:

- A framework as program start and entry point with uniform project and data management for all supported types of devices.
- PlugIns for the special requirements of each device type (e.g. SFC-LACI) with the necessary descriptions and dialogues. The PlugIns are managed and started from the framework.

Printed information

In order to use the complete help or parts of it independently of a PC, you can use one of the following options:

- Use the “Print” button in the Help window to print individual pages of the Help or all the pages of a book directly from the table of contents for the help.
- Print a prepared version of the help in Adobe PDF format:

Printed version	Directory	File
FCT help (Framework)	...(FCT installation directory)\Help\	– FCT_en.pdf
PlugIn help (SFC-LAC)	...(FCT installation directory)\HardwareFamilies\Festo\SFC-LAC\V...\Help\	– SFC-LAC_en.pdf



In order to use the printed version in Adobe PDF format, you will require Adobe Reader.

5. Commissioning

5.3.1 Installing the FCT

**Note**

FCT PlugIn SFC-LAC V 3.0.0 supports the motor controller SFC-LACI-...-DN with firmware version V1.00.

Check with later versions of the SFC-LACI whether an updated PlugIn is provided. If necessary, consult Festo.

**Note**

Administrator rights are required for installing the FCT.

The FCT is installed on your PC with an installation program.

1. Close all programs.
2. Place the “Festo Configuration Tool” CD in your CD ROM drive. If Auto-Run is activated on your system, the installation starts automatically and you can skip steps 3 and 4.
3. Select [Execute] in the Start menu.
4. Enter D:\setup (if necessary replace D with the letter of your CD ROM drive).
5. Follow the instructions on the screen.

5.3.2 Procedure

Starting the FCT

1. Connect the SFC-LACI to your PC via the parameterising interface (RS232) → section 3.5.
2. Start the FCT:
Double click on the FCT icon on the desktop
– or –
Switch to Windows and select the entry [Festo Software] [Festo Configuration Tool] in the menu [Start].
3. Create a project in the FCT or open an existing project.
Add a device to the project with the SFC-LAC PlugIn.

Instructions on parameterising and commissioning

FCT framework

Information on working with projects and on inserting a device in a project can be found in the help for the FCT framework with the command [Help][Contents FCT general].

PlugIn SFC-LAC

The SFC-LAC PlugIn for the FCT supports all the steps necessary for commissioning an SFC-LACI. The necessary parameterisation can be executed offline, i.e. without the SFC-LACI being connected to the PC. This enables preparation for the actual commissioning, e.g. in the design office when a new system is planned.



Further information can be found in the PlugIn help:
Command [Help][Contents of installed PlugIns]
[Festo (manufacturer name)][SFC-LAC (PlugIn name)].

Device Control

When the SFC-LACI is switched on, the controller interface is activated as standard [HMI = off].



Caution

Unexpected movements of the drive due to incorrect parameterising

- Make sure that there is no active ENABLE signal when switching on the SFC-LACI on the controller interface.
- Parameterise the entire system completely before activating the controller with ENABLE (controller interface), “Enable” (FCT), or [HMI = on] (control panel).

In order that the Festo Configuration Tool can control the connected SFC-LACI, the control interface of the SFC-LACI must be deactivated and control must be enabled in the FCT. The actual status of the control bit ENABLE then has no effect.

- To do this, go to the “Project Output” window, select the “Operate” tab and ,under “Device Control”, activate the “FCT” checkbox.
The controller interface of the SFC-LACI will then be deactivated and Control Enable will be set for the FCT.

5.4 Commissioning on a DeviceNet master

The following sections detail the configuration and addressing of the SFC-LACI on a DeviceNet interface and a DeviceNet master. To understand this section, you should be familiar with DeviceNet and know the specification.

5.4.1 Overview of commissioning on the field bus

The following steps are required for commissioning the SFC-LACI as a field bus participant:

1. Set the following on the SFC-LACI:

Settings	Description
MAC ID	Permitted address range: 0 ... 63
Baudrate	Permitted: 125 / 250 / 500 kBd
I/O Datalength	I/O data length <ul style="list-style-type: none">– 8 bytes (FHPP standard)– 16 bytes (FHPP standard + FHPP-FPC)

- on the control panel (only with type SFC-LACI-...-H2), see section 4.5.6 and 5.2.1 or
 - with the Festo Configuration Tool (see help for the Festo Configuration Tool).
2. Configure the master (section 5.4.2):
 - install the EDS file,
 - or make settings manually.
 3. Test the field bus connection.

5.4.2 Configuration of the DeviceNet master (“I/O configuration”)

Configuration with
EDS file

“EDS files” are available for configuring the DeviceNet master. These files are installed with the aid of the configuration software of the DeviceNet master. The detailed procedure can be found in the manuals for this software.

Obtainable from

The accompanying CD contains EDS files for the SFC-LACI in the “DeviceNet” folder.

You will find the latest EDS files on the Festo website at:
www.festo.com/download/

EDS file

For the SFC-LACI you will require one of the following EDS files (in English):

- SFC-LACI-DN_08-Revx_y.eds (= 8 bytes of I/O data) or SFC-LACI-DN_16-Revx_y.eds (= 16 bytes of I/O data, transmitted in 3 telegrams).
Only **one** EDS file can be installed.
- Graphics file: SFC-LACI.ico

Manual configuration

Vendor Code	26 (= 1Ah)
Product Type	12 (= 0Ch)
Product Code	9011 (decimal)

The corresponding device information can also be found in the EDS file under [Device].

5. Commissioning

Allen-Bradley

Support of the Auto Device Replacement (ADR) from Allen-Bradley.

In its master controllers, Rockwell Automation offers a special function that supports the slave stations with automatic parameter setting when a device is exchanged during servicing. All of the parameters with write access addressed in the EDS file are uploaded by the master after commissioning and saved in the scanner of the controller. Upon network startup, the parameter values are automatically downloaded to the slave via Explicit Messaging. This means that devices can be exchanged in the system without an FCT project.

Omron

Support of the Autoconfigmode on Omron controllers. With Omron controllers the DeviceNet slaves are configured by an Autoconfig mode. A setpoint configuration via the DeviceNet Configurator software is not necessary. The current network configuration automatically becomes the setpoint configuration. In addition, the scanner automatically performs an I/O mapping.

5.5 Festo Handling and Positioning Profile (FHPP)

5.5.1 FHPP operating modes

The FHPP operating modes differ regarding their contents and the meaning of the cyclic I/O data and in the functions which can be accessed in the SFC-LACI.

Operation mode	Description
Record selection	A total of 31 position sets (= positioning tasks) can be saved in the SFC-LACI. A record contains all the parameters which are required for a positioning task. The record number is transferred in the cyclic I/O data.
Direct mode	The task is transferred directly in the I/O telegram. Only the most important setpoint values (target position, speed) are thereby transferred. Supplementary parameters (e.g. acceleration) are defined via the parameterisation.

Tab. 5/2: Overview of FHPP operating modes

The operating mode is switched by the control byte CCON (see below) and indicated in the status byte SCON. Definition by means of parameterising is not possible. Switching between modes is only permitted in the “Drive disabled” or “Drive enabled” status.

Record selection

Preset operating mode when the SFC-LACI is started up.

The SFC-LACI has 31 records (1 ... 31), which contain all the information necessary for a positioning task (+ record 0 = homing run).

The record number, which the SFC-LACI is to process at the next start, is transferred in the output data of the master. The input data contains the record number that was processed last. The positioning job itself does not need to be active.

5. Commissioning



The SFC-LACI cannot function autonomously, i.e. it does not have its own user program. However, record switching can be used to define a sequence of records.

There are also 3 records with special functions (which cannot be executed in Record selection mode):

- Record 32 contains the parameters for the Jog mode.
- Record 33 contains the parameters for Direct mode.
- Record 34 is the direct set for the FCT software.

Direct mode

In direct mode (also called direct order) positioning tasks are formulated directly in the output data of the master.

Positioning mode

The typical application dynamically calculates the target setpoint values for each job or just for some jobs. Adaptation to different workpiece sizes is therefore possible. It is not sensible here to parameterise the record list again each time. The positioning data are managed completely in the PLC and sent to the SFC-LACI.

Operating modes of the SFC-LACI: “Profile Position Mode”

Force mode

Alternatively, setpoint values relative to the rated motor current can be specified in direct mode. With linear motors, this results in a force (force control).

Operating modes of the SFC-LACI: “Profile torque mode”

FHPP Continuous Mode

Continuous setpoint specification: Specification of changeable position values at millisecond frequency (typically 4 ... 10 ms).

Operating modes of the SFC-LACI: “FHPP Continuous Mode”

5.5.2 Structure of the cyclic I/O data (FHPP standard)

FHPP standard contains 8 bytes of input and 8 bytes of output data:

data	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Output data	Bytes 1 and 2 (fixed) are retained in each operating mode and transmit control and status bytes for enabling the SFC-LACI and for setting the operating modes.		Bytes 3 to 8 depend on the operating mode selected (Direct mode, Record select) and transmit further control and status bytes as well as setpoint and actual values: <ul style="list-style-type: none">– Record number or target position in the output data– Feedback of actual position and record number in the input data– Further setpoint and actual values depending on the operating mode					
Input data								

I/O data: Record selection								
data	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Output data	CCON	CPOS	Record no.	Reserved	Reserved			
Input data	SCON	SPOS	Record no.	RSB	Actual position			

I/O data: Direct mode								
data	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Output data	CCON	CPOS	CDIR	Setpoint value 1 (velocity)	Setpoint value 2 (position, force/torque,...)			
Input data	SCON	SPOS	SDIR	Actual value 1 (velocity, force/ torque,...)	Actual value 2 (actual position)			



Further 8 bytes I/O as per FHPP-FPC
In the cyclic data a further 8 bytes input data and 8 bytes output data are permitted for transferring parameters in accordance with the FPC protocol (Festo Parameter Channel)
→ section B.2.

5. Commissioning

Assignment of the control bytes (overview)

CCON	B7 OPM2	B6 OPM1	B5 LOCK	B4 –	B3 (F) RESET	B2 BRAKE	B1 STOP	B0 ENABLE
	Operating mode selection		HMI access blocked	–	Acknowled. error	Clamping unit	Stop	Enable drive
CPOS	B7 –	B6 CLEAR	B5 TEACH	B4 JOGN	B3 JOGP	B2 (F) HOM	B1 (F) START	B0 HALT
	–	Clear remaining path	Teach value	Jog negativ	Jog positiv	Start homing	Start position. task	Halt
CDIR (only direct mode)	B7 FUNC	B6 FAST	B5 XLIM	B4 CONTT	B3 CONT	B2 COM2	B1 COM1	B0 ABS
	–	–	Deactiv. stroke limit	Contin. mode toggle	Continuous mode	Control mode (Position, force ...)		Absolute/relative
– : reserved; (F): edge-sensitive								

Assignment of the status bytes (overview)

SCON	B7 OPM2	B6 OPM1	B5 HMI	B4 24VL	B3 FAULT	B2 WARN	B1 OPEN	B0 ENABLED
	Acknowledgement of operating mode		Control hierarchy	Load voltage applied	Error	Warning	Operation enabled	Drive enabled
SPOS	B7 REF	B6 STILL	B5 DEV	B4 MOV	B3 TEACH	B2 MC	B1 ACK	B0 HALT
	Drive referenced	Down-time monitor	Contour error	Axis is moving	Acknowl. teach or sample	Motion complete	Acknowledge start	Halt
SDIR (only direct mode)	B7 FUNC	B6 FAST	B5 XLIM	B4 VLIM	B3 CONT	B2 COM2	B1 COM1	B0 ABS
	–	–	Stroke limit reached	Velocity limit reached	–	Reply message control mode (position, force, ...)		Absolute/relative
– : reserved								

5. Commissioning

5.5.3 Description of the I/O data (Record select)

Description of the output data: Record selection		
Byte	EN	Description
1	CCON	Control bytes, see section 5.5.5
2	CPOS	
3	Record number	Pre-selection of record number (0 ... 31)
4 ... 8	–	Reserved (= 0)

Description of the input data: Record selection		
Byte	EN	Description
1	SCON	Status bytes, see section 5.5.6
2	SPOS	
3	Record number	Reply message of record number (0 ... 31)
4	RSB	Record status byte
	Bit 0 RC1: 1st Record Chaining	For record chaining: = 0: First step criterion not configured / not reached = 1: First step criterion reached *)
	Bit 1 RCC: Record Chaining Complete	For record chaining (only valid when MC = 1): = 0: Record chaining cancelled. At least one step criterion was not configured/achieved = 1: Record chain was processed to the end of the chain
5 ... 8	Position, ...	Feedback of the position in increments
*) The first step criterion is reached when, after the first record with further switching, Motion Complete = 1		

5. Commissioning

5.5.4 Description of the I/O data (Direct mode)

Output data – Direct mode		
Byte	EN	Description
1	CCON	Control bytes, see section 5.5.5
2	CPOS	
3	CDIR	
4	Velocity	In % of the basic speed (compare PNU 540 / CI 21F8h)
5 ... 8	new Force, ...	Position in increments or force in % of rated force

Input data – Direct mode		
Byte	EN	Description
1	SCON	Status bytes, see section 5.5.6
2	SPOS	
3	SDIR	
4	Velocity	In % of basic speed (compare PNU 540 / CI 21F8h)
	Force	In % of the rated force (see section 5.5.7, point 7)
5 ... 8	new	Position in increments

5.5.5 Description of the control bytes CCON, CPOS, CDIR

CCON With control byte 1 (CCON) all the states are controlled which must be available in all operating modes. The cooperation of the control bits can be found under the description of the drive functions in section 5.6.

Control byte 1 (CCON)		
Bit	EN	Description
B0 ENABLE	Enable Drive	= 1: Drive (controller) enable = 0: Drive (controller) blocked
B1 STOP	Stop	= 1: Enable drive Any error will be deleted = 0: STOP active: The axis stops with the fast stop ramp (Quick Stop) or with the normal stop ramp (compare PNU 1020/605Dh). The positioning task counts as finished.
B2 BRAKE	Brake	If the SFC-LACI is not in the “ready” state (Status word does not equal “operation_enable”): = 0: Close brake / clamping unit = 1: Open brake / clamping unit. In the “ready” condition, the controller takes over control of the brake output. Control of the output via the PLC is then not possible.
B3 RESET	Reset Fault	With a rising edge a fault is acknowledged and the fault number is deleted
B4	–	reserved, must be at 0
B5 LOCK	Lock HMI access	Controls access to the parameterisation interface: = 1: MMI and FCT may only observe the drive, the device control (HMI control) cannot be taken over by MMI and FCT. = 0: MMI or FCT may take over the device control (in order to modify parameters or to control inputs)
B6 OPM1	Select Operating Mode	= 00: Record selection = 01: Direct mode = 10: reserved = 11: reserved
B7 OPM2		

5. Commissioning

CPOS

Control byte 2 (CPOS) controls the positioning sequences as soon as the drive is enabled.

Control byte 2 (CPOS)		
Bit	EN	Description
B0 HALT	Halt	= 1: HALT is not active = 0: HALT is activated. The axis stops with a defined braking ramp, the positioning job remains active (with B6 the remaining path can be deleted)
B1 START	Start positioning job	With a rising edge the current setpoint data will be transferred and positioning started (record 0 = homing run)
B2 HOM	Start Homing	With a rising edge homing is started with the set parameters.
B3 JOGP	Jog positive	The drive moves at the specified speed in the direction of larger actual values, providing the bit is set. The movement begins with the rising edge and ends with the falling edge.
B4 JOGN	Jog negative	The drive moves in the direction of smaller actual values, see bit 3.
B5 TEACH	Teach actual value	With a falling edge the current actual value of the position will be transferred to the setpoint value register of the currently addressed positioning task, see section 5.6.3. The teach target is defined with PNU 520.
B6 CLEAR	Clear Remaining Position	In the "HALT" status, a signal edge causes the positioning task to be deleted and transfer is made to the "Ready" status.
B7 –	–	Reserved, must be set to 0

5. Commissioning

CDIR

Control byte 3 (CDIR) is a special control byte for the operating mode “Direct mode”.

Control byte 3 (CDIR) – Direct mode		
Bit	EN	Description
B0 ABS	Absolute/ Relative	= 0: Setpoint value is absolute = 1: Setpoint value is relative to last setpoint value
B1 COM1	Control mode	= 00: Positioning mode = 01: Force control = 10: reserved = 11: Positioning mode energy optimised
B2 COM2		
B3 CONT	Continuous Mode	Continuous setpoint specification: = 0: inactive = 1: active
B4 CONTT	Continuous Mode Toggle	Must be toggled for every specified cycle to ensure that new specifications are recognised.
B5 XLIM	Stroke (X -) limit not active	In force mode = 0: Stroke monitoring active = 1: Stroke monitoring not active
B6 FAST	–	reserved, must be at 0
B7 FUNC	–	reserved, must be at 0

5. Commissioning

5.5.6 Description of the status bytes SCON, SPOS, SDIR (RSB)

Status byte 1 (SCON)		
Bit	EN	Description
B0 ENABLED	Drive Enabled	= 0: Drive blocked, controller not active = 1: Drive (controller) enabled
B1 OPEN	Operation Enabled	= 0: STOP active = 1: Operation enabled, positioning possible
B2 WARN	Warning	= 0: Warning not applied = 1: Warning applied Fault number in diagnostic memory
B3 FAULT	Fault	= 0: No error = 1: An error exists or an error reaction is active Fault number in diagnostic memory
B4 24VL	Voltage Load	= 0: No load voltage = 1: Load voltage applied
B5 HMI	Drive control	= 0: Device control by PLC/field bus = 1: Device control by FCT/MMI
B6 OPM1	Operating Mode	= 00: Record select (standard) = 01: Direct mode = 10: reserved = 11: reserved
B7 OPM2		

5. Commissioning

Status byte 2 (SPOS)		
Bit	EN	Description
B0 HALT	Halt	= 0: HALT is active = 1: HALT is not active; axis can be moved
B1 ACK	Acknowledge Start	= 0: Ready for start (reference, jog) = 1: Start carried out
B2 MC	Motion Complete	= 0: Positioning job active = 1: Positioning job completed, where applicable with error Note: MC is first set after switching on (status "Drive blocked")
B3 TEACH	Acknowledge teaching / sampling	Depending on the setting in PNU 354: <ul style="list-style-type: none"> – PNU 354 = 0: Display of the teach status SPOS.B3 = 0: Ready for teaching SPOS.B3 = 1: Teaching carried out, actual value is transferred – PNU 354 = 1: Display of the sampling status SPOS.B3 = 0: No edge SPOS.B3 = 1: An edge has occurred New position value available On the position sampling: see section 5.6.12
B4 MOV	Axis is Moving	= 0: Speed of the axis < limit value = 1: Speed of the axis >= limit value
B5 DEV	Deviation Warning	= 0: No drag error = 1: Contouring error active
B6 STILL	Standstill warning	= 0: After MC, axis remains in tolerance window = 1: After MC axis remains outside tolerance window
B7 REF	Axis is Referenced	= 0: Drive is not referenced (homing run must be carried out) = 1: Drive is referenced

5. Commissioning

Status byte 3 (SDIR) – Direct mode		
Bit	EN	Description
B0-ABS	Absolute/Relative	= 0: Setpoint value is absolute = 1: Setpoint value is relative to last setpoint value
B1-COM1	Control Mode feedback	= 00: Positioning mode = 01: Force control = 10: reserved = 11: Positioning mode energy optimised
B2-COM2		
B3-CONT	Continuous Mode	Continuous setpoint specification: = 0: inactive = 1: active
B4-VLIM	Speed (V-) Limit reached	With force control: = 1: Speed limit reached = 0: Speed limit not reached
B5-XLIM	Stroke (X-) Limit reached	With force control: = 1: Stroke limit value reached = 0: Stroke limit value not reached
B6-FAST	–	Reserved
B7-FUNC	–	Reserved

5.5.7 Examples of control and status bytes (FHPP standard)

On the following pages you will find typical examples of control and status bytes as per FHPP standard:

1. Create readiness to operate – Record selection
2. Create readiness to operate – Direct mode
3. Fault handling
4. Homing run
5. Positioning using record selection
6. Direct mode: Positioning mode
7. Direct mode: Force mode



A description of the status machine of the SFC-LACI can be found in section B.3.

0. Safeguard device control

Step/ Description	Control bytes									Status bytes								
	Byte	B7	B6	B5	B4	B3	B2	B1	B0	Byte	B7	B6	B5	B4	B3	B2	B1	B0
0.1 Device control HMI = on	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	CCON	0	0	0	0	0	0	0	0	SCON	0	0	1	1	0	0	0	0
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	CPOS	x	0	0	0	0	0	0	0	SPOS	0	0	0	0	0	1	0	0
0: 0-signal 1: 1-signal x: not relevant (optional) F: Edge positive																		

Tab. 5/3: Control and status bytes “Device control active”

Description of 0. Secure device control

- 0.1 Device control via the parameterisation interface (control panel or FCT) is activated.
For controlling the SFC-LACI via the control interface, this device control must first be deactivated via the parameterisation interface (HMI = off).

1. Create readiness to operate – Record select

Step/ Description	Control bytes										Status bytes									
	Byte	B7	B6	B5	B4	B3	B2	B1	B0	Byte	B7	B6	B5	B4	B3	B2	B1	B0		
1.1 Basic status (Device control HMI = off)	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL		
	CCON	0	0	0	0	0	0	0	0	SCON	0	0	0	1	0	0	0	0		
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT		
	CPOS	x	0	0	0	0	0	0	0	0	SPOS	0	0	0	0	0	1	0	0	
1.2 Disable device control by FCT/HMI (optional)	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL		
	CCON	x	x	1	x	x	0	x	x	SCON	x	x	0	x	x	x	x	x		
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT		
	CPOS	x	x	x	x	x	x	x	x	x	SPOS	x	x	x	x	x	x	x		
1.3 Enable drive, enable operation (Record selection)	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL		
	CCON	0	0	x	x	0	0	1	1	SCON	0	0	0	1	0	0	1	1		
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT		
	CPOS	x	0	0	0	0	0	0	1	1	SPOS	0	0	0	0	0	1	0	1	
0: 0-signal 1: 1-signal x: not relevant (optional) F: Edge positive																				

Tab. 5/4: Control and status bytes a “Establish readiness – set selection”

Description of 1. Create readiness to operate

- 1.1 Basic status of the drive when the supply voltage has been switched on → Step 1.2 or 1.3
- 1.2 Optionally: Disable device control via FCT/HMI using CCON.B5 = 1 (LOCK) → Step 1.3
- 1.3 Enable drive in Record Select mode
→ Homing: Example 4, Tab. 5/7

If there are faults after switching on or after setting CCON.B0 (ENABLE):
 → Fault handling: see example 3, Tab. 5/6 and section 6.3 “Error messages”



2. Create readiness to operate – Direct mode

Step/ Description	Control bytes									Status bytes								
	Byte	B7	B6	B5	B4	B3	B2	B1	B0	Byte	B7	B6	B5	B4	B3	B2	B1	B0
2.1 Basic status (Device control HMI = off)	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	CCON	0	0	0	0	0	0	0	0	SCON	0	0	0	1	0	0	0	0
2.2 Disable device control by FCT/HMI (optional)	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	CPOS	x	0	0	0	0	0	0	0	SPOS	0	0	0	0	0	1	0	0
2.3 Enable drive, enable operation (Direct mode)	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	CCON	x	x	1	x	x	0	x	x	SCON	x	x	0	x	x	x	x	x
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	CPOS	x	x	x	x	x	x	x	x	SPOS	x	x	x	x	x	x	x	x
0: 0-signal 1: 1-signal x: not relevant (optional) F: Edge positive																		

Tab. 5/5: Control and status bytes “Create readiness to operate – Direct mode”

Description of 2. Create readiness to operate

- 2.1 Basic status of the drive when the supply voltage has been switched on → Step 2.2 or 2.3
- 2.2 Optionally: Disable device control via FCT/HMI using CCON.B5 = 1 (LOCK) → Step 2.3
- 2.3 Enable drive in Direct mode
→ Homing: Example 4, Tab. 5/7

If there are faults after switching on or after setting CCON.B0 (ENABLE):

→ Fault handling: see example 3, Tab. 5/6 and section 6.3 “Error messages”



3. Fault handling

Step/ Description	Control bytes									Status bytes								
	Byte	B7	B6	B5	B4	B3	B2	B1	B0	Byte	B7	B6	B5	B4	B3	B2	B1	B0
3.1 Error	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	CCON	x	x	x	x	x	0	x	x	SCON	x	x	x	x	1	x	x	x
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	CPOS	x	x	x	x	x	x	x	x	SPOS	x	x	x	x	x	0	x	x
3.2 Warning	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	CCON	x	x	x	x	x	0	x	x	SCON	x	x	x	x	x	1	x	x
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	CPOS	x	x	x	x	x	x	x	x	SPOS	x	x	x	x	x	0	x	x
3.3 Acknowledge fault	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	CCON	0	x	x	x	F	0	x	1	SCON	0	x	0	1	0	0	0	0
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
with CCON.B3 (RESET)	CPOS	x	0	0	0	0	0	x	x	SPOS	x	0	0	0	0	1	0	1
3.4 Acknowledge fault	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	CCON	0	x	x	x	0	0	x	N	SCON	0	x	0	1	0	0	x	0
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
with CCON.B0 (ENABLE)	CPOS	x	0	0	0	0	0	x	x	SPOS	x	0	0	0	0	1	x	x
0: 0-signal 1: 1-signal x: Not relevant (optional) F: Positive edge N: Negative edge																		

Tab. 5/6: Control and status bytes “Error treatment”



Description to 3. Fault handling

Description of errors and warnings see section 6.3.

- 3.1 An error is shown with SCON.B3 FAULT.
→ Positioning can no longer be undertaken.
- 3.2 A warning is shown with SCON.B2 WARN.
→ Positioning can still be undertaken.
- 3.3 Acknowledge fault with positive edge at CCON.B3 (RESET).
→ Fault bit SCON.B3 FAULT or SCON.B2 (WARN) will be reset.
→ SPOS.B2 MC will be set.
→ Drive is ready to operate.

– or –

- 3.4 Acknowledge fault with negative edge at CCON.B0 ENABLE.
→ Fault bit SCON.B3 FAULT or SCON.B2 WARN will be reset.
→ SPOS.B2 MC will be set.
→ Establish readiness to operate again
(see examples 1, Tab. 5/4 and 2, Tab. 5/5)



Caution

After the removal of ENABLE, the drive is no longer under position control. This may cause injury to people and material damage.

- With vertical or sloping drive mountings, the moving mass might slide down.

4. Homing run (requires status 1.4 or 1.5)

Step/ Description	Control bytes										Status bytes									
	Byte	B7	B6	B5	B4	B3	B2	B1	B0	Byte	B7	B6	B5	B4	B3	B2	B1	B0		
4.1 Start homing	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL		
	CCON	0	x	x	x	0	0	1	1	SCON	0	x	0	1	0	0	1	1		
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT		
	CPOS	x	0	0	0	0	F	0	1	SPOS	0	0	0	0	0	0	1	1		
4.2 Homing running	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL		
	CCON	0	x	x	x	0	0	1	1	SCON	0	x	0	1	0	0	1	1		
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT		
	CPOS	x	0	0	0	0	1	0	1	SPOS	0	0	0	1	0	0	1	1		
4.3 Homing finished	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL		
	CCON	0	x	x	x	0	0	1	1	SCON	0	x	0	1	0	0	1	1		
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT		
	CPOS	x	0	0	0	0	0	0	1	SPOS	1	0	0	0	0	1	0	1		
0: 0-signal 1: 1-signal x: not relevant (optional) F: Edge positive																				

Tab. 5/7: Control and status bytes “Homing run”

Description on 4. Homing run

- 4.1 A positive edge at CPOS.B2 HOM starts the reference travel. The start is confirmed with SPOS.B1 CK (Acknowledge start) as long as CPOS.B2 HOM is set.
- 4.2 Movement of the axis is shown with SPOS.B4 MOV.
- 4.3 After successful reference travel SPOS.B2 MC (Motion Complete) and SPOS.B7 REF will be set.

If there are faults during homing:
→ Fault handling: see example 3, Tab. 5/6



5. Commissioning

5. Positioning Record select (requires status 1.3/2.3 and 4.)

Step/ Description	Control bytes									Status bytes								
	Byte	B7	B6	B5	B4	B3	B2	B1	B0	Byte	B7	B6	B5	B4	B3	B2	B1	B0
5.1 Preselect record number (control byte 3)	Byte 3 Record No.	Record number Record no. (1 ... 31)								Byte 3 Record No.	Record number Previous record no. (1 ... 31)							
5.2 Start task	Byte 1 CCON	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1 SCON	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	Byte 2 CPOS	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2 SPOS	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
5.3 Job running	Byte 1 CCON	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1 SCON	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	Byte 2 CPOS	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2 SPOS	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	Byte 3 Record No.	Record number Record no. (0 ... 31)								Byte 3 Record No.	Record number Current record no. (0 ... 31)							
	Byte 1 CCON	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1 SCON	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
5.4 Job finished	Byte 2 CPOS	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2 SPOS	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	Byte 5 ... 8	Reserved								Byte 5 ... 8	new							
	–	Reserved								Actual position	Actual position (increments)							
	0: 0-signal 1: 1-signal x: Not relevant (optional) F: Positive edge																	

Tab. 5/8: Control and status bytes “Positioning record select”

Description of 5. Positioning record select

(Sequence dependent on steps 5.1 ... 5.4)

When the readiness to operate is created and the reference travel has been carried out, a positioning task can be started.

- 5.1 Preselect record number: Byte 3 of the output data
 - 0 = Reference travel
 - 1 ... 31 = Programmable positioning records
- 5.2 With CPOS.B1 START the preselected positioning task will be started. The start is confirmed with SPOS.B1 (Acknowledge start) as long as CPOS.B1 START is set.
- 5.3 Movement of the axis is shown with SPOS.B4 MOV.
- 5.4 At the end of the positioning task, SPOS.B2 MC (Motion Complete) will be set.

If there are faults during positioning:

→ Fault handling: see example 3, Tab. 5/6



5. Commissioning

6. Direct mode: Positioning mode (requires status 1.3/2.3 and 4.)

Step/ Description	Control bytes									Status bytes								
	Byte	B7	B6	B5	B4	B3	B2	B1	B0	Byte	B7	B6	B5	B4	B3	B2	B1	B0
6.1 Preselect position and speed (control bytes 4 and 5 ... 8)	Byte 4 Velocity	RVelocity Velocity preselect (0 ... 100 %)								Byte 4 Velocity	RVelocity Velocity reply message (0 ... 100 %)							
	Byte 5...8 Set-point (target) position	new Setpoint position (increments)								Byte 5...8 Actual position	new Actual position (increments)							
6.2 Start task	Byte 1 CCON	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1 SCON	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	Byte 2 CPOS	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2 SPOS	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	Byte 3 CDIR	FUNC	FAST	XLIM	VLIM	CONT	COM2	COM1	ABS	Byte 3 SDIR	FUNC	FAST	XLIM	VLIM	CONT	COM2	COM1	ABS
6.3. Order runs	Byte 1 CCON	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1 SCON	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	Byte 2 CPOS	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2 SPOS	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
6.4 Job finished	Byte 1 CCON	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1 SCON	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	Byte 2 CPOS	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2 SPOS	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
0: 0-signal 1: 1-signal x: Not relevant (optional) F: Positive edge S: Positioning condition: 0 = absolute 1 = relative																		

Tab. 5/9: Control and status bytes “Positioning mode Direct mode”

Description of direct mode – positioning mode

(step 6.1 ... 6.4 conditional sequence)

When the readiness to operate is created and the reference travel has been carried out, a setpoint position must be preselected.

- 6.1 The setpoint position in increments is transferred to bytes 5 ... 8 of the output word.
The setpoint speed is transferred in % of the base value in byte 3 (0 = no speed; 100 = base value).
- 6.2 With CPOS.B1 START the preselected positioning task will be started. The start is confirmed with SPOS.B1 (Acknowledge start) as long as CPOS.B1 START is set.
- 6.3 Movement of the axis is shown with SPOS.B4 MOV.
- 6.4 At the end of the positioning task, SPOS.B2 MC (Motion Complete) will be set.

If there are faults during positioning:

→ Fault handling: see example 3, Tab. 5/6



7. Direct mode – Force mode (requires status 1.3/2.3 and 4)

Step/ Description	Control bytes									Status bytes								
	Byte	B7	B6	B5	B4	B3	B2	B1	B0	Byte	B7	B6	B5	B4	B3	B2	B1	B0
7.1 Specify setpoint value	4	not relevant								4	Actual value in % of the rated force							
	5 ... 8	Setpoint value in % of the rated force								5 ... 8	Actual position in increments							
7.2 Prepare force control	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	CCON	0	1	x	x	0	0	1	1	SCON	0	1	0	1	0	0	1	1
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	CPOS	x	0	0	0	0	0	0	1	SPOS	1	0	0	0	0	1	0	1
7.3 Start task	Byte 3	FUNC	FAST	XJUM	–	CONT	COM2	COM1	ABS	Byte 3	FUNC	FAST	XJUM	VJUM	CONT	COM2	COM1	ABS
	CDIR	0	0	S	x	0	0	1	0	SDIR	0	0	0	x	0	0	0	0
	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	CCON	0	1	x	x	0	0	1	1	SCON	0	1	0	1	0	0	1	1
7.4 Job running (setpoint value not reached)	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	CPOS	x	0	0	0	0	0	F	1	SPOS	1	0	0	0	0	0	1	1
	Byte 3	FUNC	FAST	XJUM	–	CONT	COM2	COM1	ABS	Byte 3	FUNC	FAST	XJUM	VJUM	CONT	COM2	COM1	ABS
	CDIR	0	0	S	x	0	0	1	0	SDIR	0	0	0	0	0	0	1	0
7.5 Job running (setpoint value reached)	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	CCON	0	1	x	x	0	0	1	1	SCON	0	1	0	1	0	0	1	1
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	CPOS	x	0	0	0	0	0	x	1	SPOS	1	0	0	0	0	1	x	1
7.5 Job running (setpoint value reached)	Byte 3	FUNC	FAST	XJUM	–	CONT	COM2	COM1	ABS	Byte 3	FUNC	FAST	XJUM	VJUM	CONT	COM2	COM1	ABS
	CDIR	0	0	S	x	0	0	1	0	SDIR	0	0	0	0	0	0	1	0
	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL
	CCON	0	1	x	x	0	0	1	1	SCON	0	1	0	1	0	0	1	1
7.5 Job running (setpoint value reached)	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT
	CPOS	x	0	0	0	0	0	x	1	SPOS	1	0	0	0	0	1	x	1
	Byte 3	FUNC	FAST	XJUM	–	CONT	COM2	COM1	ABS	Byte 3	FUNC	FAST	XJUM	VJUM	CONT	COM2	COM1	ABS
	CDIR	0	0	S	x	0	0	1	0	SDIR	0	0	0	0	0	0	1	0

5. Commissioning

Step/ Description	Control bytes										Status bytes								
	Byte	B7	B6	B5	B4	B3	B2	B1	B0	Byte	B7	B6	B5	B4	B3	B2	B1	B0	
7.6 Job discontinued (stroke limit or software end position reached)	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL	
	CCON	0	1	x	x	0	0	1	1	SCON	0	1	0	1	0	0	1	1	
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT	
	CPOS	x	0	0	0	0	0	x	1	SPOS	1	0	0	0	0	1	x	1	
	Byte 3	FUNC	FAST	XUM	–	CONT	COM2	COM1	ABS	Byte 3	FUNC	FAST	XUM	VUM	CONT	COM2	COM1	ABS	
	CDIR	0	0	S	x	0	0	1	0	SDIR	0	0	1	0	0	0	0	0	
7.7 Stop job (e.g. with STOP)	Byte 1	OPM2	OPM1	LOCK	–	RESET	BRAKE	STOP	ENABL	Byte 1	OPM2	OPM1	HMI	24VL	FAULT	WARN	OPEN	ENABL	
	CCON	0	1	x	x	0	0	0	1	SCON	0	1	0	1	0	0	0	1	
	Byte 2	–	CLEAR	TEACH	JOGN	JOGP	HOM	START	HALT	Byte 2	REF	STILL	DEV	MOV	TEACH	MC	ACK	HALT	
	CPOS	x	0	0	0	0	0	x	1	SPOS	1	0	0	0	0	1	x	1	
	Byte 3	FUNC	FAST	XUM	–	CONT	COM2	COM1	ABS	Byte 3	FUNC	FAST	XUM	VUM	CONT	COM2	COM1	ABS	
	CDIR	0	0	S	x	0	0	1	0	SDIR	0	0	0	0	0	0	0	0	
0: 0-signal 1: 1-signal x: Not relevant (optional) F: Positive edge S: Positioning condition: 0 = absolute 1 = relative																			

Tab. 5/10: Control and status bytes “Direct mode – Force mode”

Description of force mode

When the readiness to operate is created and the reference travel has been carried out, a setpoint value must be specified and the force control must be prepared.

- 7.1 Specify the setpoint value in % of the rated motor force. Value range: 30 ... 100 % (values under 30 % are rounded up to 30 %).
- 7.2 Prepare force control Set bit CDIR.B1 COM1 and if desired set bit CDIR.B5 XLIM for the stroke limitation.
- 7.3 Start the job with CPOS.B1 START. The start is confirmed with SPOS.B1 (Acknowledge start) as long as CPOS.B1 START is set.
- 7.4 or 7.5
Depending on whether the setpoint value is reached or not, the relevant bits in the status will be set.
- 7.6 The job will be finished automatically when the stroke limit or software end position is reached. Switching is made again to position control.
- 7.7 The task can be discontinued by the controller e.g. with STOP.



If there are faults during force mode:
see example 3, Tab. 5/6 Fault handling



Note

Modification of the setpoint value with force mode is only possible with a new starting edge when the last specified position (MC) has been reached.

5.6 Drive functions



The necessary FHPP parameter numbers (PNU) will be specified for each drive function. The relevant DeviceNet parameters (class, attribute, instance) can be found in the detailed descriptions of the PNUs in section B.4.

5.6.1 Homing

When the device is switched on, homing must be carried out before a positioning task can be executed.

The drive homes against a stop or a proximity sensor. A stop is reached when there is an increase in the motor current at the same time as the drive shaft comes to a stop. As the drive must not position continuously against the stop, it must move at least 1 mm into the stroke range again (offset axis zero point).

Sequence

1. Search for the reference point in accordance with the configured method.
2. Move from reference point to axis zero point (offset axis zero point).
3. Set at axis zero point:
Actual position = 0 – project zero point offset (i.e. PZ).

5. Commissioning

Overview of parameters involved (see also section B.4.9)				
Parameters involved	Description	FCT	PNU	CI
	Offset axis zero point	x	1010	607Ch
	Homing method	x	1011	6098h
	Homing speeds	x	1012	6099h
	Homing required	–	1014	23F6h
	Maximum homing current	x	1015	23F7h
Start (FHPP)	CPOS.B2 = positive edge: Start Referenzfahrt			
Feedback (FHPP)	SPOS.B1 = positive edge: Acknowledge start SPOS.B7 = drive is referenced			
Prerequisites	Device control by PLC/field bus; controller in the “Operation enabled” status; no jogging command is present.			

Tab. 5/11: Parameters involved in homing

Homing methods ¹⁾		
Hex	Dec	Description
01h	1	Search for limit switch in negative direction with index search
02h	2	Search for limit switch in positive direction with index search
07h	7	Search for reference switch in positive direction with index search
0Bh	11	Search for reference switch in negative direction with index search
EFh	-17	Search for stop in a negative direction. The point found is the reference position. As the axis must not stand still at the stop, the offset axis zero point must be $\neq 0$.
EEh	-18	Search for stop in a positive direction. The point found is the reference position. As the axis must not stand still at the stop, the offset axis zero point must be $\neq 0$.
¹⁾ For a detailed description of the reference travel methods see section 1.1.6.		

Tab. 5/12: Overview of homing methods

5.6.2 Jog mode

In the “Operation enabled” status, the drive can be jogged to the left/right. This function is usually used for

- Moving to teaching positions
- Moving the drive out of the way (e.g. after a system fault)
- Manual movement as the normal operating mode

Sequence

1. When one of the signals “Jog left / Jog right” is set, the drive starts to move slowly. Due to the slow speed, a position can be defined very accurately.
2. If the signal remains set, after the time “Duration Phase 1” has passed, the speed will be increased until the maximum configured speed is reached. In this way large strokes can be traversed quickly.
3. When the signal changes to 0, the drive is braked.
4. The drive stops automatically if it reaches a software end position (if the drive is referenced; otherwise, no test of the software end positions!). The software end position is not exceeded; the path for stopping is taken into account according to the ramp set. The jog mode can be exited here with Jogging = 0.

5. Commissioning




Fig. 5/1: Sequence diagram for jog mode

Overview of parameters involved (see section B.4.8)				
Parameters involved	Description	FCT	PNU	CI
	Speed Phase 2 2	x	531	20ED/21h
	Acceleration or deceleration 3	x	532	20EE/21h
	Duration phase 1 4	x	534	20E9/21h
Start (FHPP)	CPOS.B3 = 1: Jog positive (forwards) CPOS.B4 = 1: Jog negative (backwards)			
Feedback (FHPP)	SPOS.B4 = 1: Drive moving SPOS.B2 = 0: Motion Complete			
Requirements	Device control by PLC/field bus Controller must be in status "Operation enabled"			

Tab. 5/13: Parameters involved in jogging mode

5.6.3 Teaching via field bus

Position values can be taught via the field bus. Previously taught position values will then be overwritten.

Sequence

- 1. The drive is moved to the desired position using the jogging mode.
- 2. The user must make sure that the desired parameter is selected. For this, the parameter “Teach target” and, if applicable, the correct record address must be entered.

Teach target (PNU 520)	Is taught
= 1 (specification)	Target position in position record. – Record selection: Positioning record after control byte 3 – Direct mode: Positioning record after PNU 400
= 2	Axis zero point
= 3	Project zero point
= 4	Lower software end position
= 5	Upper software end position

Tab. 5/14: Overview of teach targets

3. Teaching takes place via the handshake of the bits in the FHPP control and status bytes CPOS/SPOS:

- 1 Ready for teaching
- 2 Value transferred




Fig. 5/2: Handshake when teaching



The drive must not stand still for teaching. However, a speed of 1 m/s means that the actual position changes by 1 mm every millisecond. With the usual cycle times of the PLC + field bus + motor controller there will be inaccuracies of several millimetres even at a speed of only 100 mm/s.

Overview of parameters involved (see sections B.4.7 and B.4.8)				
Parameters involved	Description	FCT	PNU	CI
	Teach target	– 1)	520	21FCh
	Record number	– 1)	400	2033h
Start (FHPP)	CPOS.B5 = falling edge: Teach value			
Feedback (FHPP)	SPOS.B3 = 1: Value transferred			
Prerequisites	Device control by PLC/field bus Controller must be in status “Operation enabled”			
1) Teaching is made possible in the Festo Configuration Tool by means of special functions.				

Tab. 5/15: Parameters involved in teaching

5.6.4 Record selection: Carrying out a record

A record can be started in the “Drive enabled” state.
This function is usually used for:

- moving to any position from positions in the record list,
- processing a positioning profile by linking records,
- known target positions that seldom change (formulation change).

Sequence

1. Set the desired record number in the output data of the master. Until the start, the controller replies with the number of the record last processed.
2. With a rising edge at START (CPOS.B1) the controller accepts the record number and starts the positioning job.
3. The controller signals with the rising edge at “Acknowledge start” that the PLC output data has been accepted and the positioning job is now active. The positioning command will be processed irrespective of whether CPOS.B1 START has been reset to zero or not.
4. When the record is concluded, SPOS.B2 MC is set.

Causes of errors

- Homing has not been carried out.
- The target position is unreachable.
- Invalid record number.




Fig. 5/3: Sequence diagram for start/stop record




Fig. 5/4: Sequence diagram: Stop record with HALT and continue




Fig. 5/5: Sequence diagram: Stop record with HALT and delete remaining path

Parameters involved (record selection)

The entries in the positioning table can be written via the field bus (PNU 401 ... 417).



The composition of the positioning table as per FHPP is described in section B.4.7. Record chaining is described in section 5.6.5.

Overview of parameters involved (see section B.4.7)				
Parameters involved	Description	FCT	PNU	CI
	Mode (absolute/relative/energy optimised)	x	401	20E0/01h
	Target position	x	404	20E0/02h
	Velocity	x	406	20E0/03h
	Acceleration	x	407	20E0/04h
	Deceleration (=Braking)	x	408	20E0/0Ah
	Acceleration jerk	x	409	20E0/05h
	Mass of the working load (without tool mass)	x	410	20E0/06h
	Damping time	x	415	20E6h 20E0/07h
	Deceleration jerk	x	417	20E0/0Bh
Start (FHPP)	CPOS.B1 = positive edge: Start Jogging and referencing have priority			
Feedback (FHPP)	SPOS.B2 = 0: Motion complete SPOS.B1 = positive edge: Acknowledge start SPOS.B4 = 1: Drive moving			
Requirements	Device control by PLC/field bus Controller must be in status "Operation enabled" Record number must be valid			

Tab. 5/16: Parameters involved in Record Select mode

5. Commissioning

5.6.5 Record selection: Switching to next record

Switching to the next record (= record chaining) allows a sequence of records to be defined. To do this, for every record in the table you can specify whether another record should be processed afterwards (PNU 402), and if so, then which record (PNU 416) is to be processed after which delay (PNU 405).

Overview of supplementary parameters (see Tab. 5/16)				
Parameters involved	Description	FCT	PNU	CI
	Switch to next record yes/no?	x	402	20EBh 20E0/01h
	Delay time in [ms]: The time between Motion Complete (MC) for a record with record chaining and the start of the next positioning record.	x	405	20E4h 20E0/08h
	Number of the next positioning record	x	416	20E5h 20E0/09h
Feedback (FHPP)	PNU 400/2: Active position record Status byte 4 RSB.B0 RC1 = 1: First record chaining performed (counts as carried out if after the first record with further switching MC = 1). Status byte 4 RSB.B1 RCC = 1: Record chain has been processed to the end of the chain (only valid when MC = 1)			
Notes (FHPP)	The CCON.STOP bit stops the active sequence and discards the current motion task. With the bit CPOS.HALT a sequence can be stopped; it can be continued and concluded if CPOS.START is set again.			

Tab. 5/17: Additional parameters for switching to next record



The remaining parameters and sequences reflect the record selection (→ section 5.6.4).

5.6.6 Direct mode: Specification of a position or force

In the status “Operation enabled” a positioning task is formulated directly in the I/O data which are transmitted via the field bus. The setpoint values for position or force/torque are managed in the PLC.

The function is used in the following situations:

- moving to any position.
- the target positions are unknown during planning or change frequently (several different work item positions).

A positioning profile using chained records can be externally implemented by the master.

Procedure for specifying a position

1. The user sets the desired setpoint values into the PLC output data:
CDIR.B1/2: Positioning mode control mode, possibly energy optimised,
CDIR.B0: Setpoint position absolute/relative
FHPP control byte 4: Velocity setpoint value,
FHPP control bytes 5 ... 8: Position setpoint value
2. With a rising edge at START (CPOS.B1) the controller accepts the setpoint position and starts the positioning job.
3. After the start, you must wait for MC (SPOS.B2) before a new start can be made.
4. When the setpoint position is reached, MC is set.

Procedure for specifying a force



Notes on force control

Control of the motor force occurs indirectly via current regulation. All force specifications refer to the rated motor force (relative to the rated motor current). The actual force at the axis should be calculated/checked and then set with external measuring devices during commissioning.

Force control is prepared when the control mode is switched over. The drive stands with the position controlled. The signal MC (Motion Complete) is used in this control mode to mean “Force value reached.”

After the setpoint value has been specified, the force is built up by the start signal (START bit) in the direction of the sign of the setpoint value. The speed is limited to the value in the parameter “Speed limit.” Once this speed has been reached, the bit “Speed limit reached” is set in the status byte SDIR.

When the setpoint value has been reached, taking into account the target window and the time window, the “MC” signal is set. The force continues to be controlled.

If the path set in the path/stroke monitoring (relative to the starting position) is exceeded, the bit “Stroke limit reached” is set in the status byte SDIR. The drive is braked with the emergency stop ramp, held with the position controlled at the current position, and the “MC signal” is set.



The smallest permitted force setpoint value is 30 % of the rated force. If smaller values are specified, these will be raised to 30 %.

5. Commissioning




Fig. 5/6: Start the task



The sequence of the remaining control and status bits as well as the functions HALT and STOP react as with the function Record select, see Fig. 5/3, Fig. 5/4 and Fig. 5/5.

Causes of errors

- No referencing carried out.
- When specifying a position: Target position outside the software end positions.


5. Commissioning

Overview of parameters involved (see section B.4.8)				
	Description	FCT	PNU	CI
Positioning mode	Basic velocity	x	540	21F8h
	Acceleration	x	541	20EE/22h
	Deceleration	x	542	20EF/22h
	Acceleration jerk	x	543	20E7/22h
	Applied load	x	544	20E8/22h
	Deceleration jerk	x	547	21E1/22h
	Damping time	x	1023	20E6/22h
Force control ¹⁾	Stroke limitation	x	510	60F6/01h
	Minimum force (fix 30 % of the rated value)	x	511	60F6/05h
	Maximum force	x	512	6072h
	Force target window (tolerance)	x	552	60F6/03h
	Force damping time in [ms]	x	553	60F6/04h
	Max. permitted speed	x	554	60F6/02h
Start (FHPP)	CPOS.B1 START = positive edge			
Feedback (FHPP)	SPOS.B2 = 0: Motion complete SPOS.B1 = positive edge: Acknowledge start SPOS.B4 = 1: Drive moving			
Prerequisites	Device control by PLC/field bus Controller must be in status “Operation enabled”			
¹⁾ Further parameters:				
6071h	Target torque	6076h	Rated torque	
6077h	Actual torque	6087h	Torque slope	
6088h	Torque profile type	CDIR.B5	Stroke limitation active/inactive	

Tab. 5/18: Parameters involved in Direct mode

5.6.7 Direct mode: Continuous setpoint specification (Continuous Mode)

With continuous setpoint specification (Following mode) the higher level controller continuously specifies position values at fixed time intervals (typically 4 ... 10 ms). Since this time interval is usually longer than a position controller cycle (350 μ s), the controller independently interpolates the values between the specified position values. At every specified interval, the CDIR.B4 CONTT ("Toggle Bit") must be toggled to ensure that any new interval is recognised.



1 Specified interval (PNU 570)

2 Position controller cycle (350 μ s)

Fig. 5/7: Continuous setpoint specification (FHPP Continuous Mode)



Continuous setpoint specification can be used to travel curved paths or for coupling axis motion (use of several axes).

Overview of parameters involved (see section B.4.8)				
Parameters involved	Description	FCT	PNU	CI
	Interpolation time, i.e. the time interval used by the higher level controller for sending position setpoints	–	570	20B6h
Start (FHPP)	CDIR.B3 CONT = 1 CPOS.B1 START = positive edge, must remain set while the setpoint specification is active CDIR.B4 CONTT = 0 <=> 1 (“Toggle Bit”) CCON.B1 STOP stops the setpoint specification. CPOS.B0 HALT has no intermediate stop function and behaves in a similar manner to the CCON.B1 STOP bit. A negative edge at CPOS.B1 START also stops the setpoint specification.			
Feedback (FHPP)	SDIR.B3 CONT = 1			
Prerequisites	Device control by PLC/field bus Controller must be in status “Operation enabled”			

Tab. 5/19: Parameters used for continuous setpoint specification

5.6.8 Standstill monitoring

With the standstill monitoring it is clear that the target position window is exited at a standstill.

When the target position has been reached and MC is signalled in the status word, the drive switches to the “standstill” state and bit SPOS.B6 STILL (standstill monitor) is reset. If, in this status, the drive is removed from the standstill position window for a defined time due to external forces or other influences, the bit SPOS.B6 STILL will be set.

As soon as the drive is in the standstill position window again for the standstill monitoring time, the bit SPOS.B6 STILL is reset.




Fig. 5/8: Standstill monitoring

Standstill monitoring becomes inactive when the standstill position window is set to “0”.

Overview of parameters involved (see section B.4.9)				
Parameter	Description	FCT	PNU	CI
	Setpoint position	–	1040	6062h
	Actual position	–	1041	6064h
	Standstill position window	–	1042	2040h
	Standstill monitoring time	–	1043	2041h
Start (FHPP)	SPOS.B2 = positive edge: Motion Complete			
Feedback (FHPP)	SPOS.B6 = 1: drive has moved out of standstill position window			
Prerequisites	Device control by PLC/field bus Controller must be in status “Operation enabled”			

Tab. 5/20: Parameters involved in standstill monitoring

5. Commissioning

5.6.9 Using hardware enable

Reaction

Controller not enabled

If the controller enable is not set (no ENABLE signal at the controller interface and [HMI = off] on the control panel):

If the hardware enable is missing, the “Power” LED flashes. The SFC-LACI can be parameterised, however, and records the position of the drive.

Controller enabled

If the controller enable is set:

When the hardware enable is removed, the load voltage is switched off.



Caution

If the drive is not under position control after the removal of “Hardware enable”, this may cause injury to people and material damage

- If the hardware enable is removed during a current positioning procedure, then the mass continues to move due to inertia.
- With vertical or sloping drive mountings, the moving mass will then slide down.

Also note:

When the hardware enable is removed, the load voltage is switched off immediately. However, several seconds can pass before the SFC-LACI reports the error “Load Power Down” and a brake closes (if present).

5.6.10 Using the local digital outputs

Purpose	<p>The outputs can be used for the following:</p> <ul style="list-style-type: none">– Displaying an internal logical status of the SFC-LACI, (e.g. occurrence of an error)– Displaying that certain values have been reached (e.g. position values)– Controlling a brake/clamping unit (see section 5.6.11)– Operating a fan, DC motor or similar.
Switching logic	<p>Positive switching logic: when the output is set (switching state true, logic “1”), the output is set to 24 V. If the output is not set, to 0 V (or in Out2 with PWM, to high impedance).</p> <p>Negative switching logic: If the output is set, the output is set to 0 V (or in Out2 with PWM, to high impedance). If the output is not set: to 24 V.</p>
PWM (only Out2)	<p>With pulse-width modulation (PWM), a pulsed signal is output. When using as a brake output, a continuous signal is initially output for 100 ms when the output is set (CI 6510/1Ah).</p>
PWM value	<p>The PWM value is the duty cycle during a period of time (frequency: approx. 20 kHz), in the following diagram, 33 %:</p>




Fig. 5/9: PWM value

Behaviour depending upon pin use

Out1

Standard	When the output is set, a continuous signal (24 V) appears. If the output is not set: 0 V.
Inverted	By “inverting” the output: when the output is set, 0 V applied. If the output is not set: 24 V.

Out2

Signal A – Signal /A	<p>For the connection of the consumer between pin 4 (signal A) and pin 1 (signal /A), i.e. use of the differential output:</p> <p>PWM value 1 ... 100 %: Positive switching logic. If the output is not set, the two pins are highly resistive. Change of polarity due to the output being inverted (exception: when used for brake plus only at pin 4).</p> <p>PWM value 0 %: Always 24 V. Setting/resetting the output causes polarity change. Polarity presetting can be changed by inverting the output.</p>
Signal A – ground	<p>For the connection between pin 4 (signal A) and pin 3 (ground):</p> <p>PWM value 1 ... 100 %: Positive switching logic. If the output is not set, pin 4 is highly resistive. Do not operate inverted.</p> <p>PWM value 0 %: Positive switching logic. If the output is not set, pin 4 is not highly resistive, but at 0 V. Negative switching logic due to the output being inverted.</p>
Signal /A – ground	<p>For the connection between pin 1 (signal /A) and pin 3 (ground):</p> <p>PWM value 1 ... 100 %: Positive switching logic. If the output is not set, pin 1 is highly resistive. Always operate inverted. Cannot be used for a brake since with the parameter setting for brake plus is always at pin 4.</p> <p>PWM value 0 %: Negative switching logic. If the output is not set, pin 4 is not highly resistive, but at 0 V. Positive switching logic due to the output being inverted.</p>

Overview of parameterisation of Out2

Basis settings

The behaviour is set via

- Operating mode of object 2422/01h: Values 1 (brake), 2 (digital signal) or 3 (output compare)
- PWM value of object 2422/0Ah: Values 0 ... 100 %
- Setting “inverted” object 2422/09h:
Value 0 = not inverted, otherwise inverted

Without PWM

Without pulse-width modulation, the following options are available:

1. PWM value 0, operating mode 1 (does not matter whether inverted) – or – operating mode 2 / 3 and not inverted.
If the output is set: $A = 24 \text{ V}$, $/A = 0 \text{ V}$.
If the output is reset: $A = 0 \text{ V}$, $/A = 24 \text{ V}$.
2. PWM value 0, operating mode 2 or 3 and inverted.
If the output is reset: $A = 24 \text{ V}$, $/A = 0 \text{ V}$.
If the output is set: $A = 0 \text{ V}$, $/A = 24 \text{ V}$,
therefore completely the opposite to point 1.

With PWM

When the PWM is not inverted (if the output is set), $A = 24 \text{ V}$, $/A = 0 \text{ V}$ during the active PWM time; in the non-active PWM time, the two pins are highly resistive. If the output is reset, the two pins are highly resistive the whole time.

3. PWM value not equal to 0, operating mode 1, does not matter whether inverted: PWM-modulated brake. In the first 100 ms, PWM value = 100 %, after that the specified value applies.
4. PWM value not equal to 0, operating mode 2 or 3, not inverted: is the PWM-modulated output.
5. PWM value not equal to 0, operating mode 2 or 3, inverted: is the PWM-modulated inverted output. The behaviour is just the same as it is in point 4, only the two output pins are swapped: during the active PWM time, $/A = 24 \text{ V}$, $A = 0 \text{ V}$.

5. Commissioning

Overview of the parameters for the local digital outputs Out1/2				
Parameter / Description		PNU	FCT	CI
Out1/2: Status of the outputs (set/not set)		304	x	60FE/01h
Bit	Value			Display
0	0x00000001			Status Brake
25	0x02000000			Status Out1
26	0x04000000			Status Out2
Out1/2: Mask		304	–	60FE/02h
Bit	Value			Function
25	0x02000000			Activates the display of Out1 in 60FE/01h
26	0x04000000			Activates the display of Out2 in 60FE/01h
Out1: Use		1240	x	2421/01h
Value	Out1 is used as:			
0	No function			
1	Brake output (see section 5.6.11)			
2	“Digital signal display” (see FCT)			
3	“Output/Compare” (see FCT)			
Out1: Setting condition		1241	x	2421/02h
Value	The output is set dependent upon:			
1	Position comparison			
2	Force comparison			
3	Speed comparison			
4	Record number comparison			
10h	Ready			
11h	Motion complete			
12h	Error			
13h	Sample in			
14h	(reserved)			
15h	ON (during setting of this bit, the output is set immediately)			
Out1: Resetting condition (delay: see 2421/08h)		1242	x	2421/03h
Value	The output is reset dependent upon:			
1	Position comparison + delay			
2	Force comparison + delay			
3	Speed comparison + delay			
4	Record number comparison + delay			
10h	Ready + delay			
11h	Motion complete + delay			
12h	Error + delay			
13h	Sample in + delay			
14h	Delay			
15h	OFF (during setting of this bit, the output is reset immediately)			

5. Commissioning

Parameter / Description	PNU	FCT	CI
Out1: Value for setting condition The saved value that when reached means that the comparison condition is considered fulfilled in accordance with 2421/02h. With record number comparison: bit number Δ record number: bit 1 = record 1 (bit 0: do not use). Example: 0x6 = in record1 and also in record2, the condition is considered fulfilled and the output is set.	1243	x	2421/04h
Out1: Value for resetting condition As above, but in accordance with 2421/03h for the resetting condition.	1244	x	2421/05h
Out1: Setting condition rising/falling Value = 0: The output is set if the reference value accrued from lower values has been reached in accordance with 2421/04h. Value = 1: The output is set if the reference value accrued from higher values has been reached in accordance with 2421/04h.	1245	x	2421/06h
Out1: Resetting condition rising/falling Value = 0: The output is reset if the reference value accrued from lower values has been reached in accordance with 2421/05h. Value = 1: The output is reset if the reference value accrued from higher values has been reached in accordance with 2421/05h.	1246	x	2421/07h
Out1: Delay Delay time in [ms] after a resetting condition has occurred. The output is not reset until the delay time has expired (= switch-off delay).	1247	x	2421/08h
Out1: Inverted 0 = not inverted 1 = inverted This setting is not taken into account when the output is used for a brake/clamping unit (see 2421/01h).	1248	x	2421/09h

5. Commissioning

Parameter / Description	PNU	FCT	CI
Out2: Use Value Out2 is used as: 0 No function 1 Brake output (see section 5.6.11) 2 Digital signal display (see FCT) 3 “Output/Compare” (see FCT)	1250	x	2422/01h
Out2: Setting condition Value The output is set dependent upon: 1 Position comparison 2 Force comparison 3 Speed comparison 4 Record number comparison 10h Ready 11h Motion complete 12h Error 13h Sample in 14h (reserved) 15h ON (during setting of this bit, the output is set immediately)	1251	x	2422/02h
Out2: Resetting condition (delay: see 2422/08h) Value The output is reset dependent upon: 1 Position comparison + delay 2 Force comparison + delay 3 Speed comparison + delay 4 Record number comparison + delay 10h Ready + delay 11h Motion complete + delay 12h Error + delay 13h Sample in + delay 14h Delay 15h OFF (during setting of this bit, the output is reset immediately)	1252	x	2422/03h
Out2: Value for setting condition The saved value that when reached means that the comparison condition is considered fulfilled in accordance with 2422/02h. With record number comparison: bit number $\hat{=}$ record number: bit 1 = record 1 (bit 0: do not use). Example: 0x6 = in record1 and also in record2, the condition is considered fulfilled and the output is set.	1253	x	2422/04h
Out2: Value for resetting condition As above, but in accordance with 2422/03h for the resetting condition.	1254	x	2422/05h

5. Commissioning

Parameter / Description	PNU	FCT	CI
Out2: Setting condition rising/falling Value = 0: The output is set if the reference value accrued from lower values has been reached in accordance with 2422/04h. Value = 1: The output is set if the reference value accrued from higher values has been reached in accordance with 2422/04h.	1255	x	2422/06h
Out2: Resetting condition rising/falling Value = 0: The output is reset if the reference value accrued from lower values has been reached in accordance with 2422/05h. Value = 1: The output is reset if the reference value accrued from higher values has been reached in accordance with 2422/05h.	1256	x	2422/07h
Out2: Delay Delay time in [ms] after a resetting condition has occurred. The output is not reset until the delay time has expired (= switch-off delay).	1257	x	2422/08h
Out2: Inverted 0 = not inverted 1 = inverted This setting is not taken into account when the output is used for a brake/clamping unit (see 2422/01h).	1258	x	2422/09h
Out2: PWM value Duty cycle during a period of time. See Fig. 5/9. Values: 1 ... 100 % Value = 0 deactivates the pulse-width modulation	1259	x	2422/0Ah

Tab. 5/21: Parameters for the local digital outputs

5.6.11 Using a brake/clamping unit

One of the local digital outputs (Out1 or Out2) can be used to control a brake/clamping unit. Options here are a continuous signal or, in the case of Out2, both a continuous and a pulsed signal (PWM, see Fig. 5/9).



The parameterisation can easily be carried out via FCT. Note the detailed functional descriptions in the help section for PlugIn SFC-LAC.



Note

When using the DNCE/DFME-...-LAS-...-C clamping unit: The clamping unit may not be closed until the drive is at standstill. It must be opened before a new positioning motion begins.

The clamping unit must not be used to brake moving masses. Braking masses in movement leads to increased wear and to the functional failure of the clamping unit.

5. Commissioning

Overview of parameters when using a brake/clamping unit			
Parameter / Description	PNU	FCT	CI
Out1: Use Value = 1: Out1 is the defined brake output	1240	x	2421/01h
Out2: Use Value = 1: Out2 is the defined brake output	1250	x	2422/01h
Switch-on delay Time in [ms] between setting the enable (ENABLE = 1) or a START signal (if the automatic brake is activated) and the start of a positioning motion. The brake can open completely in this period of time. Values: 0 ... 500 ms	1310	x	6510/17h
Switch-off delay Time in [ms] between the removal of the enable (ENABLE = 0) or the expiry of the activation time of the automatic brake and the switching off of the SFC-LACI's output stage. In this period of time, the SFC-LACI continues to control the position, and the brake can close completely. Values: 0 ... 500 ms	1311	x	6510/18h
Activation time of the automatic brake Time in [s] between the completion of a positioning motion ("Motion Complete") and the resetting of the brake output (providing in this period of time there is no new START signal). The switch-off delay follows after the activation time. Value = 0 deactivates the automatic brake	1312	x	6510/19h
PWM value Duty cycle during a period of time, see Fig. 5/9 Values: 1 ... 100 % Value = 0 deactivates the pulse-width modulation	1259	x	2422/09h
Display of brake status Bit 0 = 1 / 0: The configured brake output is set / not set.	304	x	60FE/01h

Tab. 5/22: Parameters when using a brake/clamping unit




Fig. 5/10: Pulse-time diagram – automatic brake

In this example, both the time for switching to the next record and the activation time of the automatic brake (T Automatic) starts to run after the completion of a positioning record (MC). After the activation time has expired, the brake is closed and the switch-off time runs simultaneously. After the switch-off time has expired, the controller end stage is switched off (less warming).

After the time for switching to next record has expired, there is a new internal START signal, the drive, however, does not start to move until the switch-on delay has expired.

5.6.12 Position sampling (on-the-fly measurement)

A local digital input (IN1 or IN2) not occupied by the reference or limit switch can be used as a fast sample input. With a falling (depending on configuration: a rising) edge at the configured sample input, the current position value is written (in 204A/05h or 06h) into a tab of the SFC-LACI and can afterwards be read out by the higher-level control system (PLC/IPC) (PNU 350 or PNU 351).

Overview of parameters for position sampling (on-the-fly measurement)			
Parameter / Description	PNU	FCT	CI
Input that is going to be used for the position sampling: value = 0: none value = 1: IN1 value = 2: IN2	1305	x	6510/16h
Trigger mode – Value = 1: “cyclic” (continuous) = record position for every rising (depending on configuration: and/or falling) edge – Value = 2: “single” (one-time) = record position only for the first rising (depending on configuration: and/or falling) edge	352	x	204A/01h
Edge status – Value = 0: An edge was not registered. Writing 0 resets both edge events to 0. – Value = 1: A falling edge has occurred and a new position value was stored. – Value = 2: A rising edge has occurred and a new position value was stored. – Value = 3: A rising and a falling edge have occurred, the respective position values were stored.	353	–	204A/02h

5. Commissioning

Parameter / Description	PNU	FCT	CI
Transfer edge status to FHPP status byte SPOS and status word (CI object 6041h) <ul style="list-style-type: none"> Value = 0: If an edge occurs (see subindex 02h), this event is not displayed in the status word. Writing 0 resets bit 14 to 0 in the status word. Value = 1: If a rising edge occurs (see subindex 02h), bit 14 is set in the status word. Value = 2: If a falling edge occurs (see subindex 02h), bit 14 is set in the status word. Value = 3: If a rising or a falling edge occurs (see subindex 02h), bit 14 is set in the status word. <p>With field bus: Display in SPOS.B3 TEACH – If the corresponding values are set, bit 3 in the FHPP status byte SPOS no longer displays the teach status, but the sampling status.</p>	354	–	204A/03h
Control byte sampling <ul style="list-style-type: none"> Value = 0: No reaction to edges. Writing value = 0: switch off position sampling Value = 1: The SFC-LACI reacts to falling edges. In trigger mode “single”: writing value = 1 resets the status (subindex 02h) of a falling edge and allows a position to be recorded again. Value = 2: The SFC-LACI reacts to rising edges. In trigger mode “single”: writing value = 2 resets the status (subindex 02h) of a rising edge and allows a position to be recorded again. Value = 3: The SFC-LACI reacts to rising edges and to falling edges. In trigger mode “single”: writing value = 3 resets the status (subindex 02h) of all edges and allows a position to be recorded again. 	355	x	204A/04h
Position value for a rising edge in [increments]	350	–	204A/05h
Position value for a falling edge in [increments]	351	–	204A/06h

Tab. 5/23: Parameters for position sampling (on-the-fly measurement)

5.7 Notes on operation



Warning

Danger of injury

Electric axes can move suddenly with high force and at high speed. Collisions can lead to serious injury to human beings and damage to components.

- Make sure that nobody can reach into the operating range of the axes or other connected actuators (e.g. with a protective grille) and that no objects lie in the positioning range while the system is still connected to a power supply.



Caution

Not using the parameterising interface as designated causes injury to people and material damage

The parameterising interface (RS232) is

- not electrically isolated and
- not real-time capable.

It is not intended for permanent connection to PC systems or as a controller interface.

Controlling the SFC-LACI via RS232 requires, among other things, a risk assessment by the user, ambient conditions free of interference and reliability of data transmission e.g. via the control program of the higher-order control system.

- Note that control of the SFC-LACI via the RS232 does not comply with designated use.
- Use the connection only for parameterising, commissioning and diagnosis.

5. Commissioning



Caution

Errors in the parameterisation can cause injury to people and material damage if you enable the controller with ENABLE.

- Make sure that there is no active ENABLE signal when switching on the SFC-LACI on the controller interface.
- Parameterise the entire system completely before activating the controller with ENABLE or [HMI = on].



Caution

The SFC-LACI does not carry out any positioning tasks if it is not referenced. In the following cases, carry out a homing run to reference the SFC-LACI:

- **Every time** the logic voltage supply is connected (or after every failure).
- When the homing method is changed.
- When the axis zero point is modified.



Note

When setting ENABLE for the first time after switch-on (or when activating the device control on the control panel for the first time using [HMI: on]), the SFC-LACI carries out a commutation point search (the drive vibrates gently). If the drive is not freely movable and the commutation point search cannot be performed successfully, then an error is reported and the SFC-LACI will not carry out a homing run or any positioning tasks.

- Make sure that the drive can move freely when ENABLE is set.

5. Commissioning



Note

Damage to components

Movement to the mechanical end positions is not permitted during operation.



Note

Observe the instructions in the documentation for the drives and additional components used.

Password protection

The factory setting does not provide active protection by a password. All download and control functions can be blocked in order to prevent unauthorised or unintentional overwriting or modification of parameters in the device.

- Recommendation:
Protect your settings against undesired modifications with a password:
 - FCT password protection (8 characters, see SFC-LAC Plugin help)
 - HMI password protection on the control panel of the SFC-LACI-...-H2-... (3 characters, see section 4.5)

Service and maintenance

The motor controllers of type SFC-LACI-... are maintenance-free within the service life specified. However, follow the maintenance instructions for the additional components.

Diagnosis and fault display

Chapter 6

Contents

6.1 Diagnostics options 6-3

6.2 LED status displays 6-5

6.3 Error messages 6-7

6.4 Diagnostics via field bus 6-14

 6.4.1 Overview 6-14

 6.4.2 Diagnostic memory 6-15

6.5 Diagnosis via parameter channel (FPC) 6-17

6.6 Warning “Index pulse warning” 6-18

6. Diagnosis and fault display

6.1 Diagnostics options

Overview organised according to the type of the diagnostic information:

Type of diagnostic information	Access via ...	See ...
General status display	LEDs on the SFC-LACI	Section 6.2
	FCT: virtual LEDs in the “Device status” window	Help for PlugIn
	FHPP status bytes SCON and SPOS	Section 5.5.2
The current error message in plain text	Control panel of the SFC-LACI (only type ...-H2)	Section 6.3
	FCT: Text field in the “Device status” window	Help for PlugIn
	DeviceNet class 108 “System diagnosis” (PNU 205, 207, 208, 209, 215)	Sections B.1.1 and B.4.5
Diagnostic memory: the last 16 messages	FCT: in the “Diagnosis” window (with existing device connection)	Help for PlugIn
	FPC: The second 8 bytes of the cyclic field bus communication can transfer the contents of the diagnostic memory	Sections B.2.1 and 6.4.2
	DeviceNet classes 101/102	Sections B.1.1 and B.4.5
Parameterising	Control panel: in the [Diagnosis] menu	Section 4.3
	FCT	Help for PlugIn

Tab. 6/1: Diagnostic information according to type

6. Diagnosis and fault display




Overview organised according to the type of access to the diagnostic information

Access	Brief description	Advantages / features	Detailed description
LEDs	The LEDs indicate the readiness to operate, positioning status, errors and bus status	Fast “on-the-spot” recognition of errors	Section 6.2
Control panel of an SFC-LACI-...-H2	On the LCD display: Messages, warnings and errors	Fast “on-the-spot” diagnosis	Section 6.3
	In the [Diagnostic] menu: Diagnostic data, operating mode, current position set, target and actual positions, speed as well as information on communication via the field bus	Detailed “on-the-spot” diagnosis	Section 4.3
Festo Configuration Tool	With active device connection: – Display of the current position set, target and actual positions as well as speed. – Display of the operating mode, special outputs and operating states as well as error messages of the SFC-LACI – Display of the bus status – Display of the diagnostic memory	Detailed diagnosis during commissioning	Help for PlugIn SFC-LACI
Field bus	Diagnosis via FHPP status bytes SCON and SPOS	Simple diagnosis via the field bus	Section 5.5.6
	Extended access to diagnostic data, e. g. diagnostic memory	Detailed diagnosis via the field bus	Section 6.4.2

Tab. 6/2: Diagnostic information as per access




6.2 LED status displays

Voltage supply

POWER	Status
 Green	Logic and load voltages applied
 Flashing	Logic voltage is present Load voltage is not present or missing hardware enable
 Off	There is no voltage

Tab. 6/3: LED “Power”













Malfunction indicator

ERROR	Status
 Red	Error The SFC-LACI is not ready for operation
 Flashing	Warning Check cause and rectify if necessary; see section 6.3
 Off	No internal malfunction indicated

Tab. 6/4: LED “Error”


6. Diagnosis and fault display

Bus status

I/F		Bus status ¹⁾	
	ON OFF 	Off	The device is not online. The Dup_MAC_ID test is not yet concluded. Possibly missing logic voltage.
	ON OFF 	Flashes green ²⁾	The Dup_MAC_ID test has been successfully concluded, and the device is online. But the device is not yet assigned to a master.
	ON OFF 	Green	The device is online and assigned to a master
	ON OFF 	Flashes red ²⁾	For at least one I/O connection, the time was exceeded (status "Timed Out")
	ON OFF 	Red	A critical error has occurred (duplicate MAC-ID or bus switched off)
	ON OFF 	Flashes red and green ³⁾	The device has ascertained a network access error and is in the status "Communication Failed". In addition, the device received and answered a communication fault request ("Identify Communication Faulted Request – Long Protocol").
<p>¹⁾ Display as per DeviceNet specification During start-up, the LED is switched off when valid bus parameters are present; otherwise, there is a message in the control panel display.</p> <p>²⁾ Flashing frequency 1 Hz</p> <p>³⁾ Flashing frequency 2 Hz, i.e. colour changes every 250 ms without going dark</p>			

Tab. 6/5: "I/F" LED

6.3 Error messages



Malfunctions can have different levels of severity. A warning or a fault message is displayed depending on the level of severity.

Messages

Messages inform about operating states.

Message	Cause
Attention Motor moves...	Message before the start of a positioning movement. After confirmation with the <Enter> button, the drive moves.
Please wait! Commut. Point evaluation is active	The commuting point is being sought. The drive vibrates for a few seconds.

6. Diagnosis and fault display

Warnings

Warnings have no influence on the behaviour of the drive.
The cause of the warning should be eliminated in order that it does not lead to a malfunction.
If a warning occurs, the error LED will flash and the SCON.B2 WARN output will be set (FHPP status bits, see section 5.5.2).

Warning	Cause	PNU 215	Fault no. *)
INDEX PULSE WARNING	During homing: The homing switch signal lies too close to the index pulse. In some cases this can mean that no reproducible reference position can be determined. <ul style="list-style-type: none">• See section 6.6	0x0001	84
WARNING MOTOR COLD	Temperature of the linear motor < -10 °C Increase the ambient temperature as appropriate.	0x0002	108
WARNING MOTOR HOT	Temperature of the linear motor 70 ... 75 °C Check for possible overloading of the drive; check the mechanical system, e.g. for sluggishness; reduce ambient temperature.	0x0004	109
WARNING SFC-LACI COLD	Temperature < -10 °C	0x0008	74
WARNING SFC-LACI HOT	Temperature 80 ... 85 °C	0x0010	75
STANDSTILL WARNING	The axis has moved outside the standstill tolerance window	0x0020	36
ILLEGAL RECORD WARNING	Impermissible record number	0x0040	3
*) Fault number in the diagnostic memory, see section 6.4.2.			

6. Diagnosis and fault display

Error messages

The drive is stopped in the event of an error. The fault LED is illuminated, the output SCON.B3 FAULT is set.

1. Rectify the cause of the error.
2. Acknowledge the error message:
 - Using <Enter> on the control panel.
 - Using the “Acknowledge Error” button in the FCT.
 - via the field bus with a rising edge of the RESET signal CCON.B3 or with a falling edge of the ENABLE signal.



Caution

If the drive is not under position control after the removal of ENABLE, this may cause injury to people and material damage

- With vertical or sloping drive mountings, the moving mass might slide down; see section 1.1.3.

Error	Possible cause and remedy	PNU	Fault no. *)
PLEASE ENFORCE HOMING RUN	When starting a positioning record Possible causes: <ul style="list-style-type: none"> – Valid homing run has not yet been carried out – Due to a logic voltage failure the reference position has been lost <ul style="list-style-type: none"> • Carry out a homing run 	PNU 205 0x0200	1
TARGET POSITION OUT OF LIMIT	The specified target position is outside the permitted positioning range <ul style="list-style-type: none"> • Check software end positions, target position and reference (absolute or relative) 	PNU 205 0x0800	2
INTERPOLATION CYCLE TIME	For FHPP Continuous Mode: missing position specification(s) or missing toggle bit	PNU 208 0x0001	7
LIMIT SWITCH ACTIVATED	A limit switch has been actuated <ul style="list-style-type: none"> • Check the positioning dynamics (overswing?), e.g. using trace diagrams in the FCT • Check switches and cables 	PNU 208 0x004	8

*) Fault number in the diagnostic memory, see section 6.4.2.

6. Diagnosis and fault display

Error	Possible cause and remedy	PNU	Fault no. ^{*)}
BLOCK DURING JOG MODE	A fixed stop was reached in job mode	PNU 208 0x008	9
POSITION ERROR	Drag error. Possible causes: – The drive is blocked – Speed, acceleration or jerk is too great	PNU 205 0x0400	31
HOMING ERROR	Error during homing Possible causes: – Homing run interrupted – Reference switch defective • If necessary, check the function of the reference switch • Repeat the homing run • Contact Festo service	PNU 205 0x0100	32
POSITION PLAUSIBILITY ERROR	Error while searching for the commutation point. • Acknowledge the error. The search is restarted. – If several drives are fitted in a vibration-free system: Carry out commutation point search one after the other (see PNU 1072 / 2051h).	PNU 205 0x4000	40
*) Fault number in the diagnostic memory, see section 6.4.2.			

6. Diagnosis and fault display

Error	Possible cause and remedy	PNU	Fault no. *)
COMMUTATION POINT ERROR	<p>Commutation point is invalid. Possible cause and remedy:</p> <ul style="list-style-type: none"> – The drive is blocked: Ensure freedom of movement. – Excessive load: Reduce the load. – Controller parameter wrongly set: Determine the relevant controller parameter and set it to the correct value. To do this, you may have to perform a commutation point search without a load (remove the load, correctly set the tool mass and applied load), start the axis, connect the load (correctly set the tool mass and applied load), determine the new controller parameters (see FCT help on controller parameterisation), reparameterise the drive and then restart the commutation point search with new controller parameters. – The drive remains directly at a hard end stop. Vibration motion is therefore not possible in the direction of the end stop. The following conditions are necessary in order to find the commuting point: Cushion the end points / make them soft (e.g. rubber bumper). – The axis is not fastened stiffly enough: Stiffen the axis mounting. – The effective load is not fastened stiffly enough on the axis: Stiffen the load mass mounting. – Effective load can vibrate: Form stiffer load; modify intrinsic frequency of the load. – If several drives are fitted in a vibration-free system: Carry out commutation point search one after the other (see PNU 1072/2051h). <p>Contact the Festo service department if these measures do not produce the desired results.</p>	PNU 205 0x8000	41
HARDWARE ERROR SFC-LACI	<p>Device fault SFC-LACI, e.g. EEPROM defective</p> <ul style="list-style-type: none"> • Contact Festo service 	PNU 205 0x0001	51
LOAD-POWER-DOWN	<p>Load voltage < 36 V or missing hardware enable</p> <ul style="list-style-type: none"> – Voltage drops under load: Power supply too weak, cable too long, cable cross-section too small? – Hardware enable connection, see section 3.2 	PNU 205 0x0080	70
*) Fault number in the diagnostic memory, see section 6.4.2.			

6. Diagnosis and fault display

Error	Possible cause and remedy	PNU	Fault no. *)
DIGITAL-POWER-DOWN	Logic voltage < 15 V – Voltage drops under load: Power supply too weak, cable too long, cable cross-section too small?	PNU 205 0x0040	71
OVERCURRENT POWER STAGE	Output stage current consumption too high, e.g. due to short circuit. • Contact Festo service	PNU 208 0x002	72
ERROR SFC-LACI HOT	Temperature > 85 °C • Remain within all maximum values and check the mechanical system, e.g. for sluggishness • Reduce the ambient temperature • Improve the heat dissipation	PNU 205 0x0020	73
ELGO SENSOR / COMMUNICATION ERROR	Position sensor faulty • Contact Festo service	PNU 205 0x0004	82
CAN COMMUNICATION ERROR	CAN communication fault • Contact Festo service	PNU 205 0x0002	83
I ² t-ERROR	Current monitoring I ² t Possible cause: The drive is blocked, load/dynamics too high. • Check the drive mechanics • Reduce load/dynamic response; increase the pause times	PNU 205 0x1000	100
ERROR MOTOR HOT	Temperature of the linear motor > 75 °C • Remain within all maximum values and check the mechanical system, e.g. for sluggishness • Reduce the ambient temperature • Improve the heat dissipation	PNU 205 0x0010	101
MOTOR STOP ERROR	The positioning procedure is discontinued on the control panel with EMERG.STOP (<Menu> button) • Acknowledge the error	PNU 205 0x2000	106
HARDWARE ERROR DRIVE	Wire break on temperature sensor • Contact Festo service	PNU 205 0x0008	107

*) Fault number in the diagnostic memory, see section 6.4.2.

6. Diagnosis and fault display

Error	Possible cause and remedy	PNU	Fault no. *)
DeviceNet Init Parameter	Incorrect configuration of the bus parameters	PNU 207 0x0001	121
CAN_BUS_OFF	The CAN controller has detected a switched-off bus	PNU 207 0x0010	122
RX_QUEUE_OVERRUN	More PDOs were received than could be processed (stack fault)	PNU 207 0x0004	123
TX_QUEUE_OVERRUN	Not all the PDOs to be sent could be sent: Bus load too high? (stack fault)	PNU 207 0x0008	
CAN_CONTROLLER_QUEUE_OVERRUN	CAN controller fault	PNU 207 0x0020	
DUP_MAC_ERROR	Double MAC ID recognized	PNU 207 0x0002	124
DN_RESET	DeviceNet has been reset	PNU 207 0x0040	
BUS_SENSE_ERROR	Faulty bus supply	PNU 207 0x0080	122
*) Fault number in the diagnostic memory, see section 6.4.2.			

Tab. 6/6: Fault messages

6. Diagnosis and fault display

6.4 Diagnostics via field bus

6.4.1 Overview

- FHPP status bytes (see section 5.5.2)
 - SCON.B2 WARN – Warning
 - SCON.B3 FAULT – Fault
 - SPOS.B5 DEV – Drag error
 - SPOS.B6 STILL – Standstill monitoring
- DeviceNet classes:

DeviceNet class			INST ¹⁾	ATTR	PNU ²⁾	See...
101 (65h)	Diagnosis memory	Diagnostic event	01h ... 10h	01h	200	Sections 6.4.2, B.4.5
		Fault number	01h ... 10h	02h	201	
		Time stamp	01h ... 10h	03h	202	
102 (66h)	Diagnostic memory administration	<ul style="list-style-type: none">- Record faults- Resolution- Clear buffer- Number of entries	<ul style="list-style-type: none">01h01h01h01h	<ul style="list-style-type: none">01h02h03h04h	204	Section B.4.5
108 (6Ch)	Current faults	Device faults	01h	01h	205	Section B.4.5
		Warnings	01h	02h	215	
		Extended device faults	01h	0Ah	207	
			01h	0Bh	208	
109 (6Dh)	Field bus diagnosis	<ul style="list-style-type: none">- Bus status- Current baud rate- Current MAC ID- Current I/O data length	<ul style="list-style-type: none">01h01h01h01h	<ul style="list-style-type: none">01h02h04h05h	206	Section B.4.5
¹⁾ Access via Explicit Messaging						
²⁾ Access via I/O Messaging (FHPP-FPC)						

Tab. 6/7: Diagnosis via field bus: DeviceNet classes

6. Diagnosis and fault display

6.4.2 Diagnostic memory

The diagnostic memory contains the last 16 diagnostic messages. It is backed up if possible in the event of power failure. If the memory is full, the oldest element will be overwritten (ring buffer).

Structure of the diagnostic memory				
Parameters ¹⁾	PNU 200 (20C8 _h)	PNU 201 (20C9 _h)	PNU 202 (20CA _h)	PNU 203 (20CB _h)
Format	uint8	uint16	uint32	uint32
Meaning	Diagnostic event	Fault number	Time stamp	Cycle number
Subindex 1	Current diagnostic message			
Subindex 2	Previous diagnostic message			
...	...			
Subindex 16	Oldest diagnostic message			
¹⁾ See section B.4.5				

Tab. 6/8: Diagnostic memory: structure

Configuration of diagnostic memory with PNU 204/(20CCh)				
SI	Description	Specifi- cation	Min.	Max.
1	= 1: Record incoming and outgoing ^{*)} faults = 2: Record only incoming faults ^{*)} Outgoing fault = Acknowledge the fault	1	1	2
2	= 1: Resolution time stamp 10 ms = 2: Resolution time stamp 1 ms	1	1	2
3	Deleting the diagnostic memory – Writing with value = 1 deletes the diagnostic memory. – Read will always reply with value = 1.	0	0	1
4	Read the number of entries in the diagnostic memory	0	0	16

Tab. 6/9: Diagnostic memory: configuration

6. Diagnosis and fault display

The faults are divided into logical groups according to the fault numbers.

Group	Name	Comment
0	–	No fault active
1 ... 19	Processing error	Examples: No homing run, setpoint position outside software end positions, setpoint value calculation not possible. Although the system is OK, a user command cannot be processed. In most cases there is an error in operation. Source: Sequence control, controller
20 ... 29	Parameter error	Example: Software end positions outside the working stroke. A parameter lies within the limit values so that it can be written by the user. During the new calculation of the controller, it was ascertained that it is not permitted in the context of the other parameters. Note: Non-permitted parameters are rejected by the parameter protocol and do not generate a fault in the controller
30 ... 49	Controller	Examples: Positioning timeout, homing run not successful, drag error too large, ... The task could not be processed correctly. No hardware fault is recognized here. Source: controller
50 ... 69	Initialisation	Error in initialising the controller
70 ... 79	Run time of controller	Error in controller run time: undervoltage, checksum
80 ... 89	–	Reserved
90 ... 99	–	Reserved
100 ... 109	Run time of motor	Run time of motor: undervoltage, overtemperature, etc.
110 ... 119	–	Reserved
120 ... 139	Field bus fault	e. g. baud rate fault

Tab. 6/10: Overview of fault numbers



A detailed description of the faults is provided in section 6.3.

6.5 Diagnosis via parameter channel (FPC)

The Festo parameter channel offers the following possibilities of access to diagnostic information:

Diagnosis	PNU	Section
Diagnosis memory	– PNU 200 ... 204	Compare sections B.4.5 and 6.4.2
Error	– PNU 205 (2FF1h) – PNU 207 (2FFAh) – PNU 208 (2FFBh) – PNU 209 (2FFCh)	Compare sections B.4.5 and 6.3
Warnings	– PNU 215 (2FF2h)	Compare sections B.4.5 and 6.3
DeviceNet diagnosis	– PNU 206 (2FF4h)	Compare section B.4.5

6.6 Warning “Index pulse warning”

In the homing run to the proximity sensor, the drive initially moves into the switching range of the sensor and then reverses. After the switching range is exited, the SFC-LACI searches for the nearest index pulse. This applies as the homing point.



Note


Material damage due to moved measuring reference system

The following situation arises if the switching point of the proximity sensor and the index pulse lie very close to one another: Should the switching point move (e.g. due to temperature influence) such that it then lies behind the index pulse, then the SFC-LACI will use the index pulse after that as a reference point. The entire measuring reference system would then be offset by 2 mm in DFME-...-LAS, in DNCE-...-LAS: by 5 mm.

Remedy:

1. Check the distance of the switching point to the index pulse: See FCT, “Homing” page, “Homing” register (or CI 2FFE/0Dh, see appendix B).
2. Then move the proximity sensor a few tenths of a mm.

- 1 Switching range of the proximity sensor
- 2 Index pulses (every 2 or 5 mm)
- 3 Recommended position: in the centre between two index pulses



Technical appendix

Appendix A

Contents

A.1 Technical data A-3

A.2 Accessories A-5

A.3 Converting the units of measurement A-6

A.1 Technical data

General	
Protection class of the entire system according to EN 60529	IP54 (plug connector inserted or fitted with protective cap)
Relative air humidity (at 25 °C)	0 ... 95 %, non-condensing
Temperature range	Operation: 0 ... +40 °C Storage/transport: -20 ... +60 °C
SFC-LACI temperature monitoring	Warning message at temperature > 80 °C Shutdown at temperature > 85 °C (restart only when temperature falls below 80 °C)
Electromagnetic compatibility (EMC) ¹⁾ (interference immunity and interference emission)	See declaration of conformity (www.festo.com)
Vibration	As per DIN EN 60068, part 2-6: 0,15 mm travel at 10 ... 58 Hz 2 g acceleration at 60 ... 150 Hz
Shock	As per DIN EN 60068, part 2-27: ±15 g at 11 ms duration 5 shocks per direction
Mounting	Wall or DIN H-rail mounting
Dimensions	Approx. 247 x 120 x 66 mm (without plug)
Product weight	Approx. 1500 g
¹⁾ The component is solely intended for use in industrial environments.	

Electrical data	
Load voltage supply – Nominal voltage – Nominal current (max. continuous motor current) – Peak current	Power connection, pins A1, A2) 48 VDC (+5/-10 %) (Load power down: ≤ 36 V) 10 A 20 A
Logic voltage supply – Nominal voltage – Nominal current	Power connection, pins 1, 2 24 VDC ±10 % 3.8 A (when using the local digital outputs, see section 3.2)
Protection against electric shock (protection against direct and indirect contact as per IEC/DIN EN 60204-1)	By means of PELV power circuit (Protected Extra-Low Voltage)
Parameterising interface specification	RS232, 38400 Baud, see chapter 3.5

DeviceNet data	
Version – Physical layer – Data link layer	As per ISO 11898 (corresponds to DS102) As per CAN specification 2.0
DeviceNet specification	As per IEC 62026 and EN 50325 “Predefined connection set: Group 2 slave only”
Manufacturer ID	“Festo Corporation” 26 (0x1A)
DeviceNet device type	“Communication adapter” (0x0C / 12)
Product code	9011
Address range (MAC ID)	0 ... 63
Baud rate	125, 250, 500 kBaud
Interface – Plug connector – Electrical isolation – Integrated bus terminal	Sub-D 9-pin, plug Yes No
Cable type	Depends on length of cable and field bus baud rate, see controller manual

A.2 Accessories

Connection	Cable/Plugs	Type	Length [m]
Controller interface	Field bus plug	FBS-SUB-9-BU-2x5POL-B (IP54) FBS-SUB-9-WS-CO-K (IP20)	–
	Field bus adapter	FBA-2-M12-5POL (IP54) FBA-1-SL-5POL (IP20)	–
Voltage supply	Power supply cable	KPWR-MC-1-SUB-15HC-...	2.5 / 5 / 10
Motor	Motor cable	NEBM-T1G6-T1G6-...	2.5 / 5 / 10
	Encoder cable	NEBM-T1G12-T1G12-...	2.5 / 5 / 10
Parameterising interface	Programming cable	KDI-MC-M8-SUB-9-...	Fix 2.5

Protective caps	Type	Comment
Protective caps for the parameterising interface and the local digital inputs and outputs	ISK-M8	10 items per bag

Wall mounting	Type	Comment
2 sets of central supports (4 brackets)	MUP-8/12	2 items per bag
Wall mounting requires 4 additional M3 screws with cylindrical head		

H-rail mounting
Recommended: On a DIN mounting rail in accordance with EN 50022: width 35 mm, height 15 mm

User's manual	
German	GDCP-SFC-LACI-DN-DE
English	GDCP-SFC-LACI-DN-EN
French	GDCP-SFC-LACI-DN-FR
Italian	GDCP-SFC-LACI-DN-IT
Spanish	GDCP-SFC-LACI-DN-ES
Swedish	GDCP-SFC-LACI-DN-SV

A.3 Converting the units of measurement

The CI interface works with increments [Inc, Inc/s, Inc/s², Inc/s³].

DNCE-...-LAS

The distance between two index lines (= north or south pole of the magnetic displacement encoder) is **5 mm**. The resolution of the measurement system is 11 bits, which is the same as 2048_d (800_h) increments. The increments are calculated by means of interpolation. This results in the following conversions (all figures are decimal):

[Inc] → [mm]

$$\text{mm} = \frac{x \text{ Inc}}{2048 \text{ Inc}} \times 5 \text{ mm}$$

[mm] → [Inc]

$$\text{Inc} = \frac{x \text{ mm}}{5 \text{ mm}} \times 2048 \text{ Inc}$$

DFME-...-LAS

The distance between two index lines (= north or south pole of the magnetic displacement encoder) is **2 mm**. The resolution of the measurement system is 11 bits, which is the same as 2048_d (800_h) increments. The increments are calculated by means of interpolation. This results in the following conversions (all figures are decimal):

[Inc] → [mm]

$$\text{mm} = \frac{x \text{ Inc}}{2048 \text{ Inc}} \times 2 \text{ mm}$$

[mm] → [Inc]

$$\text{Inc} = \frac{x \text{ mm}}{2 \text{ mm}} \times 2048 \text{ Inc}$$

Parametrizing via field bus

Appendix B

Contents

B.1 Parameterising via Explicit Messaging B-3

 B.1.1 DeviceNet Classes B-3

 B.1.2 Parameter overview (class, attribute, instance) B-4

B.2 Parameterisation via FPC B-15

 B.2.1 Structure of the Festo Parameter Channel (FPC) B-15

 B.2.2 Task identifiers, response identifiers and error numbers B-17

 B.2.3 Rules for job reply processing B-20

 B.2.4 Example of parameterising via FPC B-22

B.3 FHPP finite state machine B-24

 B.3.1 Create readiness to operate B-26

 B.3.2 Positioning B-27

B.4 Reference FHPP Parameters B-30

 B.4.1 FHPP parameter groups B-30

 B.4.2 Overview of parameter numbers (PNU) B-31

 B.4.3 Representation of the parameter entries B-40

 B.4.4 Device data B-41

 B.4.5 Diagnosis B-48

 B.4.6 Process Data B-55

 B.4.7 Positioning record table (Record list) B-65

 B.4.8 Project data B-79

 B.4.9 Axis parameters for electric drives 1 B-88

 B.4.10 Supplementary objects B-101

B. Parametrizing via field bus

B.1 Parameterising via Explicit Messaging

B.1.1 DeviceNet Classes

Class	CLASS ¹⁾	Description
Device Data	100 (0x64)	Device identification and device-specific settings, version numbers, identifier words, control panel polling, etc.
Diagnosis Buffer	101 (0x65)	Memory for diagnostic events: Fault numbers, fault time, incoming/outgoing event
Diagnosis Buffer Administration (diagnosis buffer management)	102 (0x66)	Administration of the diagnostic memory
Process Data	103 (0x67)	Current nominal and actual values, local I/Os, status data, record numbers, etc.
Record Sets (record list)	104 (0x68)	A record contains all the nominal value parameters required for a positioning procedure
Project Data	105 (0x69)	Basic project settings. Maximum speed and acceleration, offset project zero point etc. → Parameters are the basis for the record list.
Factor Group	106 (0x6A)	Reserved
Axis Data	107 (0x6B)	All axis-specific parameters for electric drives. Gear factor, feed constant, reference parameter, etc.
System Diagnosis	108 (0x6C)	Reading or deleting the current device malfunction
Fieldbus Diagnosis	109 (0x6D)	Current connection status and field bus settings, e. g. baud rate, I/O data length
¹⁾ Class number as per DeviceNet specification		

Tab. B/1: DeviceNet Classes

B. Parametrizing via field bus


B.1.2 Parameter overview (class, attribute, instance)

Explicit Messaging

The following tables contain all defined parameters with indication of the Class (CLS), Attribute (ATTR) and Instance (INST) for access via “Explicit Messaging”.

FPC

For access via FPC (within the cyclic I/O data), the FHPP parameter number (PNU with subindex) is used.



A detailed description of the parameters can be found under the specified FHPP parameter numbers PNU in the sections B.4.4 to B.4.10.

Device Data				FHPP		
Class 100 (0x64)		CLS	ATTR	INST	PNU	SI
Manufacturer Hardware Version BCD		100	1	1	100	0
Manufacturer Firmware Version BCD		100	2	1	101	0
Version FHPP		100	3	1	102	0
Version FCT PlugIn	PlugIn Min. BCD	100	4	1	104	1
	PlugIn Opt. BCD	100	5	1	104	2
Controller Type		100	6	1	115	0
Controller Serial Number		100	8	1	114	1 ... 12
Manufacturer Device Name		100	9	1	120	1 ... 30
User Device Name		100	10	1	121	1 ... 25
Drive Manufacturer		100	11	1	122	1 ... 30
HTTP Drive Catalog Address		100	12	1	123	1 ... 30
Festo Order Number		100	13	1	124	1 ... 30
Device Control		100	14	1	125	0

B. Parametrizing via field bus

Device Data					FHPP	
Class 100 (0x64)		CLS	ATTR	INST	PNU	SI
HMI Parameter	LCD Current	100	15	1	126	1
	LCD Contrast	100	16	1	126	2
	Measure	100	17	1	126	3
	Scaling Factor	100	18	1	126	4
Data Memory Control	Delete EEPROM	100	20	1	127	1
	Save Data	100	21	1	127	2
Supported Drive Modes		100	45	1	112	0
Version Axis Interface		100	60	1	106	0

Diagnosis Buffer					FHPP	
Class 101 (0x65)		CLS	ATTR	INST	PNU	SI
Diagnosis	Diagnostic Event	101	1	01h ... 10h	200	1 ... 16
Diagnosis	Fault Number	101	2	01h ... 10h	201	1 ... 16
Diagnosis	Time Stamp	101	3	01h ... 10h	202	1 ... 16
Diagnosis	Additional Information	101	4	01h ... 10h	203	1 ... 16

Diagnosis Buffer Administration					FHPP	
Class 102 (0x66)		CLS	ATTR	INST	PNU	SI
Diagnostic Memory Parameter	Fault Type	102	1	1	204	1
	Resolution	102	2	1	204	2
	Clear Memory	102	3	1	204	3
	Number of Entries	102	4	1	204	4

B. Parametrizing via field bus

Process Data					FHPP	
Class 103 (0x67)		CLS	ATTR	INST	PNU	SI
Position Monitoring	Actual Position	103	1	1	300	1
	Demand Position	103	2	1	300	2
Torque/Force Monitoring	Actual Torque	103	4	1	301	1
	Target Torque	103	5	1	301	2
Digital Inputs		103	10	1	303	0
Digital Output	Local Digital Outputs	103	20	1	304	1
	Mask	103	21	1	304	2
Cycle Number		103	30	1	305	0
Record Number	Record Number	103	32	1	400	1
	Active Record	103	33	1	400	2
	Record Status Byte	103	34	1	400	3
Velocity Monitoring	Actual Velocity	103	36	1	310	1
	Demand Velocity	103	37	1	310	2
Motor Data – Actual Power		103	40	1	1054	0
FHPP Continuous Mode: Interpolation Time		103	48	1	570	0
FHPP Status Data	Status Data (Byte 1 ... 4)	103	60	1	320	1
	Status Data (Byte 5 ... 8)	103	61	1	320	2
FHPP Control Data	Control Data (Byte 1 ... 4)	103	62	1	321	1
	Control Data (Byte 5 ... 8)	103	63	1	321	2
Control Word		103	70	1	330	0
Status Word		103	71	1	331	0
Operation Mode		103	72	1	332	0
Operation Mode Display		103	73	1	333	0

B. Parametrizing via field bus

Process Data					FHPP	
Class 103 (0x67)		CLS	ATTR	INST	PNU	SI
Switches	Limit Switch Polarity	103	74	1	1300	0
	Limit Switch Selector	103	75	1	1301	0
	Homing Switch Selector	103	76	1	1302	0
	Homing Switch Polarity	103	77	1	1303	0
	Limit Switch Deceleration	103	78	1	1304	0
Sample Input		103	79	1	1305	0
Brake Delay Time Switch ON		103	80	1	1310	0
Brake Delay Time Switch OFF		103	81	1	1311	0
Automatic Brake Time		103	82	1	1312	0
Sample Switch Polarity		103	84	1	1306	0
Position Sampling	Trigger Mode	103	96	1	352	0
	Status	103	97	1	353	0
	Status Mask	103	98	1	354	0
	Control Byte	103	99	1	355	0
	Position Rising Edge	103	100	1	350	0
	Position Falling Edge	103	101	1	351	0

B. Parametrizing via field bus

Process Data					FHPP	
Class 103 (0x67)		CLS	ATTR	INST	PNU	SI
Local Digital Output 1 (DOUT1)	Function	103	112	1	1240	0
	Trigger ON	103	113	1	1241	0
	Trigger OFF	103	114	1	1242	0
	Value ON	103	115	1	1243	0
	Value OFF	103	116	1	1244	0
	Direction Value ON	103	117	1	1245	0
	Direction Value OFF	103	118	1	1246	0
	Delay	103	119	1	1247	0
	Inverted	103	120	1	1248	0
Local Digital Output 2 (DOUT2)	Function	103	128	1	1250	0
	Trigger ON	103	129	1	1251	0
	Trigger OFF	103	130	1	1252	0
	Value ON	103	131	1	1253	0
	Value OFF	103	132	1	1254	0
	Direction Value ON	103	133	1	1255	0
	Direction Value OFF	103	134	1	1256	0
	Delay	103	135	1	1257	0
	Inverted	103	136	1	1258	0
	PWM Value	103	137	1	1259	0

B. Parametrizing via field bus

Record Sets					FHPP	
Class 104 (0x68)		CLS	ATTR	INST	PNU	SI
Record Control Byte 1	Record Sets	104	1	01h ... 20h	401	1 ... 32
	Direct Mode	104	1	22h	401	34
Record Control Byte 2	Record Sets	104	2	01h ... 20h	402	1 ... 32
Target Position	Record Sets	104	4	01h ... 20h	404	1 ... 32
	Jog Mode	104	4	21h	404	33
	Direct Mode	104	4	22h	404	34
Record Delay	Record Sets	104	5	01h ... 20h	405	1 ... 32
Velocity	Record Sets	104	6	01h ... 20h	406	1 ... 32
	Jog Mode	104	6	21h	531	0
Acceleration	Record Sets	104	7	01h ... 20h	407	1 ... 32
	Jog Mode	104	7	21h	532	0
	Direct Mode	104	7	22h	541	0
Deceleration	Record Sets	104	8	01h ... 20h	408	1 ... 32
	Jog Mode	104	8	21h	408	33
	Direct Mode	104	8	22h	542	0
Jerk Acceleration	Record Sets	104	9	01h ... 20h	409	1 ... 32
	Jog Mode	104	9	21h	409	33
	Direct Mode	104	9	22h	543	0
Work Load	Record Sets	104	10	01h ... 20h	410	1 ... 32
	Jog Mode	104	10	21h	410	33
	Direct Mode	104	10	22h	544	0
Position Window Time	Record Sets	104	14	01h ... 20h	415	1 ... 32
	Jog Mode	104	14	21h	415	33
	Direct Mode	104	14	22h	1023	0

B. Parametrizing via field bus

Record Sets					FHPP	
Class 104 (0x68)		CLS	ATTR	INST	PNU	SI
Following Record	Record Sets	104	15	01h ... 20h	416	1 ... 32
Jerk Deceleration	Record Sets	104	16	01h ... 20h	417	1 ... 32
	Jog Mode	104	16	21h	417	33
	Direct Mode	104	16	22h	547	0

Project Data					FHPP	
Class 105 (0x69)		CLS	ATTR	INST	PNU	SI
Project Zero Point		105	1	1	500	0
Software End Position	Lower Limit	105	2	1	501	1
	Upper Limit	105	3	1	501	2
Max Velocity		105	4	1	502	0
Max Acceleration		105	5	1	503	0
Motion Profile Type		105	8	1	506	0
Stroke Limit (Force Control)		105	10	1	510	0
Min Torque/Force		105	11	1	511	0
Max Torque/Force		105	12	1	512	0
Torque/Force Profile Type		105	13	1	513	0
Teach Target		105	20	1	520	0
Jog Mode Time Slow Motion		105	34	1	534	0
Direct Mode Base Velocity		105	40	1	540	0
Torque/Force Slope		105	50	1	550	0
Force Target Window		105	52	1	552	0
Force Target Damping Time		105	53	1	553	0
Speed Limit (Force Control)		105	54	1	554	0

B. Parametrizing via field bus

Axis Data				FHPP		
Class 107 (0x6B)		CLS	ATTR	INST	PNU	SI
Polarity		107	1	1	1000	0
Encoder Resolution	Encoder Increments	107	2	1	1001	1
	Motor Resolution	107	3	1	1001	2
Gear Ratio	Motor Revolutions	107	4	1	1002	1
	Motor Shaft Revolutions	107	5	1	1002	2
Feed Constant Linear Axis	Feed	107	6	1	1003	1
	Feed Shaft Revolutions	107	7	1	1003	2
Position Factor	Numerator	107	8	1	1004	1
	Denominator	107	9	1	1004	2
Axis Parameter	Axis Length	107	10	1	1005	1
	Axis Type	107	13	1	1005	4
	Axis Installation Position	107	15	1	1005	6
Offset Axis Zero Point (Home Offset)		107	20	1	1010	0
Homing Method		107	21	1	1011	0
Homing Velocities	Search REF	107	22	1	1012	1
	Search AZ	107	23	1	1012	2
Homing Required		107	25	1	1014	0
Homing Max Torque/Force		107	26	1	1015	0
Quick Stop Option Code		107	29	1	1019	0
HALT Option Code		107	30	1	1020	0
Fault Reaction / STOP Option Code		107	31	1	1021	0
Target Position Window		107	32	1	1022	0

B. Parametrizing via field bus

Axis Data					FHPP	
Class 107 (0x6B)		CLS	ATTR	INST	PNU	SI
Control Parameter	Position Controller Closed Loop Internal Frequency	107	34	1	1024	18
	Position Controller Damping	107	35	1	1024	19
	Current Controller Gain	107	36	1	1024	20
	Current Controller Integrating Time Constant	107	37	1	1024	21
Motor Data – I ² t Value		107	41	1	1027	0
Quick Stop Deceleration		107	42	1	1029	0
Motor Data	Serial Number	107	44	1	1025	1
	I ² t Factor	107	45	1	1025	3
Commutation Point		107	46	1	1050	0
Motor Data – Nominal Power		107	47	1	1053	0
Motor Data – Max Phase Current		107	48	1	1028	0
Drive Data	Output Stage Temp	107	49	1	1026	1
	Output Stage Max Temp	107	50	1	1026	2
	Max Current	107	52	1	1026	4
	Device Control	107	54	1	1026	6
	Controller Serial Number	107	55	1	1026	7
Power Supply		107	57	1	1070	0
Tool Load		107	58	1	1071	0
Motor Type		107	60	1	1030	0
Max Current		107	64	1	1034	0
Motor Rated Current		107	65	1	1035	0
Motor Rated Torque/Force		107	66	1	1036	0

B. Parametrizing via field bus

Axis Data				FHPP		
Class 107 (0x6B)		CLS	ATTR	INST	PNU	SI
Position Demand Value		107	68	1	1040	0
Position Actual Value		107	69	1	1041	0
Standstill Position Window		107	70	1	1042	0
Standstill Timeout		107	71	1	1043	0
Following Error Window		107	72	1	1044	0
Following Error Timeout		107	73	1	1045	0
Commutation Status		107	74	1	1056	0
Start Delay Commutation		107	75	1	1072	0
Motor Data – Actual Coil Temp		107	80	1	1060	0
Motor Data – Max Coil Temp		107	81	1	1061	0
Motor Data – Lower Coil Temp Threshold		107	82	1	1062	0
Motor Data – Upper Coil Temp Threshold		107	83	1	1063	0
Output Stage Temperature SFC-LACI	Actual Temperature	107	86	1	1066	0
	Max Temperature	107	87	1	1067	0
	Lower Threshold Temp	107	88	1	1068	0
	Upper Threshold Temp	107	89	1	1069	0
Measurement System Resolution		107	90	1	1051	0
Measurement System Pitch		107	91	1	1052	0
Offset Reference Point		107	92	1	1055	0
Record Power Consumption		107	93	1	1057	0
Positioning Time		107	94	1	1058	0
Actual Current		107	95	1	1059	0

B. Parametrizing via field bus

System Diagnosis				FHPP	
Class 108 (0x6C)	CLS	ATTR	INST	PNU	SI
Device Errors	108	1	1	205	0
Device Warnings	108	2	1	215	0
Extended Device Errors A	108	10	1	207	0
Extended Device Errors B	108	11	1	208	0
Extended Device Errors C	108	12	1	209	0

Fieldbus Diagnosis					FHPP	
Class 109 (0x6D)		CLS	ATTR	INST	PNU	SI
DeviceNet Diagnosis StateByte	DeviceNet Network Status	109	1	1	206	1
	DeviceNet Baudrate	109	2	1	206	2
	DeviceNet MAC ID	109	4	1	206	4
	DeviceNet I/O Datalength	109	5	1	206	5

B.2 Parameterisation via FPC

B.2.1 Structure of the Festo Parameter Channel (FPC)

The “Festo Parameter Channel” is used for transmitting parameters. It consists of 8 octets:

FPC								
	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
O data	0	IND	PKE (ParID)		PWE (ParVal)			
I data	0	IND	PKE (ParID)		PWE (ParVal)			
IND	Subindex							
PKE	Parameter identifier: PNU and AK							
PWE	Parameter value:							
	– for double word: bytes 5 ... 8							
	– for word: bytes 7, 8							
	– for byte: byte 8							

Tab. B/2: Structure of the Festo parameter channel (FPC)

Element	Description
Parameter identifier ParID	Contains: <ul style="list-style-type: none">– Parameter number PNU: Identifies a parameter– Task or reply identifier (AK): describes the type of task/reply
Subindex (IND)	Addresses an element of an array parameter
Parameter value ParVal	Value of the parameter If a task cannot be carried out, an error number will be transmitted in the reply (see section B.2.2)

Tab. B/3: Parameter channel elements

Parameter identifier (ParID)

The parameter identifier contains the Task or Response identifier (AK) and the parameter number (PNU).
Spontaneous messages via bit 11 are not supported by the SFC-LACI.

ParID																
Bit	Byte 3								Byte 4							
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Order	ReqID (AK)				res.	PNU (parameter number)										
Reply	ResID (AK)				res.	PNU (parameter number)										
ReqID (AK)	Request Identifier – job identifier (read, write, ...)															
ResID (AK)	Response Identifier (transferred value, error, ...)															
	The Task or Response identifier indicates the type of task or reply (see section B.2.2).															
PNU	Parameter number – serves for identifying or addressing the relevant parameters.															

Tab. B/4: Structure of parameter identifier (ParID)

B. Parametrizing via field bus

B.2.2 Task identifiers, response identifiers and error numbers

Task identifiers:

ReqID	Description	Reply identifier	
		Positive	Negative
0	No job	0	–
1	Request parameter ¹⁾	1, 2	7
2	Modify parameter value (word) ¹⁾	1	7
3	Modify parameter value (double word) ¹⁾	2	7
6	Request parameter (array)	4, 5	7
7	Modify parameter value (array, word)	4	7
8	Modify parameter value (array, double word)	5	7
11	Modify parameter value (byte) ¹⁾	11	7
12	Modify parameter value (array, byte)	12	7
¹⁾ When using task numbers for simple variables to access parameters implemented as an array, the subindex is ignored or set to 0. This means that the first element of an array is always addressed. ²⁾ Jobs with non-supported job numbers (ReqID) will be answered with Response identifier 7 and error number 22.			

Tab. B/5: Task identifiers

If the task cannot be carried out, reply identifier 7 as well as the appropriate error number will be transmitted.

Reply identifiers:

ResID	Description
0	No reply
1	Parameter transferred (word)
2	Parameter transferred (double word)
4	Parameter value transferred (array, word)
5	Parameter value transferred (array, double word)
6	Number of array elements transferred
7	Task cannot be carried out (with error number, see following table)
11	Parameter value transferred (byte)
12	Parameter value transferred (array, byte)

Tab. B/6: Reply identifiers

B. Parametrizing via field bus

If the task cannot be carried out, an error number will be transmitted in the reply telegram (octets 7 and 8 of the FPC range).

Error number		Description
0	0x00	Non-permitted PNU The parameter does not exist
1	0x01	Parameter value cannot be modified (read only)
3	0x03	Faulty subindex
4	0x04	No array
5	0x05	Incorrect data type
9	0x09	Description data do not exist
11	0x0A	No control sovereignty
13	0x0C	Text not legible in cyclic exchange
22	0x16	Impermissible: attributes, number of elements, PNU or IND
24	0x18	Write Request: number of values not permitted

Tab. B/7: Error numbers

B. Parametrizing via field bus

B.2.3 Rules for job reply processing

Rules	Description
1	If the master sends the identifier for “No Task”, the SFC-LACI replies with the response identifier for “No Reply”
2	A job or reply telegram always refers to a single parameter
3	The master must continue to send a task until it receives the appropriate reply from the SFC-LACI
4	The master recognises the reply to the job placed: <ul style="list-style-type: none">– by evaluating the response identifier– by evaluating the parameter number (PNU)– if applicable, by evaluating the subindex (IND)– If applicable, by evaluating the parameter value
5	The SFC-LACI provides the reply until the master sends a new task
6	a) A write task, even with cyclic repetition of the same task, will only be carried out once by the SFC-LACI. b) Between two consecutive jobs with the same Job identifier (AK), parameter number (PNU) and subindex (IND), the Job identifier 0 (no job) must be sent and the Response identifier 0 (no reply) must be awaited. This ensures that an “old” reply is not interpreted as a “new” reply.

Tab. B/8: Rules for job reply processing

Sequence of parameter processing



Caution

Observe the following when modifying parameters:
An FHPP write signal referring to a modified parameter may only occur when the Response identifier “Parameter value transferred” is received for the relevant parameter and if applicable for the index.

If, for example, a position value in a position set table is to be modified and if movement is then to be made to this position, the positioning command must not be given until the SFC-LACI has completed the modification of the position register and confirmed this.



Caution

In order to be sure that an “old” reply cannot be interpreted as a “new” reply, the Job identifier 0 (no job) must be sent and the Response identifier 0 (no reply) must be awaited between two consecutive jobs with the same job identifier (AK), parameter number (PNU) and subindex (IND).

Evaluating errors

In the case of jobs which cannot be carried out, the slave replies as follows:

- Output of response identifier = 7
- Output an error number in bytes 7 and 8 of the parameter channel (FPC).

B. Parametrizing via field bus

B.2.4 Example of parameterising via FPC

A record in the position set table can be parameterised via FPC in the following manner:

Step 1 Output status of the 8 bytes of FPC data:

	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
	Reserved	Subindex	ReqID/ResID + PNU	Parameter value				
O data	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00
I data	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00

Step 2 write record number 1 with absolute positioning:
PNU 401, subindex 2 – Modify parameter value, array, byte:
ReqID 12 (0xC) with value 0x00

	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
	Reserved	Subindex	ReqID/ResID + PNU	Parameter value				
O data	0x00	0x02	0xC1	0x91	Unused	Unused	Unused	0x00
I data	0x00	0x02	0xC1	0x91	0x00	0x00	0x00	0x00

Step 3 After receiving the input data with ResID 0xC send output data with ReqID = 0x0 and wait for input data with ResID = 0x0:

	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
	Reserved	Subindex	ReqID/ResID + PNU	Parameter value				
O data	0x00	0x02	0x01	0x91	Unused	Unused	Unused	0x00
I data	0x00	0x02	0x01	0x91	0x00	0x00	0x00	0x00

B. Parametrizing via field bus

Step 4

write record number 1 with target position 0x1234 (decimal 4660 increments):
PNU 404, subindex 2 – Modify parameter value, array, double word: ReqID 8 (0x8) with value 0x00001234

	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
	Reserved	Subindex	ReqID/ResID + PNU		Parameter value			
O data	0x00	0x02	0x81	0x94	0x00	0x00	0x12	0x34
I data	0x00	0x02	0x81	0x94	0x00	0x00	0x12	0x34

Step 5

After receiving the input data with ResID 0x8 send output data with ReqID = 0x0 and wait for input data with ResID = 0x0:

	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
	Reserved	Subindex	ReqID/ResID + PNU		Parameter value			
O data	0x00	0x02	0x01	0x94	0x00	0x00	0x12	0x34
I data	0x00	0x02	0x01	0x94	0x00	0x00	0x12	0x34

Step 6

write record number 1 with speed 0x7743 (decimal 30531 increments/s): PNU 406, subindex 2 – Modify parameter value, array, double word: ReqID 8 (0x8) with value 0x00007743

	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
	Reserved	Subindex	ReqID/ResID + PNU		Parameter value			
O data	0x00	0x02	0x81	0x96	0x00	0x00	0x77	0x43
I data	0x00	0x02	0x81	0x96	0x00	0x00	0x77	0x43

Step 7

After receiving the input data with ResID 0x8 send output data with ReqID = 0x0 and wait for input data with ResID = 0x0:

	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
	Reserved	Subindex	ReqID/ResID + PNU		Parameter value			
O data	0x00	0x02	0x01	0x94	0x00	0x00	0x77	0x43
I data	0x00	0x02	0x01	0x94	0x00	0x00	0x77	0x43

B.3 FHPP finite state machine




Fig. B/1: Finite state machine

Notes on representing the finite status machine

The transition T3 changes to state S4, which itself contains its own sub-state machine, the states of which are marked with “SAx” and the transitions of that are marked with “TAx”. This enables an equivalent circuit diagram to be used, in which the internal states SAx are omitted:




Fig. B/2: Finite state machine equivalent circuit diagram

Transitions T4, T6 and T7* are executed from every sub-state SAx and automatically have a higher priority than any transition TAx. Such a structure is a simplification. It is not therefore necessary to define out of each SAx state a separate transition as per S3 for the reaction to STOP (S3: drive held stationary).

Reaction to faults

T7 (“Fault recognised”) has the highest priority and receives the asterisk “*”.

T7 is then derived from S5 and S6 when an error of higher priority occurs. As a result, a slight error can displace a serious error.

B. Parametrizing via field bus

B.3.1 Create readiness to operate

With the transitions only those internal conditions are named which are new. There must therefore not be any faults for T2.

T	Internal conditions	Actions of the user
T1	SFC-LACI was switched on. An error cannot be ascertained.	
T2	Load voltage applied. Field bus master must be higher-order controller.	ENABLE = 1 (drive enabled) CCON = xxx0.xxx 1
T3		STOP = 1 CCON = xxx0.xx 11
T4		STOP = 0 CCON = xxx0.xx 01
T5		ENABLE = 0 CCON = xxx0.xxx 0
T6		ENABLE = 0 CCON = xxx0.xxx 0
T7*	Fault detected	
T8	Reaction to fault completed, drive stopped	
T9	There is no longer a fault. It was a serious error.	RESET = 0→1 (acknowledge fault) CCON = xxx0. P xxx
T10	There is no longer a fault. It was a simple error.	RESET = 0→1 (acknowledge fault) CCON = xxx0. P xx 1
T11	Fault is still present	RESET = 0→1 (acknowledge fault) CCON = xxx0. P xx 1
Key: P = positive edge N = negative edge x = any		

B. Parametrizing via field bus

B.3.2 Positioning

Fundamentally, the following applies:
Transitions T4, T6 and T7* always have priority.

TA	Internal conditions	Actions of the user
TA1	Referencing is running.	START = 0→1 (Start positioning) HALT = 1 CCON = xxx0.xx11 CPOS = 0xx0.00P1
TA2	Motion Complete = 1 The current record is completed. The next record is not to be carried out automatically	“HALT” status is any CCON = xxx0.xx11 CPOS = 0xxx.xxxx
TA3	Motion Complete = 0	HALT = 1→0 CCON = xxx0.xx11 CPOS = 0xxx.xxxN
TA4		START = 0→1 (Start positioning) HALT = 1 CCON = xxx0.xx11 CPOS = 00xx.xxP1
TA5	Record selection: – A single record is finished – The next record is processed automatically	CCON = xxx0.xx11 CPOS = 0xxx.xxx1
	Direct mode: – A new positioning task has arrived	CCON = xxx0.xx11 CPOS = 0xxx.xx11
TA6		CLEAR = 0→1 (clear remaining path) CCON = xxx0.xx11 CPOS = 0Pxx.xxxx
TA7		HOM = 0→1 (start homing) HALT = 1 CCON = xxx0.xx11 CPOS = 0xx0.0Px1
Key: P = positive edge N = negative edge x = any		

B. Parametrizing via field bus

TA	Internal conditions	Actions of the user
TA8	Homing concluded or HALT	Only for HALT: HALT = 1→0 CCON = xxx0.xx11 CPOS = 0xxx.xxxN
TA9		Jog positive = 0→1 HALT = 1 CCON = xxx0.xx11 CPOS = 0xx0.Pxx1
TA10		Either – Jog positive = 1→0 – CCON = xxx0.xx11 – CPOS = 0xx0.Nxx1 or – HALT = 1→0 – CCON = xxx0.xx11 – CPOS = 0xxx.xxxN
TA11		Jog negative = 0→1 HALT = 1 CCON = xxx0.xx11 CPOS = 0xxP.0xx1
TA12		Either – Jog negative = 1→0 – CCON = xxx0.xx11 – CPOS = 0xxN.xxx1 or – HALT = 1→0 – CCON = xxx0.xx11 – CPOS = 0xxx.xxxN
Key: P = positive edge N = negative edge x = any		

Special features dependent on operating mode

Record selection

- No restrictions

Direct mode

- TA2:
The condition that no new record may be processed no longer applies.
- TA5:
A new record can be started at any time.

B.4 Reference FHPP Parameters

B.4.1 FHPP parameter groups

Group	PNU	Description
Device data	100 ... 199	Device identification and device-specific settings, version numbers, identifier words, etc.
Diagnosis memory	200 ... 299	Memory for diagnostic events: Fault numbers, fault time, incoming/outgoing event
Process data	300 ... 399	Current setpoint and actual values, local I/Os, status data etc.
Position record table (= record list)	400 ... 499	A record contains all the setpoint value parameters required for a positioning procedure
Project data	500 ... 599	Basic project settings. Maximum speed and acceleration, project zero point offset, etc. → These parameters form the basis of the position set table
Factor group	600 ... 699	Reserved
Axis data Electric drives 1	1000 ... 1099	All axis-specific parameters for electric drives. Gear factor, feed constant, reference parameter, etc.
Axis data Electric drives 2	1200 ...	Enhancements

Tab. B/9: Parameter groups (FHPP)

B.4.2 Overview of parameter numbers (PNU)

The following overview shows the available FHPP parameters arranged according to the parameter number PNU for parameterising as per FPC.

A detailed description of the parameters can be found in the sections B.4.4 to B.4.10.



You will find an overview of the available CI objects in section C.2.

Name	PNU	SI
Device Data		
Manufacturer Hardware Version BCD	0100	–
Manufacturer Firmware Version BCD	0101	–
Version FHPP	0102	–
Version FCT PlugIn BCD	0104	1 ... 2
Version Axis Interface	0106	–
Supported Drive Modes	0112	–
Controller Serial Number	0114	1 ... 12 _d
Controller Type	0115	–
Manufacturer Device Name	0120	1 ... 30 _d
User Device Name	0121	1 ... 24 _d
Drive Manufacturer	0122	1 ... 30 _d
HTTP Drive Catalog Address	0123	1 ... 30 _d
Festo Order Number	0124	1 ... 30 _d
Device Control	0125	–
HMI Parameter (control panel parameter)	0126	1 ... 4
Data Memory Control (EEPROM commands)	0127	1 ... 3

B. Parametrizing via field bus

Name	PNU	SI
Diagnosis Memory		
Diagnostic Event	0200	1 ... 16 _d
Fault Number	0201	1 ... 16 _d
Time Stamp	0202	1 ... 16 _d
Additional Information	0203	1 ... 16 _d
Diagnostic Memory Parameter	0204	1 ... 4
Device Errors	0205	–
DeviceNet Diagnosis	0206	1 ... 6
Extended Device Errors A	0207	–
Extended Device Errors B	0208	–
Device Warnings	0215	–
Process Data		
Position Monitoring	0300	1 ... 2
Torque/Force Monitoring	0301	1 ... 2
Digital Inputs	0303	–
Digital Outputs	0304	1 ... 2
Cycle Number	0305	–
Velocity Monitoring (speed monitoring)	0310	1 ... 2
FHPP Status Data	0320	1 ... 2
FHPP Control Data	0321	1 ... 2
Control Word	0330	–
Status Word	0331	–
Operation Mode	0332	–
Operation Mode Display	0333	–

B. Parametrizing via field bus

Name	PNU	SI
Position Sampling – Position Rising Edge (On-the-fly measurement – position with rising edge)	0350	–
Position Sampling – Position Falling Edge (On-the-fly measurement – position with falling edge)	0351	–
Position Sampling – Trigger Mode (on-the-fly measurement – trigger mode)	0352	–
Position Sampling – Status (on-the-fly measurement – status)	0353	–
Position Sampling – Status Mask (on-the-fly measurement – status mask)	0354	–
Position Sampling – Control Byte (on-the-fly measurement – control byte)	0355	–
Positioning Record Table (record list)		
Record Number FHPP	0400	1 ... 3
Record Control Byte 1	0401	1 ... 34 _d
Record Control Byte 2	0402	1 ... 32 _d
Target Position	0404	1 ... 34 _d
Record Delay	0405	1 ... 32 _d
Velocity (speed)	0406	1 ... 32 _d
Acceleration	0407	1 ... 32 _d
Deceleration	0408	1 ... 33 _d
Jerk Acceleration	0409	1 ... 33 _d
Work Load	0410	1 ... 33 _d
Position Window Time (damping time)	0415	1 ... 33 _d
Following Record	0416	1 ... 32 _d
Jerk Deceleration	0417	1 ... 33 _d

B. Parametrizing via field bus

Name	PNU	SI
Project Data – General		
Project Zero Point (offset project zero point)	0500	–
Software End Positions	0501	1 ... 2
Max Velocity (max. speed)	0502	–
Max Acceleration	0503	–
Motion Profile Type (ramp profile)	0506	–
Project Data – Force Control		
Force Control – Stroke Limit	0510	–
Force Control – Min Torque/Force	0511	–
Force Control – Max Torque/Force	0512	–
Force Control – Torque/Force Profile Type	0513	–
Project Data – Teach		
Teach Target	0520	–
Project Data – Jog Mode		
Jog Mode Velocity Phase 2	0531	–
Jog Mode Acceleration	0532	–
Jog Mode Time Slow Motion (time phase 1)	0534	–
Project Data – Direct Mode: Positioning Mode		
Direct Mode Base Velocity	0540	–
Direct Mode Acceleration	0541	–
Direct Mode Deceleration	0542	–
Direct Mode Jerk Acceleration	0543	–
Direct Mode Work Load (direct mode applied load)	0544	–
Direct Mode Jerk Deceleration	0547	–

B. Parametrizing via field bus

Name	PNU	SI
Project Data – Direct Mode: Force Mode		
Torque/Force Slope (change of force)	0550	–
Force Target Window	0552	–
Force Target Damping Time	0553	–
Speed Limit	0554	–
Project Data – Direct Mode: FHPP Continuous Mode		
Interpolation Time (interval specification)	0570	–
Axis Data Electric Drives 1 – Mechanical		
Polarity (reversal of direction)	1000	–
Encoder Resolution	1001	1 ... 2
Gear Ratio	1002	1 ... 2
Feed Constant Linear Axis	1003	1 ... 2
Position Factor	1004	1 ... 2
Axis Parameter	1005	1 ... 6
Electric Drives 1 – Homing		
Offset Axis Zero Point	1010	–
Homing Method	1011	–
Homing Velocities	1012	1 ... 2
Homing Required	1014	–
Homing Max Torque/Force	1015	–

B. Parametrizing via field bus

Name	PNU	SI
Electric Drives 1 – Control Parameters		
Quick Stop Option Code	1019	–
Halt Option Code	1020	–
Fault Reaction / STOP Option Code	1021	–
Target Position Window	1022	–
Direct Mode Position Window Time	1023	–
Position Control Parameter	1024	18 ... 21 _d
Motor Data (axis data)	1025	1, 3
Drive Data (data of the SFC-LACI)	1026	1, 2, 4, 6, 7
I ² t Value	1027	–
Max Phase Current (max. permitted string current)	1028	–
Quick Stop Deceleration (quick stop ramp)	1029	–
Electric Drives 1 – Electronic Type Plate		
Motor Type	1030	–
Max Current	1034	–
Rated Motor Current	1035	–
Motor Rated Torque/Force	1036	–
Electric Drives 1 – Standstill Monitoring		
Position Demand Value (setpoint position)	1040	–
Position Actual Value	1041	–
Standstill Position Window	1042	–
Standstill Timeout	1043	–

B. Parametrizing via field bus

Name	PNU	SI
Electric Drives 1 – Supplementary Parameters		
Following Error Window (contouring error window)	1044	–
Following Error Timeout (contouring error monitoring time)	1045	–
Commutation Point	1050	–
Measurement System Resolution	1051	–
Measurement System Pitch	1052	–
Nominal Power	1053	–
Actual Power	1054	–
Offset Reference Point	1055	–
Commutation Status	1056	–
Record Power Consumption	1057	–
Positioning Time	1058	–
Actual Current	1059	–
Actual Coil Temp	1060	–
Max Coil Temp	1061	–
Lower Coil Temp Threshold	1062	–
Upper Coil Temp Threshold	1063	–
Output Stage Temperature SFC-LACI	1066	–
Output Stage Max Temp SFC-LACI	1067	–
Output Stage Lower Threshold Temp	1068	–
Output Stage Upper Threshold Temp	1069	–
Power Supply	1070	–
Tool Load	1071	–
Start Delay Commutation	1072	–

B. Parametrizing via field bus

Name	PNU	SI
Local Digital Output 1 – Function (Local digital output 1 – use)	1240	–
Local Digital Output 1 – Trigger ON (Local digital output 1 – setting condition)	1241	–
Local Digital Output 1 – Trigger OFF (Local digital output 1 – resetting condition)	1242	–
Local Digital Output 1 – Value ON (Local digital output 1 – setting with record number)	1243	–
Local Digital Output 1 – Value OFF (Local digital output 1 – resetting with record number)	1244	–
Local Digital Output 1 – Direction Value ON (Local digital output 1 – setting edge)	1245	–
Local Digital Output 1 – Direction Value OFF (Local digital output 1 – resetting edge)	1246	–
Local Digital Output 1 – Delay	1247	–
Local Digital Output 1 – Inverted	1248	–
Local Digital Output 2 – Function	1250	–
Local Digital Output 2 – Trigger ON	1251	–
Local Digital Output 2 – Trigger OFF	1252	–
Local Digital Output 2 – Value ON	1253	–
Local Digital Output 2 – Value OFF	1254	–
Local Digital Output 2 – Direction Value ON	1255	–
Local Digital Output 2 – Direction Value OFF	1256	–
Local Digital Output 2 – Delay	1257	–
Local Digital Output 2 – Inverted	1258	–
Local Digital Output 2 – PWM Value	1259	–

B. Parametrizing via field bus

Name	PNU	SI
Limit Switch Polarity	1300	–
Limit Switch Selector (input for limit switch)	1301	–
Homing Switch Selector (input for reference switch)	1302	–
Homing Switch Polarity	1303	–
Limit Switch Deceleration	1304	–
Sample Input (input for on-the-fly measurement)	1305	–
Sample Switch Polarity	1306	–
Brake Delay Time Switch ON	1310	–
Brake Delay Time Switch OFF	1311	–
Automatic Brake Time (activation time of the automatic brake)	1312	–

B. Parametrizing via field bus

B.4.3 Representation of the parameter entries

		1	2	3	4	5
	Encoder Resolution					
	PNU	1001	1 ... 2		uint32	rw
6	Description	Encoder resolution in increments / revolutions The encoder resolution is fixed and cannot be modified by the user. The calculated value is derived from the fraction (encoder increments/ motor revolution).				
7	Encoder Increments	1001	1	0		
		Value range: 0 ... (2 ³² - 1) Default: 500				
	Motor Revolutions	1001	2	1		
8		Fixed = 1				
	CI	608Fh	01 ... 02h		uint32	rw
9	DeviceNet	C: 107	A: 2		I: 1	rw

- 1 Name of the parameter
- 2 Parameter number (PNU)
- 3 Subindices of the parameter
 - : the object has no subindex (simple variable)
 - 1 ... 30: the object has subindices from 1 ... 30_{dec}
- 4 Variable type
- 5 Read/write permission:
 - r = read only
 - w = write only
 - rw = read and write
- 6 Description of the parameter
- 7 If applicable: Explanation of the subindices
- 8 Corresponding CI object (see section C.1)
- 9 Access via “Explicit messaging”; class (C), attribute (A), instance (I)

Fig. B/3: Representation of the parameter entries

B. Parametrizing via field bus

B.4.4 Device data

Manufacturer Hardware Version BCD					
PNU	100	–		uint16	r
Description	Hardware version in BCD (binary coded decimals): xxyy (xx = main version, yy = secondary version)				
CI	2069h	00h		uint16	r
DeviceNet	C: 100	A: 1	I: 1	uint16	r

Manufacturer Firmware Version BCD					
PNU	101	–		uint16	r
Description	Firmware version in BCD (binary coded decimals): xxyy (xx = main version, yy = secondary version)				
CI	206Ah	00h		uint16	r
DeviceNet	C: 100	A: 2	I: 1	uint16	r

Version FHPP					
PNU	102	–		uint16	r
Description	Version number of FHPP in BCD (binary coded decimals): xxyy (xx = main version, yy = secondary version)				
CI	2066h	00h		uint16	r
DeviceNet	C: 100	A: 3	I: 1	uint16	r

B. Parametrizing via field bus

Version FCT PlugIn BCD					
PNU	104	1 ... 2	Array	uint16	r
Description					
FCT PlugIn Min.		1			r
FCT PlugIn Opt.	Minimum necessary FCT version in BCD (binary coded decimals): Format = “xx.yy” (xx = main version, yy = secondary version)				
		2			r
	Optimum FCT version in BCD (binary coded decimal): Format = “xx.yy” (xx = main version, yy = secondary version)				
CI	206Bh	01 ... 02h		uint16	r
DeviceNet	C: 100	A: 4 ... 5	I: 1	uint16	r

Version Axis Interface					
PNU	106	–		uint16	r
Description	Version number of the axis interface				
CI	2FFDh	00h		uint16	r
DeviceNet	C: 100	A: 60	I: 1	uint16	r

B. Parametrizing via field bus

Supported Drive Modes					
PNU	112	–		uint32	r
Description	Fix = 69h (105d) Bit 0: Profile position mode Bit 1: (Velocity mode) Bit 2: (Profile velocity mode) Bit 3: Profile torque mode Bit 4: (Reserved) Bit 5: Homing mode Bit 6: FHPP Continuous Mode / Interpolated Position Mode Bit 7 ... 31: (reserved)				
CI	6502h	00h		uint32	r
DeviceNet	C: 100	A: 45	I: 1	uint32	r

Controller Serial Number					
PNU	114	1 ... 12 _d		char	r
Description	Serial number of the controller, e.g.: "K402P1212345"				
CI	2072h	00h		V-String	r
DeviceNet	C: 100	A: 8	I: 1	Short string	

Controller Type					
PNU	115	–		uint16	r
Description	SFC-LACI-....IO: 0x10 = without display; 0x11 = with display SFC-LACI-....PB: 0x12 = without display; 0x13 = with display SFC-LACI-....CO: 0x14 = without display; 0x15 = with display SFC-LACI-....DN: 0x16 = without display; 0x17 = with display				
CI	20E3h	00h		uint16	r
DeviceNet	C: 100	A: 6	I: 1	uint16	r

B. Parametrizing via field bus

Manufacturer Device Name					
PNU	120	1 ... 30_d		char	r
Description	Manufacturer's name for the device: SFC-LACI-...				
CI	1008h	00h		V-String	r
DeviceNet	C: 100	A: 9	I: 1	Short string	r

User Device Name					
PNU	121	1 ... 24_d		char	rw
Description	Device name assigned by user Max. 24 characters (ASCII, 7-bit). Default: "motor001"				
CI	20FDh	00h		V-String	rw
DeviceNet	C: 100	A: 10	I: 1	Short string	r

Drive Manufacturer					
PNU	122	1 ... 30_d		char	r
Description	Festo AG & Co. KG				
CI	6504h	00h		V-String	r
DeviceNet	C: 100	A: 11	I: 1	Short string	r

HTTP Drive Catalog Address					
PNU	123	1 ... 30_d		char	r
Description	www.festo.com				
CI	6505h	00h		V-String	r
DeviceNet	C: 100	A: 12	I: 1	Short string	r

B. Parametrizing via field bus

Festo Order Number					
PNU	124	1 ... 30_d		char	r
Description	Order number for SFC-LACI				
CI	6503h	00h		V-String	r
DeviceNet	C: 100	A: 13	I: 1	Short string	r

Device Control					
PNU	125	–		uint8	rw
Description	Corresponds to “HMI control” on the control panel and “FCT” on the FCT. 0 (0x00): Control via controller interface (DeviceNet) OFF, via HMI (control panel) and FCT ON 1 (0x01): Control via controller interface ON (default)				
CI	207Dh	00h		uint8	rw
DeviceNet	C: 100	A: 14	I: 1	uint8	rw

B. Parametrizing via field bus

HMI Parameter					
PNU	126	1 ... 4		uint8	r
Description	Control panel settings (SFC-LACI-...-H2 only)				
LCD Current	126	1			
	Brightness. Value range: 1 ... 5. Default: 5				
LCD Contrast	126	2			
	Contrast. Value range: 0 ... 63 (0x00 ... 0x3F). Default: 0				
Measure	126	3			
	Unit of measurement system on the control panel (see 20D0/01h) Fix = 1: millimetre, e.. g. mm, mm/s, mm/s ²				
Scaling Factor	126	4			
	Number of post-decimal positions (see 20D0/02h) Fixed = 2: 2 post-decimal positions				
CI	20FFh	01h ... 04h		uint8	r
DeviceNet	C: 100	A: 15 ... 18	I: 1	uint8	r

B. Parametrizing via field bus

Data Memory Control					
PNU	127	1 ... 2		uint8	w
Description	Commands for EEPROM Subindex 03: See 20F1h				
	Delete EEPROM	127	1		
	Save Data	Fixed: 16 (0x10): Delete data in EEPROM. Once the object has been written, and after power off/on, the data in the EEPROM are reset to the factory settings.			
		127	2		
	The data in EEPROM will be overwritten with the current user-specific settings. Fix 1 (0x01): Save data				
CI	20F1h	01h ... 02h		uint8	w
DeviceNet	C: 100	A: 20 ... 21	I: 1	uint8	w



Note

All user-specific settings will be lost on deletion (except for cycle number). The status after deletion corresponds to the standard factory setting.

- Always carry out a first commissioning after deleting the EEPROM.
- When the EEPROM is deleted, the field bus address is also reset.

B.4.5 Diagnosis



Description of the method of operation of the diagnostic memory: see section 6.4.2.

Diagnostic Event					
PNU	200	1 ... 16 _d		uint8	r
Description	Type of fault or diagnostic information saved in the diagnostic memory. Displays whether an incoming or outgoing fault is saved. <u>Value</u> <u>Type of diagnostic event</u> 0 (0x00): No fault (or diagnostic message deleted) 1 (0x01): Incoming fault 2 (0x02): Outgoing fault 3 (0x03): (reserved) 4 (0x04): Overrun time stamp				
	Event 1	200	1		
	Active diagnostic event				
	Event 2	200	2		
	Previous diagnostic event				
	Event ...	200	...		
	...				
	Event 16	200	16		
	Oldest saved diagnostic event				
CI	20C8h	01 ... 10h		uint8	r
DeviceNet	C: 101	A: 1	I: 1 ... 16	uint8	r

B. Parametrizing via field bus

Fault Number					
PNU	201	1 ... 16 _d		uint16	r
Description Event ...	Fault number saved in the diagnostic memory, serves for identifying the fault. Fault numbers with descriptions: see section 6.3				
	201	...			
	See PNU 200				
CI	20C9h	01h ... 10h		uint16	r
DeviceNet	C: 101	A: 2	I: 1 ... 16	uint16	r

Time Stamp					
PNU	202	1 ... 16 _d		uint32	r
Description Event ...	Time stamp: Time of the diagnostic event since device was switched on, in the time unit as per PNU 204/2				
	202	...			
	See PNU 200				
CI	20CAh	01h ... 10h		uint32	r
DeviceNet	C: 101	A: 3	I: 1 ... 16	uint32	r

Additional Information					
PNU	203	1 ... 16 _d		uint32	r
Description Event ...	Number of movement cycles at the time a fault comes or goes. See PNU 305				
	202		
	See PNU 200				
CI	20CBh	01h ... 10h		uint32	r
DeviceNet	C: 101	A: 4	I: 1 ... 16	uint32	r

B. Parametrizing via field bus

Diagnostic Memory Parameter					
PNU	204	1 ... 4		uint8	r(w)
Description	Configuration of the diagnostic memory				
	Fault Type	204	1		rw
	1 (0x01): Record incoming and outgoing *) faults (default) 2 (0x02): Log only incoming faults *) Outgoing fault = Acknowledge the fault				
	Resolution	204	2		rw
	1 (0x01): Resolution time stamp 10 ms (default) 2 (0x02): Resolution time stamp 1 ms				
	Clear Memory	204	3		rw
	Clear diagnostic memory by writing value = 1 Reading is always answered with value = 1				
	Number of Entries	204	4		r
	Number of entries in the diagnostic memory				
CI	20CCh	01h ... 04h		uint8	rw/r
DeviceNet	C: 102	A: 1 ... 4	I: 1	uint8	rw/r

B. Parametrizing via field bus

Device Errors					
PNU	205	–		uint16	rw
Description	<p>Reading or deleting the error message(s). Explanations of the error messages can be found in chapter 6.3 “Diagnosis”.</p> <p>Writing <0>: Delete all error messages (in 2FF1h, 2FFAh, 2FFBh and 2FFCh)</p> <p>Read:</p> <p>Bit 0 (0x1): HARDWARE ERROR SFC-LACI Bit 1 (0x2): CAN COMMUNICATION ERROR Bit 2 (0x4): ELGO SENSOR/COMMUNICATION ERROR Bit 3 (0x8): HARDWARE ERROR DRIVE Bit 4 (0x10): ERROR MOTOR HOT Bit 5 (0x20): ERROR SFC-LACI HOT Bit 6 (0x40): DIGITAL POWER DOWN Bit 7 (0x80): LOAD POWER DOWN Bit 8 (0x100): HOMING ERROR Bit 9 (0x200): PLEASE ENFORCE HOMING RUN Bit 10 (0x400): POSITION ERROR (following error) Bit 11 (0x800): TARGET POSITION OUT OF LIMIT Bit 12 (0x1000): I²t-ERROR Bit 13 (0x2000): MOTOR STOP ERROR Bit 14 (0x4000): POSITION PLAUSIBILITY ERROR Bit 15 (0x8000): COMMUTATION POINT ERROR</p>				
CI	2FF1h	00h		uint16	rw
DeviceNet	C: 108	A: 1	I: 1	uint16	rw

B. Parametrizing via field bus

DeviceNet Diagnosis					
PNU	206	1 ... 6	Array	uint8	r
Description	Read out the field bus diagnostic data				
Network Status	206	1			
	0x00: Bus is inactive, missing bus power supply 0x01: Serious error 0x04/5: Error can be rectified (e.g. Timeout) 0x10: Active connection with DeviceNet Master 0x20: Device self test 0x40/50: No connection to DeviceNet Master				
Baudrate	206	2			
	Baud rate Values: 0 ... 2 Δ 125, 250, 500 kBaud 0xFF Δ invalid baud rate				
–	206	3			
	(reserved)				
MAC ID	206	4			
	Values: 0 ... 63 (0x00 ... 0x3F)				
I/O Datalength	206	5			
	0x10: 8 bytes I/O data length (FHPP standard) 0x11: 16 bytes I/O data length (FHPP + FPC)				
–	206	6			
	(reserved)				
CI	2FF4h	01h ... 06h		uint8	r
DeviceNet	C: 109	A: 1, 2, 4, 5	I: 1	uint8	r

B. Parametrizing via field bus

Extended Device Errors A					
PNU	207	–		uint16	rw
Description	Reading or deleting the active device fault(s) Explanations of the error messages can be found in chapter 6.3 “Diagnosis” Writing <0>: Delete all error messages (in 2FF1h, 2FFAh, 2FFBh and 2FFCh) Read: Bit 0 = 1: Field bus fault (configuration of the parameters) Bit 1 = 1: Double MAC address recognized Bit 2 = 1: Receive queue overrun Bit 3 = 1: Transmit queue overrun Bit 4 = 1: CAN bus off, complete bus failed Bit 5 = 1: CAN controller queue overrun Bit 6 = 0: DeviceNet is reset Bit 7 = 0: Faulty bus supply				
CI	2FFAh	00h		uint16	rw
DeviceNet	C: 108	A: 10	I: 1	uint16	rw

Extended Device Errors B					
PNU	208	–		uint16	rw
Description	Reading or deleting the active device fault(s) Explanations of the error messages can be found in chapter 6.3 “Diagnosis” Writing <0>: Delete all error messages (in 2FF1h, 2FFAh, 2FFBh and 2FFCh) Read: Bit 0: ERROR INTERPOLATION CYCLE TIME (with FHPP continuous mode: missing position specification, missing toggle bit) Bit 1: OVERCURRENT POWER STAGE Bit 2: LIMIT SWITCH ACTIVATED Bit 3: BLOCK DURING JOG MODE				
CI	2FFBh	00h		uint16	rw
DeviceNet	C: 108	A: 11	I: 1	uint16	rw

B. Parametrizing via field bus

Extended Device Errors C					
PNU	209	–		uint16	rw
Description	(reserved)				
CI	2FFCh	00h		uint16	rw
DeviceNet	C: 108	A: 12	I: 1	uint16	rw

Device Warnings					
PNU	215	–		uint16	rw
Description	Reading or deleting the active warning(s) Explanations of the error messages can be found in chapter 6.3 “Diagnosis” Writing <0>: Delete all warnings Reading: Bit 0: INDEX WARNING Bit 1: WARNING MOTOR COLD Bit 2: WARNING MOTOR HOT Bit 3: WARNING SFC-LACI COLD Bit 4: WARNING SFC-LACI HOT Bit 5: STANDSTILL WARNING Bit 6: ILLEGAL RECORD WARNING Bit 7 ... 15: (reserved)				
CI	2FF2h	00h		uint16	rw
DeviceNet	C: 108	A: 2	I: 1	uint16	rw

B. Parametrizing via field bus

B.4.6 Process Data

Position Monitoring					
PNU	300	1 ... 2		int32	r
Description	Position Monitoring				
	Position Actual Value	1			
	Actual position in Increments				
	Position Demand Value	2			
	Controller setpoint position in Increments				
CI	2800h	01h ... 02h		int32	r
DeviceNet	C: 103	A: 1 ... 2	I: 1	int32	r

Torque/Force Monitoring					
PNU	301	1 ... 2		int16	r
Description	Force Monitoring				
	Torque Actual Value	1			
	Actual force in permil of rated force Values: 0 ... 65535				
	Torque Target Value	2			
	Actual force in permil of rated force Values: -1000 ... +1000				
CI	2801h	01h ... 02h		int16	r
DeviceNet	C: 103	A: 4 ... 5	I: 1	int16	r

B. Parametrizing via field bus

Digital Inputs					
PNU	303	–		uint32	r
Description	Mapping the digital inputs Bit 0: Negative limit switch Bit 1: Positive limit switch Bit 2: Reference switch Bit 3 ... 15: reserved (= 0) Bit 16 ... 20: Current record number (compare control byte 3) Bit 21: STOP (CCON.B1) Bit 22: ENABLE (CCON.B0) Bit 23: START (CPOS.B1) Bit 24: Sample input Bit 25 ... 31: reserved (= 0)				
CI	60FDh	00h		uint32	r
DeviceNet	C: 103	A: 10	I: 1	uint32	r

Digital Outputs					
PNU	304	1 ... 2		uint32	r
Description Local Digital Outputs	Mapping the digital outputs				
	304	1			
	Bit 0: Status of brake Bit 1 ... 15: (reserved) Bit 16 : MC Bit 17: READY Bit 18: EA_ACK Bit 19: ERROR Bit 20 ... 24: (reserved) Bit 25: Status Out1 Bit 26: Status Out2				
	– 304	2			
	(reserved)				
CI	60FEh	01h ... 02h		uint32	r
DeviceNet	C: 103	A: 20 ... 21	I: 1	uint32	r

B. Parametrizing via field bus

Cycle Number					
PNU	305	–		uint32	r
Description	Number of positioning records executed, homing runs etc.				
CI	2FFFh	00h		uint32	r
DeviceNet	C: 103	A: 30	I: 1	uint32	r

Velocity Monitoring					
PNU	310	1 ... 2		int32	r
Description	Velocity Monitoring				
	Velocity Actual Value	1			
	Actual speed value in [Inc/s]				
	Velocity Demand Value	2			
	Speed setpoint value in [Inc/s]				
CI	2802h	01h ... 02h		int32	r
DeviceNet	C: 103	A: 36 ... 37	I: 1	int32	r

FHPP Status Data					
PNU	320	1 ... 2	Record	uint32	r
Description	FHPP input data (8 bytes of status data), 4 bytes each, consistent				
		1			
	FHPP status bytes 1 ... 4 (SCON, SPOS, ...)				
		2			
	FHPP status bytes 5 ... 8 (actual position)				
CI	20A0h	01h ... 02h		uint32	r
DeviceNet	C: 103	A: 60 ... 61	I: 1	uint32	r

B. Parametrizing via field bus

FHPP Control Data					
PNU	321	1 ... 2	Record	uint32	r
Description	FHPP output data (8 bytes of status data), 4 bytes each, consistent				
		1			
	FHPP control bytes 1 ... 4 (CCON, CPOS, ...)				
		2			
	FHPP control bytes 5 ... 8				
CI	20A1h	01h ... 02h		uint32	r
DeviceNet	C: 103	A: 62 ... 63	I: 1	uint32	r

B. Parametrizing via field bus

Control Word					
PNU	330	–		uint16	rw
Description	<p>Control word: Modify the current controller status or trigger an activity. As status modifications require a certain amount of time, all status modifications triggered via the control word must be read back via the status word (6041h). Further commands cannot be written via the control word until the requested status can be read in the status word. Bit assignment: see Tab. B/10</p> <p>Special features for access via the CI interface If this object is accessed via the CI interface, the following special features must be observed compared with access via the field bus interface:</p> <ul style="list-style-type: none"> – “Reset Fault” (bit 7) as per DS402 processing with positive edge, but via CI the level will be evaluated. – START bit (bit 4) with homing and positioning: as per DS402 edge-triggered, but via CI the level will be evaluated. 0-set interpreted as stop. – “HMI access locked” (bit 14): only accessible via the field bus. – Switch to “Operation enable” may simultaneously contain action-triggering bits (START, Jog, ...). – Shortened status transitions: <ul style="list-style-type: none"> – Command “Operation disable” or “Switch on” (same coding): Status “OPERATION ENABLE” -> “READY TO SWITCH ON”. Status “READY TO SWITCH ON” -> “SWITCHED ON”. – “Disable voltage” command (bit 1 = 0, rest irrelevant) – all states -> “READY TO SWITCH ON”. – “Operation enable” command (all states) -> “OPERATION ENABLE”. – “Voltage disable” and “Quick stop” commands -> “READY TO SWITCH ON” <p>Typical values for access via the CI interface: see Tab. B/11</p>				
CI	6040h	00h		uint16	rw
DeviceNet	C: 103	A: 70	I: 1	uint16	r

B. Parametrizing via field bus

Bit	Value	Description
0 ... 8		Bits 0 ... 8 are only used together: – for access via the CI interface: see Tab. B/11
9	0x0200	Reserved (= 0)
10	0x0400	
11	0x0800	log Mode positive (like FHPP CPOS.B3)
12	0x1000	log Mode negative (like FHPP CPOS.B4)
13	0x2000	Teach (like FHPP CPOS.B5)
14	0x4000	In direct mode: 0 = normal path generator 1 = energy optimised Note: Only available for control via the field bus, not via CI.
15	0x8000	In direct mode: 0 = configured values for acceleration and deceleration 1 = symmetrical ramp (deceleration = acceleration) Note: Only available for control via the field bus, not via CI.

Tab. B/10: Bit assignment control word 6040h

Value	Function
0x000F	ENABLE OPERATION, Controller enable
0x000D	VOLTAGE DISABLE, end stage off
0x001F	Start ABSOLUTE movement
0x005F	Start RELATIVE movement
0x010F	Stop movement
0x008F	Reset error + ENABLE OPERATION
0x004F	Set target position as RELATIVE

Tab. B/11: Typical values control word
(only for access via CI)

B. Parametrizing via field bus

Status Word					
PNU	331	–		uint16	r
Description	<p>Status word: Reading the controller state. Bit assignment: See Tab. B/12</p> <p>Note for access via the CI interface If this object is accessed via the CI interface, the following special features must be observed compared with access via the field bus interface:</p> <ul style="list-style-type: none"> – Bit 4 in CI reversed polarity relative to DS402. – In the FAULT state, when power is applied to the axis, the state is indicated not as xxx8, but as xxxA, i. e. “Switched on” is set. 				
CI	6041h	00h		uint16	r
DeviceNet	C: 103	A: 71	I: 1	uint16	r

B. Parametrizing via field bus

Bit	Value	Description																			
0	0x0001	Ready to switch on	<div>Bits 0 ... 3, 5 and 6 show the status of the device (x ... irrelevant for this status)</div> <table><tr><th>Value (binary)</th><th>Status</th></tr><tr><td>xxxx xxxx x0xx 0000</td><td>Not ready to switch on</td></tr><tr><td>xxxx xxxx x1xx 0000</td><td>Switch on disabled</td></tr><tr><td>xxxx xxxx x01x 0001</td><td>Ready to switch on</td></tr><tr><td>xxxx xxxx x01x 0011</td><td>Switched on</td></tr><tr><td>xxxx xxxx x01x 0111</td><td>Operation enabled</td></tr><tr><td>xxxx xxxx x00x 0111</td><td>Quick stop active</td></tr><tr><td>xxxx xxxx x0xx 1111</td><td>Fault reaction active</td></tr><tr><td>xxxx xxxx x0xx 1000</td><td>Fault</td></tr></table>	Value (binary)	Status	xxxx xxxx x0xx 0000	Not ready to switch on	xxxx xxxx x1xx 0000	Switch on disabled	xxxx xxxx x01x 0001	Ready to switch on	xxxx xxxx x01x 0011	Switched on	xxxx xxxx x01x 0111	Operation enabled	xxxx xxxx x00x 0111	Quick stop active	xxxx xxxx x0xx 1111	Fault reaction active	xxxx xxxx x0xx 1000	Fault
Value (binary)	Status																				
xxxx xxxx x0xx 0000	Not ready to switch on																				
xxxx xxxx x1xx 0000	Switch on disabled																				
xxxx xxxx x01x 0001	Ready to switch on																				
xxxx xxxx x01x 0011	Switched on																				
xxxx xxxx x01x 0111	Operation enabled																				
xxxx xxxx x00x 0111	Quick stop active																				
xxxx xxxx x0xx 1111	Fault reaction active																				
xxxx xxxx x0xx 1000	Fault																				
1	0x0002	Switched on																			
2	0x0004	Operation enabled																			
3	0x0008	Fault																			
4	0x0010	Voltage enabled																			
5	0x0020	Quick stop																			
6	0x0040	Switch on disabled																			
7	0x0080	Warning																			
8	0x0100	Drive is moving (like FHPP SPOS.B4)																			
9	0x0200	Higher-order controller (“Remote”, like FHPP SCON.B5)																			
10	0x0400	Target reached (= Motion Complete) (parameterisable via 6067h and 6068h)																			
11	0x0800	I²t error (“Internal limit active”)																			
12	0x1000	Depends on operating mode (object 6060h): – Profile Position Mode: “Setpoint_acknowledge” – Homing Mode: “Homing_attained” – Profile Torque Mode: is being performed																			
13	0x2000	Depends on operating mode (object 6060h): – Positioning Mode: contouring error – Homing Mode: “Homing_error” – Profile Torque Mode: Stroke limit reached																			
14	0x4000	Teach acknowledge (confirmation of a teach procedure)																			
15	0x8000	Drive is referenced																			

Tab. B/12: Bit assignment status word 6041h

B. Parametrizing via field bus

Operation Mode					
PNU	332	–	Var	int8	rw
Description	Operation mode of the controller: 0xF9: FHPP Continuous Mode (-7d) 0xFE: Demo Mode (fixed sequence) 0x01: Profile Position Mode (positioning mode) 0x04: Profile Torque Mode (force mode) 0x06: Homing Mode (homing run mode)				
CI	6060h	00h		int8	rw
DeviceNet	C: 103	A: 72	I: 1	int8	rw

Operation Mode Display					
PNU	333	–	Var	int8	r
Description	Reading the operating mode of the controller. Values see object 6060h				
CI	6061h	00h		int8	r
DeviceNet	C: 103	A: 73	I: 1	int8	r

Position Sampling – Position Rising Edge					
PNU	350	–	Var		r
Description	Position for a rising edge in [Increments], see section 5.6.12				
CI	204Ah	05h		int32	r
DeviceNet	C: 103	A: 100	I: 1	int32	r

Position Sampling – Position Falling Edge					
PNU	351	–	Var		r
Description	Position for a falling edge in [Increments], see section 5.6.12				
CI	204Ah	06h		int32	r
DeviceNet	C: 103	A: 101	I: 1	int32	r

B. Parametrizing via field bus

Position Sampling – Trigger Mode					
PNU	352	–	Var		rw
Description	Continuous or one-time recording. See section 5.6.12				
CI	204Ah	01h		uint16	rw
DeviceNet	C: 103	A: 96	I: 1	uint16	rw

Position Sampling – Status					
PNU	353	–	Var		rw
Description	Specifies whether an edge was registered. See section 5.6.12				
CI	204Ah	02h		uint8	rw
DeviceNet	C: 103	A: 97	I: 1	uint8	rw

Position Sampling – Status Mask					
PNU	354	–	Var		rw
Description	Display in the status byte SPOS and status word 6041h. See section 5.6.12				
CI	204Ah	03h		uint8	rw
DeviceNet	C: 103	A: 98	I: 1	uint8	rw

Position Sampling – Control Byte					
PNU	355	–	Var		rw
Description	Reaction to rising or falling edges. See section 5.6.12				
CI	204Ah	04h		uint8	rw
DeviceNet	C: 103	A: 99	I: 1	uint8	rw

B.4.7 Positioning record table (Record list)



Parameteising:
With FHPP, record selection for reading and writing is done via the **subindex** of the PNUs 401 ... 417.

Positioning record	Sub-index	PNU 401 RCB1	PNU 402 RCB2	PNU 404 Target position	PNU 405 Wait time	...	PNU 417
0	00	Homing run					
1	01
2	02
...
31	31

Tab. B/13: Position set table structure (record list)

B. Parametrizing via field bus



Record pointer:

The active record for **positioning or teaching** is selected via **PNU 400**.

Record Number FHPP						
PNU	400	1 ... 3	Array	uint8	r(w)	
Description						
	Record Number	400	1			rw
	Record pointer for positioning and teaching. It is also valid when the drive is not in Record Select mode (e.g. during teaching). For record selection this parameter is transferred in the cyclic I/O data. Value range: 0 ... 34 (0x00 ... 0x22) Values: 0 (0x00): Homing (positioning record 0) 1 (0x01): Positioning record 1 2 (0x02): Positioning record 2 ...: Positioning record ... 31 (0x1F): Positioning record 31 32 (0x20): Jog mode 33 (0x21): Direct mode 34 (0x22): FCT positioning record					
	Active Record	400	2			r
Record Status Byte	The number of the active record; relevant for record chaining					
	400	3				r
	Contains FHPP status byte 4 with information on record chaining (see section 5.5.2)					
CI	2033h	01h ... 03h		uint8	r(w)	
	Note: The object 2032h is provided for access via CI.					
DeviceNet	C: 103	A: 32 ... 34	I: 1	uint8	r(w)	

B. Parametrizing via field bus

Record Control Byte 1					
PNU	401	1 ... 34 _d		uint8	rw
Description Record Control Byte 1. Settings for record selection: – Relative/absolute positioning – Path generator, standard/energy-optimized 0x00: Target position is absolute, standard path generator (default) 0x01: Target position is relative to last setpoint, standard path generator 0x06: Target position is absolute, energy optimised path generator 0x07: Target position is relative to last setpoint value, energy-optimised path generator Note: The energy-optimized path generator enables higher dynamics with less heat; the parameterised positioning curve (a trapezoid as e.g. in Fig. 5/1) is not maintained exactly. The parameterised maximum values for speed and acceleration may be slightly exceeded.					
	Record 0 (positioning record 0)	401	1		
		Do not use (Homing)			
	Record 1 (positioning record 1)	401	2		
		Record control byte 1 Positioning record 1			
	Record ... (positioning record ...)	401	...		
		Record control byte 1 Positioning record 2 ... 30			
	Record 31 (positioning record 31)	401	32		
		Record control byte 1 Positioning record 31			
	Jog Mode	401	33		
		Record control byte 1 for jog mode			
	Direct Mode	401	34		
		Record control byte 1 for direct mode			
CI		20EAh	01h ... 22h	uint8	rw
	Note: The object 20E0h/01h is provided for access via CI.				
DeviceNet	C: 104	A: 1	I: 1 ... 34	uint8	rw

B. Parametrizing via field bus

Record Control Byte 2					
PNU	402	1 ... 32 _d	Array	uint8	rw
Description	Record control byte 2 For record selection: Switching condition for chained records (see section 5.6.5) Values: Bit 0: = 0 No record chaining = 1 Record chaining Bit 7: = 0 Record chaining is not locked out = 1 Record chaining is locked out				
	Record 0 (positioning record 0)	402	1		
		Do not use (Homing)			
	Record 1 (positioning record 1)	402	2		
		Record control byte 2 Positioning record 1			
	Record ... (positioning record ...)	402	...		
		Record control byte 2 Positioning record 2 ... 30			
	Record 31 (positioning record 31)	402	32		
		Record control byte 2 Positioning record 31			
CI	20EBh	01h ... 20h		uint8	rw
DeviceNet	C: 104	A: 2	I: 1 ... 32	uint8	rw

B. Parametrizing via field bus

Target Position					
PNU	404	1 ... 34 _d		int32	rw
Description Record 0 (positioning record 0) Record 1 (positioning record 1) Record ... (positioning record ...) Record 31 (positioning record 31) Jog Mode Direct Mode	Target positions in [Increments]				
	404	1			
	Do not use (Homing)				
	404	2			
	Target position of positioning record 1				
	404	...			
	Target positions of positioning records 2 ... 30				
	404	32			
	Target position of positioning record 31				
	404	33			
	Target position for jog mode				
	404	34			
	Target position for direct mode				
CI	20ECh	01h ... 22h		int32	rw
	Note: The object 20E0h/02h is provided for access via CI.				
DeviceNet	C: 104	A: 4	I: 1 ... 34	int32	rw

B. Parametrizing via field bus

Record Delay					
PNU	405	1 ... 32 _d		int32	rw
Description	Waiting time for record chaining (= set chaining): The time between “Motion Complete” of a chained positioning record and the start of the next positioning record. Value range: 1 ... 60000 ms				
	Record 0 (positioning record 0)	405	1		
		Do not use (Homing)			
	Record 1 (positioning record 1)	405	2		
		Delay after positioning record 1			
	Record ... (positioning record ...)	405	...		
		Delay after positioning record 2 ... 30			
	Record 31 (positioning record 31)	405	32		
		Delay after positioning record 31			
	CI	20E4h	01h ... 20h		int32
Note: The object 20E0h/08h is provided for access via CI.					
DeviceNet	C: 104	A: 5	I: 1 ... 32	int32	rw

B. Parametrizing via field bus

Velocity					
PNU	406	1 ... 32 _d		uint32	rw
Description	Speed setpoint value in [Increments/s]				
	Record 0 (positioning record 0)	406	1		
	Do not use (Homing)				
	Record ... (positioning record ...)	406	...		
	Speed of Positioning Record 1 ... 30				
	Record 31 (positioning record 31)	406	32 (20h)		
	Speed of Positioning Record 31				
CI	20EDh	01h ... 21h		uint32	rw
	Subindex 20ED/21h: → PNU 531 (Speed in inching operation) Note: The object 20E0h/03h is provided for access via CI.				
DeviceNet	C: 104	A: 6	I: 1 ... 32	uint32	rw

B. Parametrizing via field bus

Acceleration					
PNU	407	1 ... 32 _d		uint32	rw
Description Record 0 (positioning record 0) Record ... (positioning record ...) Record 31 (positioning record 31)	Acceleration setpoint value in Increments/s ² The value applies only to positioning; with force control the value is ignored.				
	407	1			
	Do not use (Homing)				
	407	...			
	Acceleration setpoint value positioning record 1 ... 30				
	407	32 (20h)			
CI	Acceleration setpoint value positioning record 31				
	20EEh	01h ... 22h		uint32	rw
Subindex 20EE/21h: → PNU 532 (Speed in inching operation) Subindex 20EE/22h: → PNU 541 (Acceleration in direct mode) Note: The object 20E0h/04h is provided for access via CI.					
DeviceNet	C: 104	A: 7	I: 1 ... 32	uint32	rw

B. Parametrizing via field bus

Deceleration					
PNU	408	1 ... 33 _d		uint32	rw
Description Record 0 (positioning record 0) Record ... (positioning record ...) Record 31 (Positioning Record 31) Jog Mode (inching operation)	Deceleration setpoint value for braking, in [Increments/s ²]. The value applies only to positioning; with force control the value is ignored.				
	408	1			
	Do not use (Homing)				
	408	...			
	Deceleration Positioning Record 1 ... 30				
	408	32 (20h)			
	Positioning record deceleration 31				
	408	33 (21h)			
	Deceleration in jog mode				
CI	20EFh	01h ... 22h		uint32	rw
	Subindex 20EF/22h: → PNU 542 (Deceleration in direct mode) Note: The object 20E0h/04h is provided for access via CI.				
DeviceNet	C: 104	A: 8	I: 1 ... 33	uint32	rw

B. Parametrizing via field bus

Jerk Acceleration					
PNU	409	1 ... 33 _d		uint32	rw
Description Record 0 (Positioning Record 0) Record ... (positioning record ...) Record 31 (Positioning Record 31) Jog Mode	Acceleration jerk in [Increments/s ³] The calculation is done with ¹ / ₁₀ of the value.				
	409	1			
	Do not use (Homing)				
	409	...			
	Jerk for position records 1 ... 30				
	409	32 (20h)			
	Jerk with positioning record 31				
	409	33 (21h)			
	Jerk in jog mode				
CI	20E7h	01h ... 22h		uint32	rw
	Subindex 20E7/22h: → PNU 543 (Jerk in direct mode) Note: The object 20E0h/05h is provided for access via CI.				
DeviceNet	C: 104	A: 9	I: 1 ... 33	uint32	rw

B. Parametrizing via field bus

Work Load					
PNU	410	1 ... 33 _d		uint32	rw
Description	Applied load: Mass in [g] of the workpiece to be transported at a positioning record Note: The mass of a tool mounted on the piston rod (or front plate) of the drive, which remains the same for all positioning records, is entered in object 6510/51h.				
	Record 0 (Positioning Record 0)	410	1		
		Do not use (Homing)			
	Record ... (positioning record ...)	410	...		
		Applied load for positioning record 1 ... 30			
	Record 31 (Positioning Record 31)	410	32 (20h)		
		Applied load for positioning record 31			
	Jog Mode	410	33 (21h)		
	Applied load in jog mode				
CI	20E8h	01h ... 22h		uint32	rw
	Subindex 20E8/22h: → PNU 544 (Applied load in direct mode) Note: The object 20E0h/06h is provided for access via CI.				
DeviceNet	C: 104	A: 10	I: 1 ... 33	uint32	rw

B. Parametrizing via field bus

Position Window Time					
PNU	415	1 ... 33 _d		uint16	rw
Description Damping time in milliseconds [ms]. If the actual position has been in the target position window for this amount of time, the “Motion Complete” bit is set in the status word. Also referred to as “Adjustment time”. Value range: 1 ... 60000 ms Default: 10 ms					
	Record 0 (Positioning Record 0)	415	1		
		Do not use (Homing)			
	Record ... (positioning record ...)	415	...		
		Damping time for positioning records 1 ... 30			
	Record 31 (positioning record 31)	415	32 (20h)		
		Damping time for position record 31			
	Jog Mode	415	33 (21h)		
		Damping time with jog mode			
CI		20E6h	01h ... 22h	uint16	rw
		Subindex 20E6/22h: → PNU 1023 (damping time for positioning in direct mode) Note: The object 20E0h/07h is provided for access via CI. 6068h contains the damping time of the currently active record.			
DeviceNet	C: 104	A: 14	I: 1 ... 33	uint16	rw

B. Parametrizing via field bus

Following Record					
PNU	416	1 ... 32 _d		uint8	rw
Description Record 0 (Positioning Record 0) Record ... (positioning record ...) Record 31 (positioning record 31)	The subsequent positioning record for a positioning record with a chaining condition = 1 Value range: 1 ... 31				
	410	1			
	Do not use (Homing)				
	410	...			
	The position record following position record 1 ... 30				
	410	32 (20h)			
	The record following record 31				
CI	20E5h	01h ... 20h		uint8	rw
	Note: The object 20E0h/09h is provided for access via CI.				
DeviceNet	C: 104	A: 15	I: 1 ... 32	uint8	rw

B. Parametrizing via field bus

Jerk Deceleration					
PNU	417	1 ... 33 _d	Array	uint32	rw
Description Record 0 (positioning record 0) Record ... (positioning record ...) Record 31 (positioning record 31) Jog Mode	Jerk when decelerating in [Increments/s ³]. The internal calculation is done with ¹ / ₁₀ of the value.				
	417	1			
	Do not use (Homing)				
	417	...			
	Jerk for deceleration of position record 1 ... 30				
	417	32 (20h)			
	Jerk for deceleration of position record 31				
	417	33 (21h)			
	Jerk deceleration in jog mode				
CI	21E1h	01h ... 22h		uint32	rw
	Subindex 21E1/22h: → PNU 547 (Jerk when braking in direct mode) Note: The object 20E0h/0Bh is provided for access via CI.				
DeviceNet	C: 104	A: 16	I: 1 ... 33	uint32	rw

B. Parametrizing via field bus

B.4.8 Project data

General project data

Project Zero Point					
PNU	500	–		int32	rw
Description	Offset of axis zero point to project zero point. Reference point for target positions with absolute positioning (compare PNU 401 and 404).				
CI	21F4h	00h		int32	rw
DeviceNet	C: 105	A: 1	I: 1	int32	rw

Software End Positions					
PNU	501	1 ... 2		int32	rw
Description	Software end positions in increments Plausibility rule: Min. limit ≤ Max. limit Factory settings: see section 5.2.6				
	Lower Limit	501	1		
		Lower software end position: Offset from axis zero point			
	Upper Limit	501	2		
		Upper software end position: Offset from axis zero point			
CI	607Bh	01h ... 02h		int32	rw
DeviceNet	C: 105	A: 2 ... 3	I: 1	int32	rw

B. Parametrizing via field bus

Max Velocity					
PNU	502	–		uint32	r
Description	Max. permitted speed in [Inc/s]				
CI	607Fh	00h		uint32	r
DeviceNet	C: 105	A: 4	I: 1	uint32	r

Max Acceleration					
PNU	503	–		uint32	r
Description	Max. permitted acceleration in [Inc/s ²]				
CI	60C5h	00h		uint32	r
DeviceNet	C: 105	A: 5	I: 1	uint32	r

Motion Profile Type					
PNU	506	–		int16	r
Description	Ramp profile Fixed = -1 (linear ramp)				
CI	6086h	00h		int16	r
DeviceNet	C: 105	A: 8	I: 1	int16	r

Force mode

Stroke Limit					
PNU	510	–		uint32	rw
Description	Stroke limitation: Maximum permitted stroke with force control. The distance of the actual position from the start position must not be more than the amount specified in this parameter. In this way you can ensure that, if force control is activated by mistake (e.g. missing work item), the axis will not perform an uncontrolled movement. This parameter is taken into account in all control modes in which the position controller is not active in the status “Operation enabled.” Monitoring can be deactivated when bit RCB1.B5 is set.				
CI	60F6h	01h		uint32	rw
DeviceNet	C: 105	A: 10	I: 1	uint32	rw

Min Torque/Force					
PNU	511	–		uint16	r
Description	The lowest permitted torque of the motor in per mill of the rated value (6076h/PNU 1036). Fixed = 300				
CI	60F6h	05h		uint16	r
DeviceNet	C: 105	A: 11	I: 1	uint16	r

Max Torque/Force					
PNU	512	–		uint16	rw
Description	The highest permitted torque of the motor in per mill of the rated value (6076h/PNU 1036). Values: 0 ... 1000				
CI	6072h	00h		uint16	rw
DeviceNet	C: 105	A: 12	I: 1	uint16	rw

B. Parametrizing via field bus

Torque/Force Profile Type					
PNU	513	–		int16	r
Description	Type of profile with which a force modification is undertaken. Fixed = 0: linear ramp				
CI	6088h	00h		int16	r
DeviceNet	C: 105	A: 13	I: 1	int16	r

Teaching

Teach Target					
PNU	520	–		uint8	rw
Description	Teach target: The parameter that is described in the next teach command with the actual position (see section 5.6.3). Values: 1 (0x01): Target position in positioning record (default). – with Record selection: Positioning record as per FHPP control bytes – with Direct mode: Positioning record as per PNU 400 2 (0x02): Axis zero point 3 (0x03): Project zero point 4 (0x04): Lower software end position 5 (0x05): Upper software end position				
CI	21FCh	00h		uint8	rw
DeviceNet	C: 105	A: 20	I: 1	uint8	rw

Jog mode

Jog Mode Velocity Phase 2					
PNU	531	–	–	uint32	rw
Description	Jog mode: Speed in phase 2 (fast travel) in [Inc/s]				
CI	20EDh	21h		uint32	rw
DeviceNet	C: 104	A: 6	I: 33	uint32	rw

Jog Mode Acceleration					
PNU	532	–	–	uint32	rw
Description	Jog mode: Acceleration in [Inc/s ²]				
CI	20EEh	21h		uint32	rw
DeviceNet	C: 104	A: 7	I: 33	uint32	rw

Jog Mode Time Slow Motion					
PNU	534	–		uint32	rw
Description	Jog mode: Duration of phase 1 (slow travel) in [ms] Default: 2000				
CI	20E9h	21h		uint32	rw
DeviceNet	C: 105	A: 34	I: 1	uint32	rw

Direct mode: Positioning mode

Direct Mode Base Velocity					
PNU	540	–		uint32	rw
Description	Reference value for speed specifications in FHPP direct mode. The master transmits a percent value, which is multiplied by the base value to reach to the final setpoint speed.				
CI	21F8h	00h		uint32	rw
DeviceNet	C: 105	A: 40	I: 1	uint32	rw

Direct Mode Acceleration					
PNU	541	–	–	uint32	rw
Description	Acceleration in direct mode in [Inc/s ²]				
CI	20EEh	22h		uint32	rw
DeviceNet	C: 104	A: 7	I: 34	uint32	rw

Direct Mode Deceleration					
PNU	542	–	–	uint32	rw
Description	Deceleration in direct mode in [Inc/s ²]				
CI	20EFh	22h		uint32	rw
DeviceNet	C: 104	A: 8	I: 34	uint32	rw

Direct Mode Jerk Acceleration					
PNU	543	–	–	uint32	rw
Description	Jerk when accelerating in direct mode in [Inc/s ³] The internal calculation is done with $\frac{1}{10}$ of the value.				
CI	20E7h	22h		uint32	rw
DeviceNet	C: 104	A: 9	I: 34	uint32	rw

B. Parametrizing via field bus

Direct Mode Work Load					
PNU	544	–	–	uint32	rw
Description	Applied load = mass of the workpiece in [g]. Note: The mass of a tool mounted on the piston rod (or front plate) of the drive, which remains the same for all positioning records, is entered in object 6510/51h.				
CI	20E8h	22h		uint32	rw
DeviceNet	C: 104	A: 10	I: 34	uint32	rw

Direct Mode Jerk Deceleration					
PNU	547	–	–	uint32	rw
Description	Jerk when decelerating in direct mode in [Inc/s^3]. The internal calculation is done with $1/10$ of the value. Note: The damping time when positioning in direct mode is specified in PNU 1023.				
CI	21E1h	22h		uint32	rw
DeviceNet	C: 104	A: 16	I: 34	uint32	rw

Direct mode: Force mode

Torque/Force Slope					
PNU	550	–		uint32	r
Description	Speed with which the force changes				
CI	6087h	00h		uint32	r
DeviceNet	C: 105	A: 50	I: 1	uint32	r

Force Target Window					
PNU	552	–		uint16	rw
Description	<p>Target window of the force: This is the amount by which the actual force may differ from the setpoint force in order to be interpreted as still being in the target window. The width of the window is twice the value transferred, with the target position in the centre of the window.</p> <p>The value is specified in $1/1000$ of the rated torque (6076h / PNU 1036).</p> <p>Value range: 0 ... 65535</p> <p>Default: 100</p>				
CI	60F6h	03h		uint16	rw
DeviceNet	C: 105	A: 52	I: 1	uint16	rw

Force Target Damping Time					
PNU	553	–		uint16	rw
Description	<p>Damping time of the force: If the actual force has been in the target window this amount of time, the “Motion Complete” bit will be set in the status word.</p> <p>Value range: 0 ... 30000 ms</p> <p>Default: 100 ms</p>				
CI	60F6h	04h		uint16	rw
DeviceNet	C: 105	A: 53	I: 1	uint16	rw

B. Parametrizing via field bus

Speed Limit					
PNU	554	–		uint32	rw
Description	Maximum permitted velocity with active force control. In this way you can ensure that, if force control is activated by mistake (e.g. work item missing), the axis will not undergo uncontrolled acceleration and move at high speed against a stop. This parameter is taken into account in all control modes in which the position controller is not active in the status “Operation enabled”.				
CI	60F6h	02h		uint32	rw
DeviceNet	C: 105	A: 54	I: 1	uint32	rw

Direct mode: FHPP Continuous Mode

Interpolation Time					
PNU	570	–		uint16	rw
Description	Time gap between two position specifications in “FHPP Continuous Mode” in [$1/10$ ms]. Value range: 0 ... 65535 See section 5.6.7				
CI	20B6h	00h		uint16	rw
DeviceNet	C: 103	A: 48	I: 1	uint16	rw

B.4.9 Axis parameters for electric drives 1

Mechanical parameters

Polarity					
PNU	1000	–		uint8	r
Description	Reversal of direction. Fixed = 1 (not adjustable)				
CI	607Eh	00h		uint8	r
DeviceNet	C: 107	A: 1	I: 1	uint8	r

Encoder Resolution					
PNU	1001	1 ... 2		uint32	r
Description	Measurement system resolution. Reflects 6410/12h				
	Encoder Increments	1001	1		
Motor Revolutions	Number of increments between two index pulses. Fixed = 2048				
	1001	2			
	Fixed = 1				
CI	608Fh	01h ... 02h		uint32	r
DeviceNet	C: 107	A: 2 ... 3	l: 1	uint32	r

B. Parametrizing via field bus

Gear Ratio					
PNU	1002	1 ... 2		uint32	r
Description	Gear unit ratio (1:1 for linear motors)				
Motor Revolutions	1002	1			
	Fixed = 1				
	1002	2			
	Fixed = 1				
CI	6091h	01h ... 02h		uint32	r
DeviceNet	C: 107	A: 4 ... 5	l: 1	uint32	r

Feed Constant Linear Axis					
PNU	1003	1 ... 2		uint32	r
Description	Feed constant / measurement system pitch: Distance in [µm] between two index pulses. Reflects 6410/13h				
Feed	1003	1			
	DFME-...-LAS: fixed = 2000 µm DNCE-...-LAS: fixed = 5000 µm				
	1003	2			
	Fixed = 1				
CI	6092h	01h ... 02h		uint32	r
DeviceNet	C: 107	A: 6 ... 7	l: 1	uint32	r

B. Parametrizing via field bus

Position Factor					
PNU	1004	1 ... 2		uint32	r
Description	Number of sensor increments per 1 measured unit of feed				
	Position factor = $\frac{\text{encoder resolution} * \text{gear ratio}}{\text{feed constant}}$				
	Numerator	1004	1		
	Position factor – numerator				
	Denominator	1004	2		
	Position factor – denominator				
CI	6093h	01h ... 02h		uint32	r
DeviceNet	C: 107	A: 8 ... 9	I: 1	uint32	r

B. Parametrizing via field bus

Axis Parameter					
PNU	1005	1 ... 6		uint32	rw
Description	Axis parameter				
	Axis Length	1005	1		
	Axis length in increments				
	–	1005	2		–
	(reserved)				
	–	1005	3		–
	(reserved)				
	Axis Type	1005	4		
	0x10 = DFME-32-100; 0x11 = DFME-32-200; 0x12 = DFME-32-320; 0x13 = DFME-40-100; 0x14 = DFME-40-200; 0x15 = DFME-40-320; 0x16 = DFME-40-400 0x20 = DNCE-32-100; 0x21 = DNCE-32-200; 0x22 = DNCE-32-320; 0x23 = DNCE-40-100; 0x24 = DNCE-40-200; 0x25 = DNCE-40-320; 0x26 = DNCE-40-400				
	–	1005	5		
	(reserved)				
	Axis Installation Position	1005	6	5	
	Mounting position of the axis: 0 = horizontal 1 = vertical				
CI	20E2h	01h ... 06h		uint32	rw
DeviceNet	C: 107	A: 10, 13, 15	I: 1	uint32	rw

Parameter homing run

Offset Axis Zero Point					
PNU	1010	–		int32	rw
Description	Offset of the axis zero point AZ to the reference point REF in [Increments] (= distance from the reference point). Factory settings: see section 5.2.5. The drive is no longer referenced after the axis zero point has been modified.				
CI	607Ch	00h		int32	rw
DeviceNet	C: 107	A: 20	I: 1	int32	rw

Homing Method					
PNU	1011	–		uint8	rw
Description	Homing method <u>Values</u> <u>Function</u> 1 (0x01): Search for limit switch in negative direction with index search 2 (0x02): Search for limit switch in positive direction with index search 7 (0x07): Search for reference switch in positive direction with index search 11 (0x0B): Search for reference switch in negative direction with index search -18 (0xEE): Search for stop in positive direction -17 (0xEF): Search for stop in negative direction The drive is no longer referenced after the homing method has been modified.				
CI	6098h	00h		uint8	rw
DeviceNet	C: 107	A: 21	I: 1	uint8	rw

B. Parametrizing via field bus

Homing Velocities					
PNU	1012	1 ... 2		int32	rw
Description	Speeds during homing				
	Search REF	1012	1		
	Speed when searching for the reference point REF in [Inc/s]				
	Search AZ	1012	2		
	Speed of travel to the axis zero point AZ in [Inc/s]				
CI	6099h	01h ... 02h		int32	rw
DeviceNet	C: 107	A: 22 ... 23	I: 1	int32	rw

Homing Required					
PNU	1014	–		uint8	r
Description		Defines whether or not homing must be carried out after switching on in order to carry out positioning tasks. Fixed = 0: Homing run must be carried out			
CI	23F6h	00h		uint8	r
DeviceNet	C: 107	A: 25	I: 1	uint8	r

Homing Max Torque/Force					
PNU	1015	–		uint8	rw
Description		Maximum force during homing in [%] Value range: 10 ... 100			
CI	23F7h	00h		uint8	rw
DeviceNet	C: 107	A: 26	I: 1	uint8	rw

Controller parameters

Quick Stop Option Code					
PNU	1019	–		uint16	r
Description	Quick stop option: Fixed = 6: Remain in stop with fast stop ramp and in the status “Fast stop active”				
CI	605Ah	00h		uint16	r
DeviceNet	C: 107	A: 29	I: 1	uint16	r

HALT Option Code					
PNU	1020	–		int16	rw
Description	Describes the reaction to a HALT signal at the controller interface (CPOS.B0 HALT) 0x01: Braking using the ramp of the current positioning record (default) 0x02: Braking using quick stop deceleration as per PNU 1029				
CI	605Dh	00h		int16	rw
DeviceNet	C: 107	A: 30	I: 1	int16	rw


Fault Reaction / STOP Option Code					
PNU	1021	–		int16	rw
Description	Describes the reaction to an error or to a STOP signal at the controller interface (CCON.B1 STOP) 0x01: Braking using the ramp of the current positioning record 0x02: Braking using quick stop deceleration as per PNU 1029 (default)				
CI	605Eh	00h		int16	rw
DeviceNet	C: 107	A: 31	I: 1	int16	rw

B. Parametrizing via field bus

Target Position Window					
PNU	1022	–		uint32	rw
Description	Target position window: Tolerance window in [Increments] Amount by which the current position may deviate from the target position, in order that it may still be regarded as being within the target window. The width of the window is twice the value transferred, with the target position in the centre of the window.				
CI	6067h	00h		uint32	rw
DeviceNet	C: 107	A: 32	I: 1	uint32	rw

Direct Mode Position Window Time					
PNU	1023	–	–	uint16	rw
Description	Damping time (= adjustment time) in direct mode in milliseconds [ms] If the actual position has been in the target position window this amount of time, the bit “Target Reached” will be set in the status word (= Motion Complete). Value range: 1 ... 60000 ms Default: 10 ms See PNU 415 (record-specific damping times in record selection) and 6068h (damping time of the active record)				
CI	20E6h	22h		uint16	rw
DeviceNet	C: 104	A: 15	I: 1 ... 32	uint16	rw

B. Parametrizing via field bus

Position Control Parameter					
PNU	1024	18 _d ... 21 _d		int32	rw
Description	 <p>Caution: Risk of injury to people and damage to property! The factory settings for the controller parameters should only be modified in exceptional cases. Unfavourable settings can lead to uncontrollable behaviour of the entire system.</p> <ul style="list-style-type: none"> • Only change the controller parameters with the aid of FCT. • Follow the instructions in FCT for the controller parameters. 				
Position Controller Closed Loop Internal Frequency		1024	18 _d (Cl: 12h)	A: 34	
		Position controller: circuit frequency. Value range: 1 ... 1000			
Position Controller Damping		1024	19 _d (Cl: 13h)	A: 35	
		Position controller: damping. Value range: 100 ... 5000			
Current Controller Gain		1024	20 _d (Cl: 14h)	A: 36	
		Current controller: gain. Value range: 100 ... 10000			
Current Controller Integrating Time Constant		1024	21 _d (Cl: 15h)	A: 37	
		Current controller: I-share. Value range: 1 ... 15000			
CI	60FBh	12h ... 15h		int32	rw
DeviceNet	C: 107	A: 34 ... 37	I: 1	int32	rw

Motor Data					
PNU	1025	1, 3		uint32	r
Description					
Serial Number	1025	1	A: 44		
	Serial number of the motor				
I ² t Factor	1025	3	A: 45		
	I ² t factor. See PNU 1027				
CI	6410h	01h, 03h		uint32	r
DeviceNet	C: 107	A: 44 ... 45	I: 1	uint32	r

B. Parametrizing via field bus

Drive Data					
PNU	1026	Various		uint32	r(w)
Description	General data of the SFC-LACI				
	Output Stage Temp	1026	1 (CI: 01h)	A: 49	r
Output Stage Max Temp	Temperature of the SFC-LACI. Range: -20 ... +120 °C				
	1026	2 (CI: 02h)	A: 50		r
Max Current	Highest temperature measured to date for the SFC-LACI, in °C. Stored in EEPROM				
	1026	4 (CI: 04h)	A: 52		rw
Device Control	Current limiting. Identical to PNU 1034 / 6073h and 6510/41h				
	1026	6 (CI: 06h)	A: 54		rw
Controller Serial Number	Identical to PNU 125 / 207Dh Bit 0 = 0: Control interface OFF, control via HMI or FCT ON Bit 0 = 1: Control interface ON To enable FCT control after the control interface has been switched off, set ENABLE OPERATION in the control word as well (object 6040h)				
	1026	7 (CI: 07h)	A: 55		r
	Serial number of the controller				
CI	6510h	Various		uint32	r(w)
Further subindices of 6510h: see section C.3					
DeviceNet	C: 107	A: 49 ... 55	I: 1	uint32	r(w)

I ² t Value					
PNU	1027	–		uint32	r
Description	Current I ² t value. See PNU 1025/4				
CI	6410h	04h		uint32	r
DeviceNet	C: 107	A: 41	I: 1	uint32	r

B. Parametrizing via field bus

Max Phase Current					
PNU	1028	–		uint32	rw
Description	Max. string current Value range: 0 ... 20000 mA Default: 15000 mA				
CI	6410h	05h		uint32	rw
DeviceNet	C: 107	A: 48	I: 1	uint32	rw

Quick Stop Deceleration					
PNU	1029	–		uint32	rw
Description	Deceleration during quick stop, in [Increments/s ²]				
CI	6085h	00h		uint32	rw
DeviceNet	C: 107	A: 42	I: 1	uint32	rw

Electronic type plate

Motor Type					
PNU	1030	–		uint16	r
Description	Classification of the motor Fixed: 0x0000				
CI	6402h	00h		uint16	r
DeviceNet	C: 107	A: 60	I: 1	uint16	r

B. Parametrizing via field bus

Max. Current					
PNU	1034	–		uint16	rw
Description	Maximum motor current in per mill of rated current (see PNU 1035). Note: The current limitation also limits the max. possible speed (or force). Higher setpoint speeds may not therefore be reached, or the drive stops. During homing: At greatly reduced values combined with high travelling resistance, there is a danger that the drive will come to a standstill and the SFC-LACI will wrongly recognize a stop.				
CI	6073h	00h		uint16	rw
DeviceNet	C: 107	A: 64	I: 1	uint16	rw

Motor Rated Current					
PNU	1035	–		uint32	rw
Description	Nominal current of the motor in [mA]. The value is fixed				
CI	6075h	00h		uint32	rw
DeviceNet	C: 107	A: 65	I: 1	uint32	rw

Motor Rated Torque/Force					
PNU	1036	–		uint32	rw
Description	Nominal force of the linear motor in [mN]. The value is fixed				
CI	6076h	00h		uint32	rw
DeviceNet	C: 107	A: 66	I: 1	uint32	rw

Objects of the standstill monitoring

Position Demand Value					
PNU	1040	–		int32	r
Description	Controller setpoint position in [Increments]				
CI	6062h	00h		int32	r
DeviceNet	C: 107	A: 68	I: 1	int32	r

Position Actual Value					
PNU	1041	–		int32	r
Description	Actual position in [Increments]				
CI	6064h	00h		int32	r
DeviceNet	C: 107	A: 69	I: 1	int32	r

Standstill Position Window					
PNU	1042	–		uint32	rw
Description	Standstill position window in [Increments]: Amount by which the drive may move after “Motion Complete”, until the standstill monitoring responds.				
CI	2040h	00h		uint32	rw
DeviceNet	C: 107	A: 70	I: 1	uint32	rw

Standstill Timeout					
PNU	1043	–		uint16	rw
Description	Standstill monitoring time in [ms]: Time during which the drive must be outside the standstill position window before the standstill monitoring responds. Value range: 0 ... 65535 (0xFFFF). Default: 80				
CI	2041h	00h		uint16	rw
DeviceNet	C: 107	A: 71	I: 1	uint16	rw

B.4.10 Supplementary objects

Following Error Window					
PNU	1044	–		uint32	rw
Description	Permissible size of following error (offset between actual position and setpoint position). Write 0xFFFFFFFF = following error monitoring OFF				
CI	6065h	00h		uint32	rw
DeviceNet	C: 107	A: 72	I: 1	uint32	rw

Following Error Timeout					
PNU	1045	–		uint16	rw
Description	Time that a following error may remain larger than the value specified in PNU 1044 before a following error is reported. Value range: 1 ... 60000 Default: 80 ms				
CI	6066h	00h		uint16	rw
DeviceNet	C: 107	A: 73	I: 1	uint16	rw

Commutation Point					
PNU	1050	–		int32	r
Description	Commutation point (is determined automatically) [Increments]				
CI	6410h	11h		int32	r
DeviceNet	C: 107	A: 46	I: 1	int32	r

B. Parametrizing via field bus

Measurement System Resolution					
PNU	1051	–		uint32	r
Description	Measurement resolution: Number of increments between two index pulses (fixed = 2048)				
CI	6410h	12h		uint32	r
DeviceNet	C: 107	A: 90	I: 1	uint32	r

Measurement System Pitch					
PNU	1052	–		uint32	r
Description	Measurement graduation: Distance [µm] between two index pulses				
CI	6410h	13h		uint32	r
DeviceNet	C: 107	A: 91	I: 1	uint32	r

Nominal Power					
PNU	1053	–		uint32	r
Description	Nominal power of the linear motor in [W]				
CI	6410h	14h		uint32	r
DeviceNet	C: 107	A: 47	I: 1	uint32	r

Actual Power					
PNU	1054	–		uint32	r
Description	Actual power of the linear motor in [W]				
CI	6410h	15h		uint32	r
DeviceNet	C: 103	A: 40	I: 1	uint32	r

B. Parametrizing via field bus

Offset Reference Point					
PNU	1055	–		int32	rw
Description	Distance in increments from the reference point to the retracted end position. Must be stated when homing to a stop. See Tab. 1/3.				
CI	6410h	16h		int32	rw
DeviceNet	C: 107	A: 92	I: 1	int32	rw

Commutation Status					
PNU	1056	–		uint8	r
Description	State of the commutation point search 0x00: No commutation (default) 0x01: Commutation point search active 0x10: Commutation point successfully found 0xFE: Error in commutation (POSITION PLAUSIBILITY ERROR) 0xFF: Error in commutation (COMMUTATION POINT ERROR)				
CI	2050h	00h		uint8	r
DeviceNet	C: 107	A: 74	I: 1	uint8	r

Record Power Consumption					
PNU	1057	–		uint32	r
Description	Power consumption in [W] during last positioning record				
CI	6410h	17h		uint32	r
DeviceNet	C: 107	A: 93	I: 1	uint32	r

B. Parametrizing via field bus

Positioning Time					
PNU	1058	–		uint32	r
Description	Duration of the last positioning motion in [ms]				
CI	6410h	18h		uint32	r
DeviceNet	C: 107	A: 94	I: 1	uint32	r

Actual Current					
PNU	1059	–		int32	r
Description	Actual current in [mA]				
CI	6410h	19h		int32	r
DeviceNet	C: 107	A: 95	I: 1	int32	r

Actual Coil Temp					
PNU	1060	–		int16	r
Description	Temperature of the coils of the linear motor. Measuring range: -20 ... +120 °C				
CI	6410h	31h		int16	r
DeviceNet	C: 107	A: 80	I: 1	int16	r

Max Coil Temp					
PNU	1061	–		int16	r
Description	Highest coil temperature measured to date (= motor). Is saved in EEPROM. Measuring range: -20 ... +120 °C				
CI	6410h	32h		int16	r
DeviceNet	C: 107	A: 81	I: 1	int16	r

B. Parametrizing via field bus

Lower Coil Temp Threshold					
PNU	1062	–		uint16	rw
Description	Lower temperature threshold of the coils (= motor): 70 °C A warning is triggered when this temperature is reached.				
CI	6410h	33h		uint16	rw
DeviceNet	C: 107	A: 82	I: 1	uint16	rw

Upper Coil Temp Threshold					
PNU	1063	–		uint16	rw
Description	Upper temperature threshold of the coils (= motor): 75 °C An error message is triggered when this temperature is reached. Restart only after the temperature has dropped below the lower threshold (see PNU 1062).				
CI	6410h	34h		uint16	rw
DeviceNet	C: 107	A: 83	I: 1	uint16	rw

Output Stage Actual Temperature					
PNU	1066	–		int16	r
Description	Temperature of the SFC-LACI output stage. Range: -20 ... +120 °C				
CI	6510h	31h		int16	r
DeviceNet	C: 107	A: 86	I: 1	int16	r

Output Stage Max Temperature					
PNU	1067	–		int16	r
Description	Highest temperature measured to date for the SFC-LACI, in °C. Stored in EEPROM				
CI	6510h	32h		int16	r
DeviceNet	C: 107	A: 87	I: 1	int16	r

B. Parametrizing via field bus

Output Stage Lower Threshold Temp					
PNU	1068	–		uint16	rw
Description	Lower temperature threshold for SFC-LACI: 80 °C A warning is triggered when this temperature is reached.				
CI	6510h	33h		uint16	rw
DeviceNet	C: 107	A: 88	I: 1	uint16	rw

Output Stage Upper Threshold Temp					
PNU	1069	–		uint16	rw
Description	Upper temperature threshold for SFC-LACI: 85 °C. When this temperature is reached, an error message is triggered. Restart only after the temperature has dropped below the lower threshold (see PNU 1068).				
CI	6510h	34h		uint16	rw
DeviceNet	C: 107	A: 89	I: 1	uint16	rw

Power Supply					
PNU	1070	–		int32	rw
Description	Output of power supply unit in [W]. Value range: 0 ... 3000 W. Default: 960 W. The nominal power rating must be stated exactly. Rounding (e. g. from 960 W to 1000 W) is not permitted.				
CI	6510h	50h		int32	rw
DeviceNet	C: 107	A: 57	I: 1	int32	rw

Tool Load					
PNU	1071	–		uint32	rw
Description	Tool load, e.g. a gripper on the front plate (or piston rod) of the drive				
CI	6510h	51h		uint32	rw
DeviceNet	C: 107	A: 58	I: 1	uint32	rw

B. Parametrizing via field bus

Start Delay Commutation

PNU	1072	–		uint32	rw
Description	<p>Waiting time [ms] between ENABLE and the start of the commutation point search. Default = 0 ms.</p> <p>During the search for the commutation point the drive vibrates. If several drives are fitted in a system which can vibrate and if the search for the commutation point is made at the same time, it may happen that the vibrations are superimposed and the complete system vibrates in an uncontrolled manner. The drives cannot then complete the search for the commutation point successfully.</p> <ul style="list-style-type: none"> In this case start the search for the commutation point of the drives at staggered intervals: <ul style="list-style-type: none"> by enabling the drives at staggered intervals via the PLC/IPC or via this object 				
CI	2051h	00h		uint32	rw
DeviceNet	C: 107	A: 75	I: 1	uint32	rw

Local Digital Output 1 – Function

PNU	1240	–	–	uint8	rw
Description	Out1: Use. See section 5.6.10				
CI	2421h	01h		uint8	rw
DeviceNet	C: 103	A: 112	I: 1	uint8	rw

Local Digital Output 1 – Trigger ON

PNU	1241	–	–	uint8	rw
Description	Out1: Setting condition. See section 5.6.10				
CI	2421h	02h		uint8	rw
DeviceNet	C: 103	A: 113	I: 1	uint8	rw

B. Parametrizing via field bus

Local Digital Output 1 – Trigger OFF					
PNU	1242	–	–	uint8	rw
Description	Out1: Resetting condition. See section 5.6.10				
CI	2421h	03h		uint8	rw
DeviceNet	C: 103	A: 114	I: 1	uint8	rw

Local Digital Output 1 – Value ON					
PNU	1243	–	–	int32	rw
Description	Out1: Setting with record number comparison: See section 5.6.10				
CI	2421h	04h		int32	rw
DeviceNet	C: 103	A: 115	I: 1	int32	rw

Local Digital Output 1 – Value OFF					
PNU	1244	–	–	int32	rw
Description	Out1: Resetting with record number comparison: See section 5.6.10				
CI	2421h	05h		int32	rw
DeviceNet	C: 103	A: 116	I: 1	int32	rw

Local Digital Output 1 – Direction Value ON					
PNU	1245	–	–	uint8	rw
Description	Out1: Edge type for setting condition. See section 5.6.10				
CI	2421h	06h		uint8	rw
DeviceNet	C: 103	A: 117	I: 1	uint8	rw

B. Parametrizing via field bus

Local Digital Output 1 – Direction Value OFF					
PNU	1246	–	–	uint8	rw
Description	Out1: Edge type for resetting condition. See section 5.6.10				
CI	2421h	07h		uint8	rw
DeviceNet	C: 103	A: 118	I: 1	uint8	rw

Local Digital Output 1 – Delay					
PNU	1247	–	–	uint16	rw
Description	Out1: Delay time for resetting. See section 5.6.10				
CI	2421h	08h		uint16	rw
DeviceNet	C: 103	A: 119	I: 1	uint16	rw

Local Digital Output 1 – Inverted					
PNU	1248	–	–	uint8	rw
Description	Out1: Invert. See section 5.6.10				
CI	2421h	09h		uint8	rw
DeviceNet	C: 103	A: 120	I: 1	uint8	rw

B. Parametrizing via field bus

Local Digital Output 2 – Function					
PNU	1250	–	–	uint8	rw
Description	Out2: Use. See section 5.6.10				
CI	2422h	01h		uint8	rw
DeviceNet	C: 103	A: 128	I: 1	uint8	rw

Local Digital Output 2 – Trigger ON					
PNU	1251	–	–	uint8	rw
Description	Out2: Setting condition. See section 5.6.10				
CI	2422h	02h		uint8	rw
DeviceNet	C: 103	A: 129	I: 1	uint8	rw

Local Digital Output 2 – Trigger OFF					
PNU	1252	–	–	uint8	rw
Description	Out2: Resetting condition. See section 5.6.10				
CI	2422h	03h		uint8	rw
DeviceNet	C: 103	A: 130	I: 1	uint8	rw

Local Digital Output 2 – Value ON					
PNU	1253	–	–	int32	rw
Description	Out2: Setting with record number comparison: See section 5.6.10				
CI	2422h	04h		int32	rw
DeviceNet	C: 103	A: 131	I: 1	int32	rw

B. Parametrizing via field bus

Local Digital Output 2 – Value OFF					
PNU	1254	–	–	int32	rw
Description	Out2: Resetting with record number comparison: See section 5.6.10				
CI	2422h	05h		int32	rw
DeviceNet	C: 103	A: 132	I: 1	int32	rw

Local Digital Output 2 – Direction Value ON					
PNU	1255	–	–	uint32	rw
Description	Out2: Edge type for setting condition. See section 5.6.10				
CI	2422h	06h		uint8	rw
DeviceNet	C: 103	A: 133	I: 1	uint8	rw

Local Digital Output 2 – Direction Value OFF					
PNU	1256	–	–	uint8	rw
Description	Out2: Edge type for resetting condition. See section 5.6.10				
CI	2422h	07h		uint8	rw
DeviceNet	C: 103	A: 134	I: 1	uint8	rw

Local Digital Output 2 – Delay					
PNU	1257	–	–	uint16	rw
Description	Out2: Delay time for resetting. See section 5.6.10				
CI	2422h	08h		uint16	rw
DeviceNet	C: 103	A: 135	I: 1	uint16	rw

B. Parametrizing via field bus

Local Digital Output 2 – Inverted					
PNU	1258	–	–	uint8	rw
Description	Out2: Invert. See section 5.6.10				
CI	2422h	09h		uint8	rw
DeviceNet	C: 103	A: 136	I: 1	uint8	rw

Local Digital Output 2 – PWM Value					
PNU	1259	–	–	uint16	rw
Description	Out2: PWM value. See section 5.6.10				
CI	2422h	0Ah		uint16	rw
DeviceNet	C: 103	A: 137	I: 1	uint16	rw

B. Parametrizing via field bus

Limit Switch Polarity					
PNU	1300	–	–	int16	rw
Description	Limit switch type: 0 = no limit switch 1 = N/C contact 2 = N/O contact				
CI	6510h	11h		int16	rw
DeviceNet	C: 103	A: 74	I: 1	int16	rw

Limit Switch Selector					
PNU	1301	–	–	int16	rw
Description	Input for limit switch. 0 none 1 IN0 = limit switch negative IN1 = limit switch positive 2 IN0 = limit switch positive IN1 = limit switch negative 3 IN0 = limit switch negative IN2 = limit switch positive 4 IN0 = limit switch positive IN2 = limit switch negative 5 IN1 = limit switch negative IN2 = limit switch positive 6 IN1 = limit switch positive IN2 = limit switch negative				
CI	6510h	12h		int16	rw
DeviceNet	C: 103	A: 75	I: 1	int16	rw

Homing Switch Selector					
PNU	1302	–	–	int16	rw
Description	Input for reference switch: 0 = none 1 = IN0 2 = IN1 3 = IN2				
CI	6510h	13h		int16	rw
DeviceNet	C: 103	A: 76	I: 1	int16	rw

B. Parametrizing via field bus

Homing Switch Polarity					
PNU	1303	–	–	int16	rw
Description	Reference switch type: 0 = N/C contact 1 = N/O contact				
CI	6510h	14h		int16	rw
DeviceNet	C: 103	A: 77	I: 1	int16	rw

Limit Switch Deceleration					
PNU	1304	–	–	int32	rw
Description	Limit switch deceleration: Braking in [m/s ²] with limit switch signal				
CI	6510h	15h		int32	rw
DeviceNet	C: 103	A: 78	I: 1	int32	rw

Sample Input					
PNU	1305	–	–	uint32	rw
Description	Input for on-the-fly measurement (position sampling) Value = 1: Sampling at IN1 Value = 2: Sampling at IN2. See section 5.6.12				
CI	6510h	16h		uint32	rw
DeviceNet	C: 103	A: 79	I: 1	uint32	rw

Sample Switch Polarity					
PNU	1306	–	–	uint8	rw
Description	Type of proximity switch used for position sampling. 0 = N/C contact 1 = N/O contact				
CI	6510h	1Ch		uint8	rw
DeviceNet	C: 103	A: 84	I: 1	uint8	rw

B. Parametrizing via field bus

Brake Delay Time Switch ON					
PNU	1310	–	–	uint16	rw
Description	Brake: Switch on delay, see section 5.6.11				
CI	6510h	17h		uint16	rw
DeviceNet	C: 103	A: 80	I: 1	uint16	rw

Brake Delay Time Switch OFF					
PNU	1311	–	–	uint16	rw
Description	Brake: Switch-off delay, see section 5.6.11				
CI	6510h	18h		uint16	rw
DeviceNet	C: 103	A: 81	I: 1	uint16	rw

Automatic Brake Time					
PNU	1312	–	–	uint16	rw
Description	Activation time of the automatic brake. See section 5.6.11				
CI	6510h	19h		uint16	rw
DeviceNet	C: 103	A: 82	I: 1	uint16	rw

B. Parametrizing via field bus

CI interface

Appendix C

Contents

C.1 The CI interface C-3

 C.1.1 Using the parameterising interface C-3

 C.1.2 Accessing the CI objects C-4

 C.1.3 Access via a terminal program C-5

 C.1.4 Composition of the CI commands C-6

 C.1.5 Checking the data C-9

C.2 Reference CI C-11

 C.2.1 Object overview (Index, Subindex) C-11

C.3 Description of additional CI objects C-21

 C.3.1 Communication Profile Area C-22


 C.3.2 Manufacturer Specific Profile Area C-23

 C.3.3 Standardised Device Profile Area C-29

C.1 The CI interface

C.1.1 Using the parameterising interface

The parameterising interface (RS232) can be used to access the objects of the “Command Interpreter” (CI) for the SFC-LACI. The FCT accesses the CI objects, too.



1 Parameterising interface (RS232)



Caution

Not using the parameterising interface as designated causes injury to people and material damage

The parameterising interface (RS232) is

- not electrically isolated and
- not real-time capable.

It is not intended for permanent connection to PC systems or as a controller interface.

Controlling the SFC-LACI via RS232 requires, among other things, a risk assessment by the user, ambient conditions free of interference and reliability of data transmission e.g. via the control program of the higher-order control system.

- Note that control of the SFC-LACI via the RS232 does not comply with designated use.
- Use the connection only for parameterising, commissioning and diagnosis.

C.1.2 Accessing the CI objects

CI objects are accessed via

- FCT or
- a terminal program.



Caution

Faulty parameterisation can cause personal injury and material damage.

Incorrect parameterisation of the CI objects can cause the controller to react unexpectedly and the motor may start uncontrolled.

- It is preferable to use the FCT or the control panel for parameterising and commissioning.
The FCT and control panel take into account mutual dependencies between the objects and, in part, prevent incorrect parameter settings.
- Use CI commands only if you already know their effects and if they are permitted for your SFC-LACI. Note that some commands reorganise or delete parts of the memory.
- Select the commands in accordance with the object list in section C.2. Observe the associated detailed descriptions.
- Use the CI commands only in special cases which require direct access to the controller.

C.1.3 Access via a terminal program

For data transmission you will require a commercially-available terminal program or the integrated CI terminal of the SFC-LAC PlugIn in the Festo Configuration Tool.

- 1. Connect the SFC-LACI to your PC (see section 3.5).
- 2. Configure your PC's COM interface:

Settings of the COM interface	
Transmission speed (baud rate)	38400 Baud
Data format	Asynchronous character frame: <ul style="list-style-type: none">– 1 start bit– 8 data bits– No parity bit– 1 stop bit

Tab. C/1: Settings of the COM interface

- 3. You can use the following command to initialise data transmission and determine the SFC-LACI's response readiness:

Command	Reply
1 <CR>	11 <CR>

C.1.4 Composition of the CI commands

The CI objects implemented in the SFC-LACI are based on CANopen DS402:

Group 1xxx	Objects for device description
Group 2xxx	Festo objects
Group 6xxx	Objects as per CANopen

The “CiA Draft Standard 402” deals with the implementation of CANopen in drive controllers.

Access procedure

Every object has a unique number (index, subindex) which is used for accessing the object.

The higher-order controller sends the controller either a write command (WRITE) to modify an object, or a read command (READ) to read out an object.

For each command the higher-order controller receives a response which either contains the value read or, in the case of a write command, serves as an acknowledgement. The transmitted value (1, 2 or 4 data bytes) depends on the data type of the object to be read or written.

WRITE (W)

Write commands (W) transfer a value in the specified format to the SFC-LACI. As a response, write commands are echoed character by character from the SFC-LACI. A checksum <PS> is inserted in front of the <CR> (“Carriage Return”).

READ (R)

Read commands (R) transfer a value from the SFC-LACI. The response contains the read value. A checksum <PS> is inserted in front of the <CR>.



All commands are entered as a character sequence without empty spaces. A hex character is a Char character in hex format.

Syntax of the read and write commands

Acc ¹⁾	Command	Reply
W W ²⁾	=IIIISS:<value><CR> =IIIISS:<Value><PS><CR>	=IIIISS:<Value> <PS> <CR>
R R ²⁾	?IIIISS<CR> ²⁾ ?IIIISS<PS><CR>	=IIIISS:<Value> <PS> <CR>
¹⁾ Access: W = write, R = read ²⁾ When checksum checking is activated (Object 20F3h)		

Tab. C/2: Syntax of a CI command / CI reply

Syntax	Explanation
“=”, “?”	Initial character for write or read commands
IIII	Index in 4 hexadecimal digits
SS	Subindex in 2 hexadecimal digits If the addressed object does not have subindices, <00> is specified.
“:”	Separating character
<Value>	Data in a format depending on data type
<PS>	Checksum in 2 hexadecimal digits
<CR>	End character <Carriage Return> (\$0D)

Tab. C/3: Syntax elements of a CI command / CI reply

Data type

The transmitted value (1, 2 or 4 data bytes as hex number) depends on the data type of the object to be read or written. The following data types are supported:

Type	Hex	Format
UINT8	2H	8 bits without sign: 0 ... 255
INT8		8 bits with sign: -128 ... 127
UINT16	4H	16 bits without sign: 0 ... 65535
INT16		16 bits with sign: -32768 ... 32767
UINT32	8H	32 bits without sign: 0 ... ($2^{32} - 1$)
INT32		32 bits with sign: $-2^{31} \dots +(2^{31} - 1)$
V-string	Corresponds to the preset string	

Tab. C/4: Data types

All values are transferred in hexadecimal figures; one character represents 4 bits; and is known as a tetrad <Tn>. The first tetrad transferred contains the higher-value bits of the value. Generally: Tetrad <Tn> contains the bits $b_n \dots b_{n+3}$

Example: UINT8

Dec	26							
Hex	1				A			
Bin	0	0	0	1	1	0	1	0
	b_7	b_6	b_5	b_4	b_3	b_2	b_1	b_0
	Tetrad T_4				Tetrad T_0			



Note

All length specifications (also velocities and similar) are saved in millimetres in the controller and are not converted into the relevant unit of measurement system until they are written or read.

Values must be converted to **increments** before being transmitted over the CI interface; see section A.3.

C.1.5 Checking the data

Permitted value ranges

Transferred parameters and values are checked by the SFC-LACI before being accepted.



Note

In the case of invalid parameters or values, an error message will not appear in the response; rather, the received value will always be returned (Echo).



Recommendation

Check that values have been written correctly by downloading the current contents of the object with a subsequent Read command. The higher level controller must compare the sent command with the “Echo” from the SFC-LACI and check the checksum.



Note

The following applies when writing the objects:

- Discrete values (values from a value list):
an invalid value will not be accepted; the previously valid value will be retained.
- Continuous values (e.g. lengths, speeds, etc.):
an impermissible value will be limited to the nearest permitted value.

Error messages

If there are errors in the commands (e.g. syntax errors, transmission errors), the value <0x00FF> will be transmitted (object 2FF0h) instead of the usual reply. Possible causes:

- Incorrect initial character, separating character or empty character
- Incorrect hex digit
- Incorrect value type

Checksum <PS>

If checksum checking of telegrams received from the SFC-LACI was activated (see CI object 20F3h), then the higher level controller must also provide a checksum before the termination character (CR = Carriage return) (for syntax, see Tab. C/2).

If the SFC-LACI detects a deviation in the checksum, then – instead of the usual response – the value <0xFFFF> will be transferred (see Object 2FF0h).

The checksum of the **command** is calculated based on the case (upper/lower case). The checksum of the **response** is always based on upper case.

Checksum <PS>	
Calculation	<div>Sum of all ASCII characters sent, reduced to 1 byte.</div> <div>W: <PS> = “=IIIISS:<Value>” modulo 256</div> <div>R: <PS> = “?IIIISS” modulo 256</div> <div>Example:</div> <div>Command =IIIISS:<Value>×CR></div> <div> =20F300:00</div> <div>ASCII-> = 2 0 F 3 0 0 : 0 0</div> <div>HEX 3D+32+30+46+33+30+30+3A+30+30</div> <div>Sum 212h</div> <div>Mod 256 212h mod 100h = 12h</div> <div>Response =20F300:0012</div>
Format	2 Hexadecimal numbers, UINT8

Tab. C/5: Checksum

C.2 Reference CI

C.2.1 Object overview (Index, Subindex)

The following overview shows all CI objects, where appropriate with the corresponding FHPP parameter numbers.

**Note**

The following table contains an overview of the CI objects. Some of the objects may be used only for certain product variants or only with limitations (e.g. writing only for service purposes). Note the detailed descriptions of the object.



A detailed description of the CI objects can be found in

- the FHPP parameter number PNU in the sections B.4.4 to B.4.10,
- if there is no PNU: under the object number in section C.3.

C. CI interface

Name	CI Object		FHPP
	Index	Sub	PNU
Group 1xxx			
Device Type	1000h	–	–
Manufacturer Device Name	1008h	–	120
Manufacturer Hardware Version	1009h	–	–
Manufacturer Firmware Version	100Ah	–	–
Group 2xxx			
Record Number CI	2032h	1h	–
Record Number FHPP	2033h	1 ... 3h	400
Standstill Position Window	2040h	–	1042
Standstill Timeout	2041h	–	1043
Position Sampling – Trigger Mode	204A	1h	352
Position Sampling – Status		2h	353
Position Sampling – Status Mask		3h	354
Position Sampling – Control Byte		4h	355
Position Sampling – Position Rising Edge		5h	350
Position Sampling – Position Falling Edge		6h	351
Commutation Status	2050h	–	1056
Start Delay Commutation	2051h	–	1072
Version FHPP	2066h	–	102
Version FCT PlugIn Min.	2067h	–	–
Version FCT PlugIn Opt.	2068h	–	–
Manufacturer Hardware Version	2069h	–	100
Manufacturer Firmware Version	206Ah	–	101
Version FCT PlugIn BCD	206Bh	1 ... 2h	104

C. CI interface

Name	CI Object		FHPP PNU
	Index	Sub	
Controller Serial Number	2072h	–	114
Device Control	207Dh	–	125
FHPP Status Data	20A0h	1 ... 2h	–
FHPP Control Data	20A1h	1 ... 2h	–
Interpolation Time	20B6h	–	570
Axis Interface 1	20BAh	1 ... Ah	–
Axis Interface 2	20BBh	1 ... 3h	–
Diagnostic Event	20C8h	1 ... 10h	200
Fault Number	20C9h	1 ... 10h	201
Time Stamp	20CAh	1 ... 10h	202
Additional Information	20CBh	1 ... 10h	203
Diagnostic Memory Parameter	20CCh	1 ... 4h	204
Scaling	20D0h	1 ... 2h	–
Record Table Element	20E0h	1 ... Bh	–
Axis Parameter	20E2h	1 ... 6h	1005
Controller Type	20E3h	–	–
Record Delay	20E4h	1 ... 20h	405
Following Record	20E5h	1 ... 20h	416
Position Window Time (incl. Jog Mode)	20E6h	1 ... 21h	415
Direct Mode Position Window Time		22h	1023
Jerk Acceleration (incl. Jog Mode)	20E7h	1 ... 21h	409
Direct Mode Jerk Acceleration		22h	543
Work Load (incl. Jog Mode)	20E8h	1 ... 21h	410
Direct Mode Work Load		22h	544

C. CI interface

Name	CI Object		FHPP PNU
	Index	Sub	
Jog Mode Time Slow Motion (time phase 1)	20E9h	21h	534
Record Control Byte 1	20EAh	1 ... 22h	401
Record Control Byte 2	20EBh	1 ... 20h	402
Target Position	20ECh	1 ... 22h	404
Record Velocity	20EDh	1 ... 20h	406
Jog Mode Velocity Phase 2		21h	531
Record Acceleration	20EEh	1 ... 20h	407
Jog Mode Acceleration		21h	532
Direct Mode Acceleration		22h	541
Deceleration (incl. Jog Mode)	20EFh	1 ... 21h	408
Direct Mode Deceleration		22h	542
Data Memory Control	20F1h	1 ... 3h	127
Trace Control	20F2h	1 ... Ah	–
CI Receive Checksum Active	20F3h	–	–
FCT Password	20FAh	1 ... 2h	–
Local Password	20FBh	–	–
User Device Name	20FDh	–	121
HMI Parameter	20FFh	1 ... 4h	126
Jerk Deceleration (incl. Jog Mode)	21E1h	1 ... 21h	417
Direct Mode Jerk Deceleration		22h	547
Project Zero Point	21F4h	–	500
Direct Mode Base Velocity	21F8h	–	540
Teach Target	21FCh	–	520
Homing Required	23F6h	–	1014

C. CI interface

Name	CI Object		FHPP
	Index	Sub	PNU
Homing Max Torque/Force	23F7h		1015
Local Digital Output 1 – Function	2421h	1h	1240
Local Digital Output 1 – Trigger ON		2h	1241
Local Digital Output 1 – Trigger OFF		3h	1242
Local Digital Output 1 – Value ON		4h	1243
Local Digital Output 1 – Value OFF		5h	1244
Local Digital Output 1 – Direction Value ON		6h	1245
Local Digital Output 1 – Direction Value OFF		7h	1246
Local Digital Output 1 – Delay		8h	1247
Local Digital Output 1 – Inverted		9h	1248
Local Digital Output 2 – Function	2422h	1h	1250
Local Digital Output 2 – Trigger ON		2h	1251
Local Digital Output 2 – Trigger OFF		3h	1252
Local Digital Output 2 – Value ON		4h	1253
Local Digital Output 2 – Value OFF		5h	1254
Local Digital Output 2 – Direction Value ON		6h	1255
Local Digital Output 2 – Direction Value OFF		7h	1256
Local Digital Output 2 – Delay		8h	1257
Local Digital Output 2 – Inverted		9h	1258
Local Digital Output 2 – PWM Value		Ah	1259
Position Monitoring	2800h	1 ... 2h	300
Torque/Force Monitoring	2801h	1 ... 2h	301
Velocity Monitoring	2802h	1 ... 2h	310
Communication Error	2FF0h	–	–

C. CI interface

Name	CI Object		FHPP PNU
	Index	Sub	
Device Errors	2FF1h	–	205
Device Warnings	2FF2h	–	215
DeviceNet Address	2FF3h	–	–
DeviceNet Diagnosis	2FF4h	1 ... 6h	206
DeviceNet Baudrate	2FF5h	–	–
DeviceNet Datalength	2FF6h	–	–
Extended Device Errors A	2FFAh	–	207
Extended Device Errors B	2FFBh	–	208
Extended Device Errors C	2FFCh	–	209
Version Axis Interface	2FFDh	–	106
Cycle Number	2FFFh	–	305
Group 6xxx			
Control Word	6040h	–	330
Status Word	6041h	–	331
Quick Stop Option Code	605Ah	–	1019
HALT Option Code	605Dh	–	1020
Fault Reaction / STOP Option Code	605Eh	–	1021
Operation Mode	6060h	–	332
Operation Mode Display	6061h	–	333
Position Demand Value	6062h	–	1040
Position Actual Value	6064h	–	1041
Following Error Window	6065h	–	1044
Following Error Timeout	6066h	–	1045
Target Position Window	6067h	–	1022

C. CI interface

Name	CI Object		FHPP PNU
	Index	Sub	
Position Window Time	6068h	–	–
Velocity Demand Value	606Bh	–	–
Velocity Actual Value	606Ch	–	–
Target Torque/Force	6071h	–	–
Max. Torque/Force	6072h	–	512
Max. Current	6073h	–	1034
Motor Rated Current	6075h	–	1035
Motor Rated Torque/Force	6076h	–	1036
Actual Torque/Force	6077h	–	–
Target Position	607Ah	–	–
Software End Positions	607Bh	1 ... 2h	501
Offset Axis Zero Point	607Ch	–	1010
Polarity	607Eh	–	1000
Max. Velocity	607Fh	–	502
Profile Velocity	6081h	–	–
Profile Acceleration	6083h	–	–
Profile Deceleration	6084h	–	–
Quick Stop Deceleration	6085h	–	1029
Motion Profile Type	6086h	–	506
Torque/Force Slope	6087h	–	550
Torque/Force Profile Type	6088h	–	–
Encoder Resolution	608Fh	1 ... 2h	1001
Gear Ratio	6091h	1 ... 2h	1002
Feed Constant Linear Axis	6092h	1 ... 2h	1003

C. CI interface

Name	CI Object		FHPP PNU
	Index	Sub	
Position Factor	6093h	1 ... 2h	1004
Homing Method	6098h	–	1011
Homing Velocities	6099h	1 ... 2h	1012
Max Acceleration	60C5h	–	503
Stroke Limit	60F6h	1h	510
Speed Limit		2h	554
Force Target Window		3h	552
Force Target Damping Time		4h	553
Min. Torque/Force		5h	511
Position Control Parameter	60FBh	12 ... 15h	1024
Digital Inputs	60FDh	–	303
Digital Outputs	60FEh	1 ... 2h	304
Motor Type	6402h	–	1030

C. CI interface

Name	CI Object		FHPP
	Index	Sub	PNU
Motor Data	6410h	1, 3	1025
I ² t Value		4h	1027
Max Phase Current		5h	1028
Commutation Point		11h	1050
Measurement System Resolution		12h	1051
Measurement System Pitch		13h	1052
Nominal Power		14h	1053
Actual Power		15h	1054
Offset Reference Point		16h	1055
Record Power Consumption		17h	1057
Positioning Time		18h	1058
Actual Current		19h	1059
Actual Coil Temp		31h	1060
Max. Coil Temp		32h	1061
Lower Coil Temp Threshold		33h	1062
Upper Coil Temp Threshold		34h	1063
Supported Drive Modes	6502h	–	–
Festo Order Number	6503h	–	124
Drive Manufacturer	6504h	–	122
HTTP Drive Catalog Address	6505h	–	123

C. CI interface

Name	CI Object		FHPP PNU
	Index	Sub	
Drive Data	6510h	1 ... 7h	1026
Limit Switch Polarity		11h	1300
Limit Switch Selector		12h	1301
Homing Switch Selector		13h	1302
Homing Switch Polarity		14h	1303
Limit Switch Deceleration		15h	1304
Sample Input		16h	1305
Brake Delay Time Switch ON		17h	1310
Brake Delay Time Switch OFF		18h	1311
Automatic Brake Time		19h	1312
Sample Switch Polarity		1Ch	1306
Output Stage Temperature		31h	1066
Output Stage Max Temp		32h	1067
Output Stage Lower Threshold Temp		33h	1068
Output Stage Upper Threshold Temp		34h	1069
Drive Data		41, 43, A0h	–
Power Supply		50h	1070
Tool Load		51h	1071

Tab. C/6: Overview of CI Objects

C.3 Description of additional CI objects

Some objects cannot be accessed via the field bus, but only via the CI interface. These objects are listed here.

Representation of additional CI objects					
Password					
CI	20FAh	01h ... 02h	Array	V-String	rw/r
Description	Managing the FCT password, entering the super password.				
FCT Password	20FAh	01h		V-String	
Super Password	Password for the FCT software Value: <.....> (fixed 8 characters, ASCII, 7-bit) Default: <00000000> (status upon delivery and after resetting)				
	20FAh	02h		V-String	
	Entering the super password. Resets all passwords (FCT password and HMI password, object 20FB). Contact Festo Service if you require the super password.				

- 1

Name of the object
- 2

CI object number
- 3

Subindices
- 4

Class
- 5

Type
- 6

Description of the object
- 7

If applicable: description of the subindices
- 8

Read/write permission:
r = read only
w = write only
rw = read and write

Fig. C/1: Representation of additional CI objects

C. CI interface

C.3.1 Communication Profile Area

Device Type					
CI	1000h	00h	Var	uint32	r
Description	Device type Fixed = 0				

Manufacturer Hardware Version					
CI	1009h	00h	Var	V-String	r
Description	Hardware version in the format = “V xx.yy” (xx = main version, yy = secondary version)				

Manufacturer Firmware Version					
CI	100Ah	00h	Var	V-String	r
Description	Firmware version in the format = “V xx.yy” (xx = main version, yy = secondary version)				

C.3.2 Manufacturer Specific Profile Area

Record Number CI					
CI	2032h	01h	Array ¹⁾	uint8	rw
Description	Selection of a positioning record (record pointer) : – from the CI object for the position record table 20E0h or – from the individual objects 607Ah: Target Position 6081h: Profile Velocity (speed) 6083h: Profile Acceleration 6084h: Profile Deceleration				
	Record Number	2032h	01h		uint8
	Read or write record number. 0 (0x00): reserved, do not use (Direct mode) 1 (0x01): reserved, do not use (FCT position record) 2 (0x02): Homing (position record 0) 3 (0x03): Position record 1 (default) 4 (0x04): Position record 2 ... Position record ... 33 (0x21): Position record 31				
¹⁾ Pseudo-array for compatibility					

Version FCT PlugIn Min					
CI	2067h	00h	Var	V-String	r
Description	Minimum required FCT PlugIn version Format = “xx.yy” (xx = main version, yy = secondary version)				

Version FCT PlugIn Opt					
CI	2068h	00h	Var	V-String	r
Description	Optimum FCT PlugIn version Format = “xx.yy” (xx = main version, yy = secondary version)				

Scaling					
CI	20D0h	01h, 02h	Array	uint8	r
Description	Units of measurement and decimal places on the control panel. See CI object 20FFh/PNU 126				
	Measuring Unit	01h			
	Definition of unit of measurement The setting for the unit of measurement system only affects the display. All parameters are converted to the given unit of measurement only during writing or reading. Note: The SFC-LACI operates internally with metric units; the CI interface with increments. Value: fixed = 1: millimetres, e.g. mm, mm/s, mm/s ²				
Scaling Size (no. of places after dec. point)		02h			
	Number of places after the decimal point Fixed = 2				

Record Table Element CI								
CI	20E0h	01h ... 0Bh	Record	Various			rw	
Description	Editing the entries in the positioning record table: 1. Selection of line with object 2032h (record pointer). 2. Selection of column under subindex 20E0: 01 ... 0Bh							
		20E0/01	20E0/02	20E0/03	20E0/04	20E0/05	20E0/...	
		Record number	RCW	Target position	Velocity	Acceleration	Jerk	...
		02						
	2032h→	03	<1>	<...>				
		...						
The values are only saved in the position record table with this command; no movement is made.								
Record Control Word (RCW)	20E0h	01h	uint16					
	Record control word (RCW). Corresponds to 20EAh and 20EBh Bit 0: = 0 absolute position specified; = 1 relative position specified Bit 1 ... 2: = 00 Standard path generator; = 11 Energy optimised path generator Bit 3 ... 7: Not used (= 0) Bit 8: = 0 No further record switching; = 1 further record switching Bit 9 ... 14: Not used (= 0) Bit 15: = 0 Record chaining is not locked out; = 1 Record chaining is locked out Note: The energy optimised path generator enables higher dynamics with less heat; the parameterised positioning curve (a trapezoid) is not maintained exactly. The parameterised maximum values for speed and acceleration may be slightly exceeded.							
Target Position	20E0h	02h	int32					
	Target position in [Increments] (corresponds to 607Ah and 20ECh)							
Velocity (speed)	20E0h	03h	int32					
	Speed in [Increments/s] (corresponds to 6081h und 20EDh)							
Acceleration	20E0h	04h	int32					
	Acceleration in [Increments/s²] (corresponds to 6083h and 20EEh)							

C. CI interface

Jerk Acc.	20E0h	05h	uint32	
	Acceleration jerk in [Increments/s ³]. Corresponds to 20E7h			
Work Load	20E0h	06h	uint32	
	Mass of a work item in [g] for a positioning record. Corresponds to 20E8h			
Damping Time	20E0h	07h	uint16	
	Damping time in milliseconds [ms]. If the actual position has been in the target position window for this amount of time, the “Motion Complete” bit is set in the status word. Values: 1 ... 60000 ms. Corresponds to 20E6h			
Record Delay	20E0h	08h	int32	
	For record chaining (=set chaining): The time between “Motion Complete” of a chained positioning record and the start of the next positioning record. Value range: 1 ... 60000 ms. Corresponds to 20E4h			
Following Record	20E0h	09h	uint8	
	The subsequent positioning record for a positioning record with a chaining condition = 1. Values: 1 ... 31. Corresponds to 20E5h			
Deceleration	20E0h	0Ah	int32	
	Setpoint value for deceleration in [Increments/s ²]. The value applies only to positioning; with force control the value is ignored. Corresponds to 20EFh			
Jerk Dec.	20E0h	0Bh	uint32	
	Jerk when decelerating in [Increments/s ³]. Corresponds to 21E1h			

Data Memory Control – Reset Device

CI	20F1h	03h	Array	uint8	w
Description	0x10: Reset device (EEPROM is not erased, status is identical to that after switching off/on). Further sub-indices of 20F1h: See PNU 127				

C. CI interface

Controller Type					
CI	20E3h	00h	Var	uint16	rw
Description	SFC-LACI-....IO: 0x10 = without display; 0x11 = with display SFC-LACI-....PB: 0x12 = without display; 0x13 = with display SFC-LACI-....CO: 0x14 = without display; 0x15 = with display SFC-LACI-....DN: 0x16 = without display; 0x17 = with display				

Trace Control					
CI	20F2h	01 ... 0Ah	Record	Various	
Description	Settings for recording positioning procedures using the Festo Configuration Tool (FCT)				

CI Receive Checksum Active					
CI	20F3h	00h	Var	uint8	rw
Description	When checksum checking is activated, the CI commands to the SFC-LACI must be provided with a checksum (see Tab. C/2). The checksum is calculated as per Tab. C/5. Example: Deactivate checksum: "20F300:0012" (12 = checksum). The CI terminal integrated into the FCT automatically uses checksums. Values: 0x00: deactivated (default); 0x01: activated				

FCT Password					
CI	20FAh	01h, 02h	Array	V-String	rw/w
Description	Management of the passwords				
	FCT Password	01h			rw
Super Password	Password for the FCT software Value: <.....> (fixed 8 characters, ASCII, 7-bit) Default: <00000000> (status upon delivery and after reset)				
		02h			w
	Entering the super password. Resets all passwords (FCT password and HMI password, object 20FB). Contact Festo Service if you require the super password.				

C. CI interface

Local Password					
CI	20FBh	00h	Var	V-String	rw
Description	Manages the (local) HMI password for enabling particular functions which are carried out via the control panel. Value: <.....> (fixed 8 characters, ASCII, 7-bit) Only the first 3 characters are evaluated. Default: <00000000> (status upon delivery and after reset)				

Communication Error					
CI	2FF0h	00h	Var	uint16	r
Description	Special object; see section C.1.5				

DeviceNet Address (DeviceNet address)					
CI	2FF3h	00h	Var	uint8	rw
Description	Field bus address of the SFC-LACI Values: 0 ... 63 (0x00 ... 0x3F) Default: 63 (0x3F)				

DeviceNet Baudrate (DeviceNet transmission rate)					
CI	2FF5h	00h	Var	uint8	rw
Description	Baud rate Values: 0 ... 2 Δ 125, 250, 500 kBaud				

DeviceNet Datalength					
CI	2FF6h	00h	Var	uint8	rw
Description	0x10 = 8 byte 0x11 = 16 byte				

C.3.3 Standardised Device Profile Area

Position Window Time					
CI	6068h	00h	Var	uint16	r
Description	Damping time of the relevant active record in [ms] See PNU 415				

Velocity Demand Value					
CI	6068h	00h	Var	int32	r
Description	Setpoint speed value of speed regulator in [lnc/s]				

Velocity Actual Value					
CI	606Ch	00h	Var	int32	r
Description	Actual speed value of speed regulator in [lnc/s]				

Target Torque/Force					
CI	6071h	00h	Var	int16	rw
Description	Setpoint value for force control. Specified in $1/1000$ of rated value (PNU 512). Transferred in the cyclic I/O data				

Actual Torque/Force					
CI	6077h	00h	Var	int16	r
Description	Actual value in force mode. Specified in $1/1000$ of nominal value (PNU 512)				

Target Position					
CI	607Ah	00h	Var	int32	rw
Description	Target position in [Increments] This position will be saved in the positioning record table in the line addressed by object 2032h, in the column intended. No movement is made at this point. See 20E0/02h				

Profile Velocity					
CI	6081h	00h	Var	int32	rw
Description	Final speed for a positioning procedure in [Increments/s] The value will be saved in the positioning record table in the line addressed by object 2032h, in the column intended. No movement is made at this point. See 20E0/03h				

Profile Acceleration					
CI	6083h	00h	Var	uint32	rw
Description	Acceleration for a positioning movement in [Increments/s ²], see 6081h and 20E0/04h				

Profile Deceleration					
CI	6084h	00h	Var	uint32	rw
Description	Deceleration for a positioning movement in [Increments/s ²]				

Torque/Force Profile Type					
CI	6088h	00h	Var	int16	r
Description	Type of profile with which a force modification is undertaken. Fixed: 0x0000 – Linear ramp				

Supported Drive Modes					
CI	6502h	00h	Var	uint32	r
Description	Fix = 69h (105d) Bit 0: Profile position mode Bit 1: (Velocity mode) Bit 2: (Profile velocity mode) Bit 3: Profile torque mode Bit 4: (Reserved) Bit 5: Homing mode Bit 6: FHPP Continuous Mode / Interpolated Position Mode Bit 7 ... 31: (reserved)				

Drive Data				
CI	6510h	Various	Record	r(w)
Description	General data of the SFC-LACI			
Max. Current		41h	uint16	rw
	Identical to 6073h/PNU 1034			
Device Control		43h	uint16	rw
	Identical to PNU 125/207Dh and PNU 1026/06			
Controller Serial Number		A0h	uint32	r
	Serial number of the controller in format 0xDDMMYYSSS: DD (day): 8 bit: 0x01 ... 0x1F M (month): 4 bit: 0x1 ... 0xC YY (year): 8 bit: 0x00 ... 0x63 SSS (serial no.): 12 bit: 0x001 ... 0xFFFF			

Index

Appendix D

Contents

D. Index D-1

A

Absolute position specification	5-20 , 5-41
Access Procedure	C-6
Adapter, Screw terminals	3-24
Adjusting mode	5-72
Applied load, Definition	XVI
Automatic brake	5-86
Axis zero point AZ	
Default values	5-16
Definition	1-11
Teach	5-16

B

Baud rate	5-10
BCD	XIX
Brake	5-84
Bus terminal	3-26

C

Cable	3-5
Field bus	3-18
Cables, Overview	3-5
CCON	5-36
CDIR	5-38
Checksum	C-6 , C-10
CI	XIX
Clamping unit	5-84
Classes	1-22
Commissioning	
Options	1-26

Overview	5-8
Commutation point search, With controller enable	5-13
Components	1-3
Connect, Field bus	3-18
Connection	3-4
Continuous setpoint specification	5-72
Control	3-4 , 3-16
Control panel	
[Diagnostic] menu	4-8
[Positioning] menu	4-11
[Settings] menu	4-13
Access the main menu	4-6
Key functions	4-5
Menu system	4-7
Controller, Dimensions	2-4
Conversion factors	A-6
CPOS	5-37

D

Data types	C-8
Demo mode	1-10
Device control	4-20 , 5-13 , 5-26
Device profile	1-20
DeviceNet	1-18
Classes	B-3
Object Directory	B-3
Diagnosis, FPC	6-17
Diagnosis memory	6-15
Dimensions of the controller	2-4
Direct mode	5-30 , 5-31 , 5-51
Continuous setpoint specification	5-72
Specification of a position or force	5-68

E

Earth terminal	3-4 , 3-10
----------------	------------

Earthing	3-10
EDS file	XIX , 5-28
EEPROM, Clear	1-6
Effective load, Definition	XVIII
EMC	XVI
ENABLE, Reaction when cancelling	1-8
Energy-optimised	B-67 , C-25
Error, Description	6-9
Error numbers	B-19
ESD	3-5
Explicit Messaging	XIX , 1-18 , B-3

F

Fault handling	5-46
Fault numbers	6-16
FCT	XVI , 5-23
Festo Configuration Tool	XVI , 5-23
Festo Parameter Channel (FPC)	B-15
FHPP	
FPC	1-24 , B-15
Introduction	1-23
Parameter groups	B-30
Standard	1-23 , 5-32
Field bus baud rate	3-19
Field bus cable	3-18
Field bus length	3-19
Field bus plug	3-22
FLASH memory	1-6
Force mode	5-31 , 5-53 , 5-68 , B-81

H

H-rail mounting	2-6
-----------------	-----

HALT	XVI
Hardware enable	
Application	5-76
Function	3-9
Reaction when cancelling	1-8
HMI	XVI
Homing method	
Definition	1-11
Overview	1-14
Set	5-11
Homing mode	1-10 , 5-14
Homing run	5-48 , 5-56
Definition	1-11
On the control panel	5-14
Setting parameters	4-15

I

I/O data, Cyclic	5-32
I/O interface	3-4
I/O Messages	1-19
I/O Messaging	XIX , 1-19
Implicit Messaging	XIX
Important user instructions	XII
Increments, Conversion	A-6
Index pulse warning	6-18
Inputs, local digital, Specification	3-29

J

Job identifier (AK)	B-16 , B-17
Jog mode	XVI , 4-17 , 5-58

K

Key function, Overview	4-5
------------------------	-----

L

LED	6-5
LSB	XX

M

M12 adapter	3-23
MAC ID	XX, 5-10
Master password	4-18
Measuring reference system	
Calculation rules	1-13
Diagram	1-12
Menu system	4-7
MMI	XVII
Motor connection	3-4
Mounting	
H-rail mounting	2-6
Wall mounting	2-5
MSB	XX

O

Object	XX
Object Directory	XX
CI	C-11
DeviceNet	B-3
FHPP	B-30
ODVA	1-18
On-the-fly measurement	5-87
Operating principle	1-5
Operation mode	
Demo mode	1-10, 5-22
Direct mode	5-30
FHPP	5-30

FHPP Continuous Mode	1-10
Force mode	1-10
Homing	1-10
Homing mode	1-10, 5-14
Homing run	5-14
Positioning mode	1-10
Profile position mode	1-10
Profile torque mode	1-10
Record selection	5-30
Out1	5-78
Out2	5-78
Outputs, local digital	
Application	5-77
Specification	3-28

P

Parameter channel	B-15
Parameter identifier (ParID)	B-15, B-16
Parameter number (PNU)	B-16
Parameter value (ParVal)	B-15
Parameterisation	1-26, B-15
Explicit Messaging	B-3
Parameterising interface	3-14
Password	5-92
Change/deactivate	4-19
Enter	4-19
Setup	4-18
Password protection	5-92
Path generator, energy optimised	B-67, C-25
Pictograms	XIII
PLC	XVII
PNU	XX
POSITION PLAUSIBILITY ERROR	6-10
Position record table	4-16

Position sampling	5-87
Position set	4-16
Position set/record	XVII
Teach	5-20
Positioning mode	5-31
Positioning record table	B-65
Power supply unit	3-6
Prefix	1-13
Profile position mode	1-10
Profile torque mode	1-10
Project zero point PZ, Definition	1-11
Pulse-width modulation	5-77
PWM	5-77

R

RAM	1-6
Record chaining	5-67
Record list	B-65
Record selection	5-30, 5-62
Reference point REF, Definition	1-11
Reference switch, Moving the	6-18
Relative position specification	5-20, 5-41
Reply identifier (AK)	B-18
Response identifier (AK)	B-16

S

Safety instructions	X
SCON	5-39
Scope of delivery	XI
Screw terminal adapter	3-24

SDIR	5-41
Serial interface	3-4 , 3-14
Service	XI
Service and maintenance	5-92
Set axis parameters	4-14
Set axis type	4-14
Software end positions	
Definition	1-11
Factory settings	5-18
Teach	5-18
SPOS	5-40
Standstill monitoring	5-74
STOP	XVII
Reaction when cancelling	1-8
Strain relief	3-18
Subindex (IND), B-15	
Switching logic, Definition	5-77
Switching to next record	5-67

T

Target group	XI
Teach mode	4-14 , 4-16
Teaching	XVII
Teaching via field bus	5-60
Technical data	A-3
Terminating resistor	XX , 3-26
Test run	5-22
Text markings	XIII
Tool load	XVII
Definition	XVII
Transmission errors	C-10

Transmission protocol C-5

U

Units of measurement
Conversion A-6
Overview 1-13

V

Value ranges, permitted C-9
Version XV
Voltage supply 3-4, 3-6
Example of connection 3-8
Requirements 3-8

W

Wall mounting 2-5
Warnings, Description 6-8
With position sensing magnet, Move 6-18